

STUDIO CARQUINEZ PATCH BAY

Front view, top of rack first. Left 16 ports: console buckets. Right 8: outboard, FX, monitoring. Generated 2026-09-20 from config.py.

Console core

Room sends

Tie lines

Outboard

Instruments & pedals

Aux sends & FX

Monitoring

2-track

Groups & mix bus

Amp rack

Network

Power

MIDI

Spare

Reserved

Rear not plugged in yet

Normalled

Not normalled

1

24 x 2
5 spare
0 normalled
0/37 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

Tanzb ar Out L

Sub 37 Out

Fuzz In

MXR Dist In

Reserved - Instruments & pedals

LA-2A In

UA 550 In

DBX 160 Link

SSL Fusion In L/R

API L/R In

Dbx 160A L/R In

D-Comp L/R In

902 De-esser IN 1-2

Art Comp In L/R

Tanzb ar Out R

Fuzz Out

MXR Dist Out

Reserved - Instruments & pedals

LA-2A Out

UA 550 Out

DBX 160 Link

SSL Fusion Out L/R

API L/R Out

Dbx 160A L/R Out

D-Comp L/R Out

902 De-esser OUT 1-2

Art Comp Out L/R

2

24 x 2
0 spare
16 normalled
0/48 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

Ghost Channel Insert Send 1-16

NORMALLED

Ghost Channel Insert Return 1-16

17

18

19

20

21

22

23

24

Group 1 - 8 Insert Send

Group 1 - 8 Insert Return

3

24 x 2
0 spare
24 normalled
0/44 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

Ghost Channel Insert Send 17-32

NORMALLED

Ghost Channel Insert Return 17-32

17

18

19

20

21

22

23

24

Aux 1 Out

Aux 2 Out

Aux 3 Out

Aux 4 Out

Aux 5 / 6 Out

Aux 7 Out L/R

EMT 140 In

PCM60 In

SDE 1000 In

Moog DLY In

N

N

N

N

NORMALLED

NORMALLED

4

24 x 2
3 spare
18 normalled
0/39 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

Worm hole Matched to Left Side Patch bay 1-16 top

NORMALLED

Console Line In 1-16

17

18

19

20

21

22

23

24

Aux 8 Out L/R

Moog DLY Out

Main Insert Send

NORMALLED

Main Insert Return

5

24 x 2
8 spare
16 normalled
0/32 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

Worm hole Matched to Left Side Patch bay 1-16 bottom

NORMALLED

Console Line In 17-32

17

18

19

20

21


22

23

24


6

24 x 2
8 spare
16 normalled
0/32 rear plu




7

24 x 2
0 spare
22 normalled
0/46 rear plu




8

24 x 2
0 spare
24 normalled
0/47 rear plu




9

24 x 2
0 spare
22 normalled
0/44 rear plu



10


24 x 2
2 spare
0 normalled
0/44 rear plu



AMP RACK

11 AMP RACK


24 x 2
16 spare
8 normalled
0/16 rear plug



ETHERNET

ETHERNET


Single row
2 spare
0/8 rear plug



MIDI

MIDI


Not in use
Single row
0 spare
0/22 rear plug



POWER SWITCHES

POWER SWITCHES

Single row
1 spare
0/9 rear plug



RACK 1 · EQUIPMENT (20U)

U1	POWER CONDITIONER	
U2	SWITCH PANEL	Not on the patch bay
U3	APOLLO 16 #1	Replacing both Apollos with one 1U unitPatch bay: Bay 6 · 1–16, Bay 8 · 1–16
U4	APOLLO 16 #2	Replacing both Apollos with one 1U unitPatch bay: Bay 7 · 1–16, Bay 9 · 1–16
U5	API 2500 COMPRESSOR	Patch bay: Bay 1 · 15–16, Power Switches · 3
U6–7	D-COMP	Patch bay: Bay 1 · 19–20, Power Switches · 4
U8	DBX 902 DE-ESSER ×2	Patch bay: Bay 1 · 21–22, Power Switches · 5
U9	LEXICON PCM 60 REVERB	Patch bay: Bay 3 · 18, Bay 7 · 19–20, Power Switches · 6
U10	SDE 1000 DELAY	Patch bay: Bay 3 · 19, Bay 7 · 21–22, Power Switches · 7
U11–12	DBX 160 COMPRESSORS	Patch bay: Bay 1 · 12, 17–18, Power Switches · 8–9
U13	EMT REVERB REMOTE	Could move
U14	HEADPHONE AMP	Could movePatch bay: Bay 9 · 23–24
U15	HEADPHONE POWER SUPPLY	
U16	MIDI PATCH BAY	Patch bay: <u>Midi</u> · 1–22
U17	HEARBACK UNIT	Patch bay: Bay 10 · 17–24, Ethernet · 1–8
U18	ETHERNET PATCH BAY	Patch bay: <u>Ethernet</u> · 1–20
U19–20	SOUNDCRAFT GHOST POWER SUPPLY	

OPEN QUESTIONS

MIDI HOOKUPS

0 of 11 connected

INSTRUMENT		PORT	PRIORITY	MIDI PATCH BAY
☐	Moog Sub 37	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned
☐	Waldorf Streichfett	MIDI In	Required	Not assigned
		MIDI Out	Low priority	Not assigned
☐	MFB Tanzbar	MIDI In	Required	Not assigned
		Check which MIDI ports it has	Low priority	Not assigned
☐	Sim n Tonic	MIDI In	Required	Not assigned
		Check which MIDI ports it has		
☐	Oberheim OB-X8	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned
☐	Oberheim OB-6	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned