CPPC 18/L

COMPUTER NETWORK & SECURITY

ACTIVITY No.1

File Sharing using LAN Cable

Submitted by:

LOGATOC, APRIL FOILA JOY M.

BS CpE 3B

Submitted to:

ENGR. JAN ERROL MAMPUSTI

Subject Professor

I. Objectives

- To demonstrate how two Windows PCs can share files using an Ethernet or LAN cable.
- To configure a direct network connection between two computers without using internet access.
- To assign static IP addresses to both computers.
- To enable network discovery and file sharing settings.
- To successfully access and transfer files from one PC to another.

II. Materials

- 1 Ethernet or LAN cable
- 2 Windows PCs
- Files or folder to be shared
- Built-in Windows network settings

III. Procedures

1. Connect the Two PCs Using a LAN Cable

- Insert one end of the Ethernet cable into PC 1.
- Insert the other end of the cable into PC 2.
- Wait for both computers to detect the Ethernet connection.
- Make sure the Ethernet status shows that the connection is active or connected.

2. Set the Network Profile to Private

- Perform this step on both computers.
- Open Settings.
- Go to Network & Internet.

- Select Ethernet.
- Click the connected Ethernet network.
- Change the network profile to Private.
- This allows the computers to be discoverable within the network.

3. Enable Network Discovery and File Sharing

- Do this on both PCs.
- Open Control Panel.
- Go to Network and Sharing Center.
- Click Change advanced sharing settings.
- Under the Private network section:
  - Turn ON Network discovery.
  - Turn ON File and printer sharing.
- Click Save changes to apply the settings.

4. Assign Static IP Address to PC 1

- On PC 1, open Control Panel.
- Go to Network and Sharing Center.
- Click Change adapter settings.
- Right-click Ethernet.
- Select Properties.
- Click Internet Protocol Version 4 (TCP/IPv4).
- Click Properties.
- Choose Use the following IP address.
- Enter the following configuration:

- IP Address: 192.168.1.1
- Subnet Mask: 255.255.255.0
- Default Gateway: Leave blank

- Click OK to save the configuration.

5. Assign Static IP Address to PC 2

- On PC 2, repeat the same steps used in configuring PC 1.
- Go to Ethernet Properties.
- Select Internet Protocol Version 4 (TCP/IPv4).
- Choose Use the following IP address.
- Enter the following configuration:
  - IP Address: 192.168.1.2
  - Subnet Mask: 255.255.255.0
  - Default Gateway: Leave blank
- Click OK to apply the settings.
- Make sure both PCs are using the same subnet mask so they can communicate with each other.

6. Share a Folder from One PC

- On the computer that will share the files, choose the folder to be shared.
- Right-click the folder.
- Select Properties.
- Go to the Sharing tab.
- Click Advanced Sharing.
- Check Share this folder.
- Click Permissions.

- Allow the needed permission:
  - Read if the other PC will only view or copy files.
  - Full Control if the other PC is allowed to modify or manage the files.
- Click OK to save the sharing settings.

7. Access the Shared Folder from the Other PC

- On the receiving PC, press Win + R.
- Type the IP address of the sharing PC:
  - \\192.168.1.1
- Press Enter.
- Wait for the shared folder to appear.
- Open the shared folder.
- Copy, transfer, or access the needed files.

IV. Conclusion

This activity demonstrated that two computers can share files directly using an Ethernet cable without requiring an internet connection. By configuring both PCs with static IP addresses, setting the network profile to private, and enabling network discovery and file sharing, the devices were able to communicate with each other successfully. The activity also showed that proper folder permissions are important to control access to shared files. Overall, this method provides a simple and useful way to transfer files between computers through a direct LAN connection.

V. Documentation