

Cooking and Alert Subsystem

Specification	Test Result	Comment
1. When the ON/OFF slider switch is flicked and occupancy slider switch is flicked, the green LED turns on and the user can choose their toast level.	- Pass	- Works as intended
2. When the user attempts to either turn on the toaster without it being occupied, or puts food in the toaster and forgets to turn it on (via the slider switches) the red LED turns on and the buzzer sounds, with a message on the serial monitor explaining the issue.	- Pass	- Works as intended, error message loops but that was a purposeful decision. This constantly alerts the user of the system status
3. LCD displays selected toaster level, time remaining, and danger status if gas and temperature sensors trigger	- Majority pass	- LCD displays selected toast level and danger status, but not time remaining
4. Gas and temperature sensors constantly check for changes in temperature and if gas is present, if this is the case the buzzer sounds and the red LED turns on, indicating danger	- Pass	- Works as intended, sensors have a small delay before sensing temperature and gas due to averaging readings for more accurate measurements

