

Holo2factory Configurator user guide

This application has as purpose to create a new list of cotations and set them correctly in the space. You have to correctly set the position and the orientation of the cotations. There is a 3D viewer to help you place the cotation and to have a brief renderer. The exported list will be used in the Unity application to display the cotations.



- 1. Load the 3D model, visible on the picture below
- 2. Open an existing json file (containing a list of cotations)
- 3. Clear the copy of the opened json file
- 4. List of cotations

Holo2factory 2022 Quentin Fornerod



- 1. Set the type of the cotation (Diameter, rectilign, hole)
- 2. Set the spatial coordinate of the cotation
- 3. Set the rotation of the cotation
- 4. Type the effective value of the cotation and the tolerance
- 5. Feel free to edit the position of the model
- 6. Preview, you can drag, rotate the model freely

Holo2factory 2022 Quentin Fornerod