

# ego_jerk


## max_ego_jerk





## min_ego_jerk





## avg_ego_jerk





## p90_ego_jerk






## abs_ego_jerk_within_bounds






driving_direction_compliance
driving_direction_compliance_score
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
100%
80%
60%
40%
20%
0%
Frequency (%)
0.6
0.8
1.0
1.2
1.4
value
min_progress_along_driving_direction_in_1_second_interval
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
100%
80%
60%
40%
20%
0%
Frequency (%)
−0.4
−0.2
0.0
0.2
0.4
meters


# ego_yaw_acceleration




















# ego_lat_acceleration
















# ego_is_making_progress





# ego_lon_acceleration
















# ego_progress_along_expert_route








drivable_area_compliance




# ego_is_comfortable




corners_in_drivable_area





# speed_limit_compliance






time_to_collision_within_bound
min_time_to_collision
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
5.0%
4.0%
3.0%
2.0%
1.0%
0.0%
Frequency (%)
0.0
0.2
0.4
0.6
0.8
1.0
seconds
time_to_collision_within_bound
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
100
80
60
40
20
0
Frequency (%)
False
True
boolean


# no_ego_at_fault_collisions


















ego_lane_change
number_of_ego_lane_change
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
100
80
60
40
20
0
Frequency (%)
0.0
count
ego_lane_change_fail_rate_below_threshold
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
100
80
60
40
20
0
Frequency (%)
False
True
boolean


# ego_lon_jerk


max_ego_lon_jerk
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100%
80%
60%
40%
20%
0%
0.8
1.0
1.2
1.4
1.6
1.8
meters_per_second_cubed



min_ego_lon_jerk
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100%
80%
60%
40%
20%
0%
−1.8
−1.6
−1.4
−1.2
−1.0
−0.8
meters_per_second_cubed



avg_ego_lon_jerk
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100%
80%
60%
40%
20%
0%
−0.4
−0.2
0.0
0.2
0.4
meters_per_second_cubed



p90_ego_lon_jerk
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100%
80%
60%
40%
20%
0%
0.4
0.6
0.8
1.0
1.2
meters_per_second_cubed



abs_ego_lon_jerk_within_bounds
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100
80
60
40
20
0
False
True
boolean


# ego_yaw_rate


max_ego_yaw_rate
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100%
80%
60%
40%
20%
0%
−0.4
−0.2
0.0
0.2
0.4
radians_per_second


min_ego_yaw_rate
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100%
80%
60%
40%
20%
0%
−0.4
−0.2
0.0
0.2
0.4
radians_per_second


avg_ego_yaw_rate
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100%
80%
60%
40%
20%
0%
−0.4
−0.2
0.0
0.2
0.4
radians_per_second


p90_ego_yaw_rate
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100%
80%
60%
40%
20%
0%
−0.4
−0.2
0.0
0.2
0.4
radians_per_second


abs_ego_yaw_rate_within_bounds
SDC_D3_ENDPOINT_ARC_BINDING_COMPAT_V1_BASELINE
Frequency (%)
100
80
60
40
20
0
False
True
boolean