## Mega Zero Switchwire Mod BOM

The following list of parts are applicable to modded parts. Refer to Voron Switchwire's BOM list for OEM parts.

\*\* ONLY USE SLIDE IN T-NUTS FOR PARTS CRUCIAL TO KINEMATICS \*\*

390mm Gantry Setup (Use MGN12H for AfterBurner)		340mm Gantry Setup (Use MGN12H for AfterBurne	
Item	Quantity	Item	Quantity
390mm T-Slot Aluminum Extrusion	1	340mm T-Slot Aluminum Extrusion	1
350mm MGN9H or MGN12H	1	300mm MGN9H or MGN12H	1
M3x8mm Socket Head	12	M3x8mm Socket Head	6
M3 Slide-in T-Nuts	12	M3 Slide-in T-Nuts	6
M5x40mm Socket Head	4	M5x40mm Socket Head	4
M5 Slide-in T-Nuts	4	M5 Slide-in T-Nuts	4
M3x30mm Socket Head	8	M3x30mm Socket Head	8
Custom Print Head Mount (Not Required	l if Using AfterBurner)		
M3 Brass Heat Inserts	12		
M3x6mm Socket Head	2		
M3x16mm Socket Head	4		
M3x40mm Socket Head	3		
M2x10mm Selft Tapping Socket Head	2		
KW10 Microswitch	1		
XZ Motor Mounts		XZ Motor Mounts	
M5x60mm Button Head	4	M5x35mm Button Head	4
M5 Washer (.5mm to 1mm thickness)	4	M5 Washer (.5mm to 1mm thickness)	4
M5 Slide-in T-Nuts	4	M5 Slide-in T-Nuts	4
M4x16mm Socket Head	4	M4x16mm Socket Head	4
M4 Slide-in T-Nuts	2	M4 Slide-in T-Nuts	2
XZ Motor Fences			
M5x10mm Button Head	4	NOT NEEDED	
M5 Slide-in T-Nuts	4		
XZ Top Idler Wings			
M5x10mm Button Head	4		
M5 Slide-in T-Nuts	4		
M5x40mm Button Head	2		
M5 Hex Nut	2		
			_
Z-Axis			
300mm MGN12H	2		
M3x8mm Socket Head	12		
M3 Slide-in T-Nuts	12		
M5x10mm	3		
M5 Slide-in T-Nuts	3		
Y-Axis			
MGN12H 400m	2		
Additional MGN12H Block	1		
M3x8mm Socket Head	20		
M3 Hex Lock Nut	8		
Keybak Mount and Idler			
M5x10mm	1		
M5x20mm	1		
M5 Slide-in T-Nuts	2		
M3 Brass Heat Insert M3x12mm	2		
····oxiz			
LCD Mount			
M5x10mm Button Head	3		
M5 Slide-in T-Nuts or rotating T-Nuts	3		
M3x10mm	2		
M2.5 harvest from printer	4		
Power Supply			
M4x30mm Socket Head	2		
M4x8mm Socket Head	4		
M4 Slide-in T-Nuts or rotating T-Nuts	4		
M3x8mm	2		