


Configuring your Static IP on ARRIS TG1652, TG2482 and TG2492 modem


By default, Melita's wireless modems are set to DHCP.

With the DHCP function enabled, no additional changes in setup are required for the internet connection to work.

To be able to change the connection mode from DHCP to Static IP, we suggest that you view the below video or follow the step-by-step guide.




Enter the IP 192.168.0.1 into the address bar of your browser and click enter to load the interface of the modem.




✓ By default, the User Name is 'admin' and the password is 'password'.

If you had previously changed the login details of the modem, enter the correct username and password and click 'Log In'.

Click on WAN Setup



Click on STATIC on the right-hand side



- ✓ Tick the Enable Static IP
- ✓ Input all Static IP settings provided to you by Melita.

Make sure to use the following DNS servers:

- Primary DNS: 212.56.129.228
- Secondary DNS: 212.56.132.20
- Click the Apply button when ready


Restart modem as soon as the above changes are applied.

Was this Helpful?



Search...

Q



Bundles

Flexi Bundle

Internet

Home Internet

Internet Fibre Power

Home WiFi Solution

1000 Mbps Fibre Power

Portable Internet

Umbrella Cyber Security

Television

Melita TV

Melita Sports

Interactive NexTV

OnDemand

TV Channel Line up

What's on TV

Sports Schedule

TSN Advertising

Telephony

Telephony Fixed Unlimited

International Call Rates

Telephone Directory

Mobile

Smartphones

Postpaid Plans

Hybrid Plans

Youth Plans

Prepaid Plans

Discover 5G

International Rates

Roaming

MelitaWiFi Hotspots

5G Trial Results

Register your SIM

Melita

About Us

Help Centre

Contact Us

Find A Shop

Careers Now Hiring

Blog

News & Info

Become an Affiliate

Terms and Conditions

Privacy Policy

Sustainability