POWER SUPPLY

EXT_POWER


USB_POWER

JP2


BERG-SR-3-M-ST

RELIMATE-2-M-ST


+3.3V




+1.2V




SPI FLASH




OSCILLATOR 100MHZ




CONFIG RESET




DONE




DWG NAME:		COMPANY NAME:		
DATE		TITLE:		
DESIGNED		PCB NO.	REV.	
CHECKED		SIZE:		
DRAWN		CUSTOMER:	SHEET	




FREE IO




PUSH BUTTON




LED




FREE IO



SLIDE SWITCH





RGB LED



DWG NAME:		COMPANY NAME:		
DATE		TITLE:		
DESIGNED		PCB NO.	REV.	
CHECKED		SIZE:		
DRAWN		CUSTOMER:	SHEET	

FT2232






MICROUSB2.0

USB


→ USB_PWR

→ USB_DP

EEPROM



OSCILLATOR 12MHZ



DWG NAME:		COMPANY NAME:		
DATE		TITLE:		
DESIGNED		PCB NO.	REV.	
CHECKED		SIZE:		
DRAWN		CUSTOMER:	SHEET	