Fluid Dynamics

Chapter 5

Viscous Flows and Turbulence

Ulrich H. Becker Boris Schilder

Frankfurt University of Applied Sciences




- Now: We start to consider friction!
- Important, if friction forces are of the same order of magnitude as inertial forces

Example:

Plates with different velocities

- Upper plate moving with velocity u_w
- Lower plate at rest




U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 2/55

 Fluid elements in direct contact to the wall have the same velocity as the wall: so called no-slip boundary condition

Therefore, the velocities of the fluid are:

lower plate: u(y=0)=0

upper plate: $u(y=h)=u_w$



 Due to friction between the fluid layers, a linear velocity profile is established (*):

$$u(y)=u_w\frac{y}{h}$$

(*) We check this later.

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 3/55

• The increase of velocity can be described with the angle $\Delta\gamma$ (see sketch):

$$\frac{u_{w} \cdot \Delta t}{h} = \tan(\Delta y)$$

$$\approx \Delta y \text{ if } \Delta y \ll 1$$

$$wall/plate at rest$$


moving wall/plate with u_w

 The velocity difference causes a shearing of layers in the fluid. The shear rate is given by:

$$\dot{y} = \frac{\Delta y}{\Delta t} = \frac{u_w}{h} = \frac{\mathrm{du}}{\mathrm{dy}}$$

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 4/55

- Analogy: Shear stress in solid bodies and fluids
 - Hooke's law for solid bodies: $\tau = G \gamma$
 - ⇒ shear angle as influencing parameter
 - Shear stress for Newtonian fluids: $\tau = \mu \dot{y} = \mu \frac{du}{dy}$
 - ⇒ Shear rate as influencing parameter



U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 5/55

 Newtonian fluids: Shear stress depends linearly on the shear rate:

$$\tau = \mu \, \dot{y} = \mu \, \frac{du}{dy}$$

Factor of proportionality is the material property


dynamic viscosity: μ [kg/(ms)] or [Pa s]

Alternative property:

kinematic viscosity: $v = \mu/\rho$ [m²/s]

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 6/55

- Test stand for viscosity measurement
 - Rotation of inner cylinder (height b)
 - Wall around the cylinder at rest. Gap of width h between cylinder and wall
 - Torque is measured as function of rotational speed



U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 7/55

- The viscosity is determined by calculating the shear stress in two different ways
- Consider a fluid layer with radius r and height b. A fluid element in this layer is given by a small angle dφ.
- Area of fluid element:
- Force = stress times area:
- Torque = force times lever:
- ... for the total circumference:
- Solve for τ: (Shear stress τ as a function of measured torque T)

$$dA = rb d\phi$$

$$dF = \tau dA = \tau rb d\phi$$

$$dT = r dF = \tau r^2 b d\phi$$

$$T = \int_0^{2\pi} \tau r^2 b d\phi$$

$$= 2\pi \tau r^2 b$$

$$\tau = \frac{T}{2\pi r^2 b}$$

- Consider the fluid in the gap h between the inner and outer cylinder
- h≪r => the flow behaves like the flow between horizontal plates:


$$u(y) = \frac{u_w}{h} y$$

• The wall velocity u_w is a function of the angular velocity ω of the rotating cylinder:

$$u(y) = \frac{u_w}{h} y = \frac{r \cdot \omega}{h} y \Rightarrow \frac{du}{dy} = \frac{r \cdot \omega}{h}$$

The shear stress for a Newtonian fluid is:


$$\tau = \mu \frac{du}{dy} = \mu \frac{r \cdot \omega}{h}$$



 Equating both terms for τ, the viscosity of a fluid can be determined:


$$\frac{T}{2\pi r^2 b} = \mu \frac{r \omega}{h} \quad \Rightarrow \quad \mu = \frac{Th}{2\pi r^3 b \omega}$$

 There are not only Newtonian fluids. The shear stress can depend on the shear rate in many ways (example on the right). This is the subject of Rheology.




U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 10/55

- Consider parallel plates with a pressure gradient in the x-direction
- Steady state condition
 - Balance of pressure- and friction forces
- Assumption: p = p(x) and v = v(y)
- Since $\tau = \mu \, dv/dy$, tau is a function of y: $\tau = \tau(y)$



U.H. Becker, B. Schilder

- Consider a moving CV with the dimensions Δx , Δy and Δz in the stream
 - No flow into or out of CV
 - Left boundary of CV at x_0 , right boundary at $x_0 + \Delta x$
 - Lower boundary of CV at y_0 , upper boundary at $y_0 + \Delta y$



• Pressure at the right boundary based on Taylor polynomial wrt. x_0 :

$$p(x_0 + \Delta x) \approx p(x_o) + \frac{\partial p}{\partial x}(x_0 + \Delta x - x_0) = p(x_o) + \frac{\partial p}{\partial x} \Delta x$$

Shear stress at the top from Taylor polynomial wrt. y₀:

$$\tau\left(y_{0}+\Delta y\right)\approx\tau\left(y_{o}\right)+\frac{\partial\tau}{\partial y}\left(y_{0}+\Delta y-y_{0}\right)=\tau\left(y_{o}\right)+\frac{\partial\tau}{\partial y}\Delta y$$

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 12/55

- Forces in x-direction on the left and the right:
 - Area left and right:

$$\Delta y \Delta z$$


- Pressure force on the left:

$$p(x_0)\Delta y \Delta z$$

- positive x-direction
- Pressure force on the right:

$$-\left(p(x_o) + \frac{\partial p}{\partial x} \Delta x\right) \Delta y \Delta z$$


negative x-direction!



- Friction forces in x-direction at the top and bottom
- Area at top and bottom:

$$\Delta x \Delta z$$

 Area vector at the bottom points against the y-direction



⇒ negative sign for friction term

$$-\tau(y_0)\Delta x \Delta z$$

Area vector at the top points in the y-direction
 ⇒ positive sign for friction term

$$\left(\tau(y_o) + \frac{\partial \tau}{\partial y} \Delta y\right) \Delta x \Delta z$$

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 14/55

Force equation in x-direction:

$$p \Delta y \Delta z - \left(p + \frac{dp}{dx} \Delta x\right) \Delta y \Delta z - \tau \Delta x \Delta z + \left(\tau + \frac{d\tau}{dy} \Delta y\right) \Delta x \Delta z = 0$$
$$-\left(\frac{dp}{dx} \Delta x\right) \Delta y \Delta z + \left(\frac{d\tau}{dy} \Delta y\right) \Delta x \Delta z = 0$$
$$-\frac{dp}{dx} + \frac{d\tau}{dy} = 0$$

 $\frac{dp}{dx} = \frac{d\tau}{dy}$

- Observation:
 - Left side: function of x!
 - Right side: function of y!
- Conclusion: Equality possible only for a constant.

$$\frac{dp}{dx} = \frac{d\tau}{dy} = \text{constant}$$

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 15/55

- Wanted: Function for u(y)
 - Flow velocity at each point of the cross section
- We get this from integrating $\frac{d\tau}{dv} = \mu \frac{d^2u}{dv^2}$ twice:

$$\mu \frac{d^{2}u}{dy^{2}} = \frac{d\tau}{dy} = \frac{dp}{dx}$$

$$\Rightarrow \mu \frac{du}{dy} = \int \frac{dp}{dx} dy$$

$$\Rightarrow \frac{du}{dy} = \frac{1}{\mu} \frac{dp}{dx} y + \frac{1}{\mu} c_{1}$$

$$\Rightarrow u(y) = \frac{1}{\mu} \frac{dp}{dx} \int y dy + \frac{1}{\mu} c_{1} \int dy$$

$$\Rightarrow u(y) = \frac{1}{2\mu} \frac{dp}{dx} y^{2} + \frac{1}{\mu} c_{1} y + c_{2}$$

integrate

$$\left| \frac{dp}{dx} \right| = constant$$

integrate

FRA-UAS: FID Summer Term 2024 16/55

- Calculation of the constants c₁ and c₂ from boundary conditions:
 - Lower plate at rest: u(0)=0

$$0 = \frac{1}{2\mu} \frac{dp}{dx} \cdot 0^2 + \frac{1}{\mu} c_1 \cdot 0 + c_2 \implies c_2 = 0$$

Upper plate with velocity u(h)=u_w

$$u_{w} = \frac{1}{2\mu} \frac{\mathrm{d}p}{\mathrm{d}x} \cdot h^{2} + \frac{1}{\mu} c_{1} \cdot h$$

$$\Rightarrow \frac{1}{\mu} c_{1} \cdot h = u_{w} - \frac{1}{2\mu} \frac{\mathrm{d}p}{\mathrm{d}x} \cdot h^{2}$$

$$\Rightarrow c_{1} = \mu \frac{u_{w}}{h} - \mu \frac{1}{2\mu} \frac{\mathrm{d}p}{\mathrm{d}x} \cdot h = \mu \frac{u_{w}}{h} - \frac{1}{2\mu} \frac{\mathrm{d}p}{\mathrm{d}x} \cdot h$$

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 17/55

Insert c₁ and c₂ into the equation for u(y):

$$u(y) = \frac{1}{2\mu} \frac{\mathrm{d}p}{\mathrm{d}x} y^2 + \frac{1}{\mu} y \left(\mu \frac{u_w}{h} - \frac{1}{2} \frac{\mathrm{d}p}{\mathrm{d}x} \cdot h \right)$$

$$\Rightarrow u(y) = \frac{1}{2\mu} \frac{\mathrm{d}p}{\mathrm{d}x} (y^2 - y \cdot h) + \frac{u_w}{h} \cdot y$$

• If both plates are at rest $(u_w = 0)$:

$$u(y) = \frac{1}{2\mu} \frac{\mathrm{d} p}{\mathrm{d} x} (y^2 - y \cdot h)$$


• Without pressure gradient (dp/dx = 0):

$$u(y) = \frac{u_w}{h} \cdot y$$

- This is the linear velocity profile we used before (see p.3).


U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 18/55

- Steady state, laminar, fully developed flow:
 - Fully developed: velocity profile does not change in flow direction
 - Velocity is only a function of radius r:
 - u=u(r)
 - $\tau = \mu \, du/dr \Rightarrow \tau = \tau(r)$




U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 19/55

- Steady state, laminar, fully developed flow:
 - assumption: p=p(x) (pressure is function of x)
 - What if p would depend on the radius too? For example, the pressure would be greater in the center compared to outer radius? The fluid would flow from the center to the outer radius. However, then the flow would not be fully developed!



- Force balance for CV (red) in x-direction:
 - p₁ with positive, p₂ with negative contribution
 - What about τ? The boundary of the CV is the surface of a cylinder barrel
 - The area vector points radially to the outside
 - Same direction as the r-coordinate: "plus"



U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 21/55

- General mom. equation $\sum \mathbf{F} = \sum \rho \dot{\mathbf{V}} \mathbf{v} \sum \rho \dot{\mathbf{V}} \mathbf{v}$
- Axial direction = x-direction

$$\sum_{x} F_{x} = 0 \qquad | \text{ in- and outflow cancel}$$

$$\Rightarrow p_{1}\pi r^{2} - p_{2}\pi r^{2} + \tau 2\pi r L = 0 \qquad | \text{ solve for } \tau$$

$$\Rightarrow \frac{p_{1} - p_{2}}{2L} r = -\tau = -\mu \frac{du}{dr} \qquad | \text{ use } \tau = \mu \frac{du}{dr}$$

$$\Rightarrow \frac{du}{dr} = -\left(\frac{p_{1} - p_{2}}{L} \frac{1}{2\mu}\right) r \qquad | \text{ integrate}$$

$$\Rightarrow u(r) = \int_{x} \frac{du}{dr} dr = -\left(\frac{p_{1} - p_{2}}{L} \frac{1}{2\mu}\right) \int_{x} r dr$$

$$\Rightarrow u(r) = -\left(\frac{p_{1} - p_{2}}{L} \frac{1}{4\mu}\right) r^{2} + c \qquad \text{ velocity profile}$$

FRA-UAS: FID Summer Term 2024 U.H. Becker, B. Schilder 23/55

velocity profile

Determine c with u(r=R)=0 (no slip at walls)

$$0 = -\left(\frac{p_1 - p_2}{L} \frac{1}{4\mu}\right) R^2 + c$$

$$\Rightarrow c = \left(\frac{1}{4\mu} \frac{p_1 - p_2}{L}\right) R^2$$

 In general: velocity of laminar pipe flow depends on radius r

$$u(r) = \left(\frac{1}{4\mu} \frac{p_1 - p_2}{L}\right) (R^2 - r^2)$$

 Maximal velocity occurs in the center of the pipe (r=0)

$$u_{max} = \left(\frac{1}{4 \mu} \frac{p_1 - p_2}{L}\right) R^2$$

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 24/55

 The total volume flow rate follows from integration over the area:


$$d\dot{V} = u(r)dA = 2\pi u(r)rdr$$

$$\Rightarrow \dot{V} = \int d\dot{V} = \int 2\pi u(r) r dr$$

$$= 2\pi \int_{0}^{R} \left(\frac{1}{4\mu} \frac{p_{1} - p_{2}}{L} \right) (R^{2} - r^{2}) r dr$$

$$= 2\pi \frac{1}{4\mu} \left(\frac{p_{1} - p_{2}}{L} \right) \int_{0}^{R} (r \cdot R^{2} - r^{3}) dr$$

$$= \pi \frac{1}{2\mu} \left(\frac{p_{1} - p_{2}}{L} \right) \left[\frac{r^{2} \cdot R^{2}}{2} - \frac{r^{4}}{4} \right]_{0}^{R}$$



 $\Rightarrow \dot{V} = \frac{\pi}{8 \,\mu} \frac{p_1 - p_2}{L} R^4$

Hagen-Poiseuille equation

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 25/55

Average velocity over the cross sectional area:

$$\bar{u} = \frac{\dot{V}}{A_{pipe}} = \frac{\pi (\frac{p_1 - p_2}{L} \frac{1}{8\mu}) R^4}{\pi R^2} = (\frac{p_1 - p_2}{L} \frac{1}{8\mu}) R^2 = \frac{1}{2} u_{max}$$

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 26/55

Laminar Pipe Flow Pressure Losses and Friction Factor

- For pipe flow the pressure losses are important
 - How much pumping power is required?
- Radius of the pipe and volume flow are usually given.
- From Hagen-Poiseuille equation:

$$\dot{V} = \frac{\pi}{8\mu} \left(\frac{p_1 - p_2}{L} \right) R^4 \qquad \Delta p_L = p_1 - p_2 \qquad R = \frac{D}{2}$$

$$\Rightarrow \dot{V} = \pi \left(\frac{\Delta p_L}{128\mu L} \right) \cdot D^4$$

Pressure loss for pipe with diameter D:

$$\Delta p_L = \frac{\dot{V} \, 128 \, \mu \, L}{\pi \, D^4} = 32 \, \mu \, L \frac{\bar{u}}{D^2}$$
 $\dot{V} = \bar{u} \, A = \bar{u} \, \pi \, \frac{D^2}{4}$

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 27/55

Laminar Pipe Flow Pressure Losses and Friction Factor

- Helpful: Dimensionless Coefficients
 - allows for a comparison and analysis of different flow situations
- Division of the derived equation by kinetic energy density

$$\frac{\Delta p_L}{\frac{\rho}{2} \bar{u}^2} = \frac{64 \,\mu L}{D^2 \,\rho \,\bar{u}} = \frac{L}{D} 64 \,\frac{\mu}{\rho \,\bar{u} \,D} = \frac{L}{D} \frac{64}{\text{Re}}$$


 Thereby, we introduced the first dimensionless number:

$$Re = \frac{\rho \, \overline{u} \, D}{\mu}$$

$$= \frac{\overline{u} \, D}{2 \, \nu}$$
Reynolds number $v = \frac{\mu}{\rho}$ Kinematic viscosity

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 28/55

Typical Reynolds Numbers



Laminar Pipe Flow Pressure Losses and Friction Factor

 How to determine the pressure loss for a given Reynolds number?

$$\frac{\Delta p_L}{\frac{\rho}{2} \overline{u}^2} = \frac{L}{D} \frac{64}{\text{Re}} = \frac{L}{D} \lambda \qquad \lambda = \frac{64}{\text{Re}} \qquad \text{Re} = \frac{\rho \overline{u} D}{\mu}$$

- Pipe friction factor λ:
 - Dimensionless variable
 - Depends on the Reynolds number
 - 64/Re for laminar flow

Laminar Pipe Flow Pressure Losses and Friction Factor

 How to determine the pressure loss for a given Reynolds number?

$$\frac{\Delta p_L}{\frac{\rho}{2} \bar{u}^2} = \frac{L}{D} \frac{64}{Re} = \frac{L}{D} \lambda \qquad \lambda = \frac{64}{Re} \qquad Re = \frac{\rho \bar{u} D}{\mu}$$

How to use this?


$$\Delta p_L = \frac{L}{D} \frac{64}{\text{Re}} \frac{\rho}{2} \overline{u}^2 = \frac{L}{D} \lambda \frac{\rho}{2} \overline{u}^2 \qquad \lambda = \frac{64}{\text{Re}} \qquad \text{Re} = \frac{\rho \overline{u} D}{\mu} \lambda \frac{\rho}{2} \overline{u}^2$$

- We need length and diameter of the tube
- We need the density as well as the average velocity and the viscosity of the fluid
- With these numbers, we can calculate the fluid pressure loss in the tube

Entrance Length and Fully Developed Flow Profile

Example: Fluid flows from a water reservoir into a pipe

- Constant velocity profile at the beginning
- Wall friction affects the flow
- Result: a parabolic profile develops after a certain length



U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 33/55

Entrance Length and Fully Developed Flow Profile

 Depending on flow conditions, the flow profile is fully developed after a certain entrance length L_i. It can be roughly determined as:

$$L_i = 0.029 \dots 0.065 \cdot \text{Re} \cdot D$$

• The pressure losses are increased in the entrance length compared to fully developed flow. This effect is considered by an additional loss constant ζ_e =1.16...2.7

$$\frac{\Delta p_L}{\frac{\rho}{2}\bar{u}^2} = \frac{L}{D}\frac{64}{\text{Re}} = \frac{L}{D}\lambda + \zeta_e$$

• Note: For long pipes (large L), the first term dominates and $\zeta_{\rm e}$ can be neglected.

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 34/55


Turbulent Flow

- A distinction is made between laminar and turbulent flow.
- Laminar flows have "separated" flow layers.
- In turbulent flows, the layers mix strongly and the idea of flow layers is not valid any more.
- What does that mean?
- Let us compare laminar and turbulent pipe flow.


U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 35/55

Turbulent Pipe Flow

 Laminar flow (as until now)




 Turbulent flow with a lot of eddies (deutsch: Wirbel)




U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 36/55

Turbulent Pipe Flow


- Characterization of a pipe flow by the Reynolds number Re
 - Pipe diameter as characteristic length
- Re > 2300:
 - Significant change of pressure losses
 - The previous law (Hagen-Poiseuille) no longer applies
- Reason: Fluctuations of speed in radial and axial direction: many eddies



Laminar and Turbulent Flow



http://aerospaceengineeringblog.com/skin-friction-drag/



https://history.nasa.gov/SP-4103/app-f.htm

Turbulent Pipe Flow

- Turbulent flow description according to Reynolds
- Decomposition of the axial velocity u into
 - Average value $\bar{\iota}$
 - Fluctuating value u'

$$u(r,\phi,x,t)=\overline{u}(r)+u'(r,\phi,x,t)$$

 Fluctuation in radial direction is instantaneous fluctuation because there is no average flow in radial direction

$$v(r,\phi,x,t)=v'(r,\phi,x,t)$$

- Average values are often of interest
- Turbulence increases e.g. mixing and heat transfer


U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 40/55

For laminar flows we had found:

$$\Delta p_L = \lambda \frac{L}{D} \frac{\rho}{2} \bar{u}^2$$
 $\lambda = \frac{64}{Re}$ $Re = \frac{\rho \bar{u} D}{\mu}$

- Idea: The first formula with the relationship between λ and Δp should still apply
- How can λ be determined?
- Much more complex for turbulent pipe flow!
- At first we have to introduce the concept of wall roughness

Detailed microscopic view of a rough pipe surface:



- These "bumps" cause velocities in radial direction and disrupt the laminar axial flow
- If the axial velocity near the wall is high, the disturbances become so large that visible large-scale and many small-scale eddies occur

- ε is therefore an average height of the bumps
- ε=0 is also referred to as "hydraulically smooth"
 - e.g. for hydraulically smooth pipes, the friction factor can be calculated as:

$$\lambda = 0.316 \text{ Re}^{-1/4} \text{ für } 5*10^3 < \text{Re } < 10^5 \text{ .}$$


- However, in technical applications, the walls are usually not perfectly smooth
- The relative roughness of technical devices is defined as

$$k = \frac{\epsilon}{D}$$

- ε can be determined by experiments
- D is the pipe diameter

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 43/55

- Determination of λ using the Moody diagram
 - You need the Reynolds number of the flow
 - The roughness k of the pipe is required
 - either k is given directly
 - or you have ε and divide it by D
 - In the Moody diagram, find the curve with the appropriate value of k (y-axis on the right side of diagram)
 - Then find the appropriate Reynolds number on the x-axis
 - Find the point where Reynolds number and the kcurve meet
 - Read the friction factor λ on the y-axis on the left of the diagram



- Hints for using the Moody Diagram:
 - Friction Factor = Reibungskoeffizient
 - Relative Pipe Roughness = Relative Rauhigkeit
 - Smooth Pipe = hydraulisch glattes Rohr
 - The axes are <u>logarithmic</u>!
 This is especially important for the Reynolds number. If you make a mistake in Re, λ is usually completely wrong.

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 46/55

Turbulent Pipe Flow Pressure Losses and Coefficient of Friction

When you have determined λ with the Moody diagram, you use

$$\Delta p_L = \frac{L}{D} \lambda \frac{\rho}{2} \overline{u}^2$$

to calculate the pressure drop Δp .

Additional note:

Inlet length L_i for turbulent flows

$$L_i = 0.693 \, \text{Re}^{-\frac{1}{4}} \cdot D$$

Turbulent Pipe Flow Pressure Losses in non-circular tubes

- The following applies to non-circular pipes
 - Average velocity

$$\bar{u} = \frac{\dot{V}}{A}$$

- hydraulic diameter

$$D_h = \frac{4A}{S}$$

with A as the cross-sectional area and s as the circumference.

 This definitions can be used to determine the Reynolds number, the relative roughness and the pressures losses for non-circular pipes in a similar way as for circular pipes.

- Bernoulli's equation is expanded to include friction
- Friction causes...
 - Loss in kinetic energy
 - an increase in internal energy and temperature (negligible at moderate velocity)
- The Bernoulli equation is expanded by a loss term Δp_L

$$\frac{\rho}{2}v_1^2 + p_1 + \rho g z_1 = \frac{\rho}{2}v_2^2 + p_2 + \rho g z_2 + \Delta p_L$$

The pressure losses can be determined for example with a manometer

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 51/55

Alternative 1: Bernoulli equation...
 in the unit of height [m]


$$\frac{v_1^2}{2g} + \frac{p_1}{\rho g} + z_1 = \frac{v_2^2}{2g} + \frac{p_2}{\rho g} + z_2 + \Delta h_L \qquad \Delta h_L = \frac{\Delta p_L}{\rho g}$$

• Alternative 2: Bernoulli equation... in the unit of specific energy [m²/s²]

$$\frac{v_1^2}{2} + \frac{p_1}{\rho} + g z_1 = \frac{v_2^2}{2} + \frac{p_2}{\rho} + g z_2 + \Delta e_L \qquad \Delta e_L = \frac{\Delta p_L}{\rho}$$


- Δe_i are the energy losses

• Graphical representation of the height loss Δh_L of a viscous pipe flow:



U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 53/55

- Flow tube with energy levels in diagram below
- Energy is transformed from one type into another along the flow length
- Without friction: The total energy is constant (dashed line)
- With friction: The kinetic energy is reduced by the energy losses (reduced volume flow rate)
- Comparing inlet and outlet, the sum of kinetic, pressure and potential energy is no longer constant



U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 54/55

Energy Losses in Pipe Flows Additional Pressure Losses Due to Components

- Additional losses due to
 - Valves
 - Tube bends
 - Branches
 - any changes in flow direction
 - Changes in cross-sectional area
- Major reason for pressure losses: recirculation zones. Result: kinetic energy dissipates in heat
- Example: sudden change in the cross-sectional area of a pipe

Energy Losses in Pipe Flows Pressure Losses due to Sudden Pipe Expansion

- Pipe friction is neglected
- Losses due to re-circulation


 CV between point 1 and 2 (large Area)

- Continuity equation $v_1A_1=v_2A_2$
- Bernoulli equation

$$\Delta p_L = p_1 + \frac{\rho}{2} v_1^2 - (p_2 + \frac{\rho}{2} v_2^2)$$



$$\rho v_2^2 A_2 - \rho v_1^2 A_1 = (p_1 - p_2) A_2$$



Note: pressure p1 acts at position 1 over the entire cross section A2 on the CV in positive direction

Energy Losses in Pipe Flows Pressure Losses due to Sudden Pipe Expansion

For the pressure losses follows:

$$\begin{split} &\Delta \, p_L = p_1 + \frac{\rho}{2} \, v_1^2 - (\, p_2 + \frac{\rho}{2} \, v_2^2) \\ &= p_1 - p_2 + \frac{\rho}{2} \Big(\, v_1^2 - v_2^2 \Big) & | \text{Continuity equ.} \\ &= p_1 - p_2 + \frac{\rho}{2} \Bigg(\, v_1^2 - \left(\frac{A_1}{A_2} \right)^2 \, v_1^2 \Big) & | \text{Momentum equ.} \\ &= \rho \, v_2^2 - \rho \, v_1^2 \frac{A_1}{A_2} + \frac{\rho}{2} \, v_1^2 \Bigg(1 - \left(\frac{A_1}{A_2} \right)^2 \Bigg) & | \text{Continuity equ.} \\ &= \rho \, v_1^2 \Big(\frac{A_1}{A_2} \Big)^2 - \rho \, v_1^2 \frac{A_1}{A_2} + \frac{\rho}{2} \, v_1^2 \Bigg(1 - \left(\frac{A_1}{A_2} \right)^2 \Bigg) \end{split}$$

 $\Delta p_L = \frac{\rho}{2} v_1^2 \left(1 - \frac{A_1}{A_2} \right)^2$ Pressure losses due to a sudden expansion

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024

Energy Losses in Pipe Flows Additional Pressure Losses Due to Components

• General approach for components: Introduction of an additional pressure loss with the loss factor ζ from the data sheet for the component

$$\Delta p_L = \zeta \frac{\rho}{2} \overline{u}^2$$

For the sudden pipe expansion we derived


$$\zeta = \frac{\Delta p_L}{\frac{\rho}{2} v_1^2} = \left(1 - \frac{A_1}{A_2} \right)^2$$

- Important: For what speed range is the loss factor valid?
- Often: Loss factor is defined for velocity <u>before</u> the cross-sectional change
- Speed is the average velocity of the cross-sectional area

U.H. Becker, B. Schilder FRA-UAS: FID Summer Term 2024 58/55

Energy Losses in Pipe Flows Pressure Losses Due to an Aperture

- Opening of an aperture
 - Opening: cross-section A'
 - Smallest cross-sectional area of the flow: crosssection A₂



Energy Losses in Pipe Flows Pressure Losses Due to an Aperture

Contraction coefficient ψ

$$\Psi = \frac{A_2}{A'}$$

Analogous to the expansion example

$$\zeta = \frac{\Delta p_L}{\frac{\rho}{2} v_1^2} = \left(\frac{1 - \Psi}{\Psi}\right)^2$$

• ζ numbers for various flow devices can be found in tables or graphs in the literature