
### Drops of LTSpice




How to create subcircuits?

## Let's imagine that you created a very nice Schmitt Trigger circuit.



And you want to use it as a component.


### However, a bigger circuit like this can be complex to use or analyze.



Can we simplify?

#### Of course we can!


First, we need to define the Net Labels of the signals that will be exposed.




Save it as ASC file.

### Now, let's create a symbol.


## Use the Draw menu to add the lines to create your symbol.




## In the Edit you have the Add Pinmenu. You need respect the same Net Label that you define.




## Save the ASY file with the same name. Your component is done!




### Now you need add the path to the files in the Control Panel.



# Now, you can add your new component in the project. Notice that you need select the directory in the list.



### And look how simple is your simulation now!



Francesco Sacco linkedin.com/in/saccofrancesco