

WATERPROOF SYSTEM

PREPARATION



- Clean** & 100% dust-free: Remove all loose/flaking old paint, rust scale, heavy corrosion buildup, oils, and dirt from the surface. Ensure the substrate remains dry.

STEP 1

First Thin Coat



- Apply evenly** with a roller.
- Following** the principle of "thin and multiple layers", maximizes adhesion to substrate.

🕒 Recoat Time: 2 - 4 Hours.

STEP 2

Second Thin Coat



- Cover** the crack <2cm with polyester fabric.
- Use** repair mortar for crack >2cm.
- Apply evenly** with a roller.
- Coverage rate**: 0.5 KG/m² (2 coats)

🕒 Full Cure Time: 8 - 12 Hours .

CURING TIME



- 👉 Touch Dry: 4 Hours
- 🚶 Light Traffic: 24 Hours
- 🚗 Full Cure: 7 Days