## 5Fingered Hand Parts List

## Main Parts

	Parts	the num o	the num of parts	
	STL file	Ring	Index	
Index & Ring Fingers	RingServoConnector	1	0	1
	IndexServoConnector	0	1	1
	RingBase	1	0	1
	IndexBase	0	1	1
	IR_Link1	1	1	2
	IR_Link1Cover	1	1	2
	IR_Link2	1	1	2
	IR_Link2Cover	1	1	2
	IR_Link3	1	1	2
	STL file	Middle	Little	
	MiddleServoConnector	1	0	1
	LittleServoConnector	0	1	1
	MiddleBase	1	0	1
Middle&	LittleBase	0	1	1
Little Fingers		1	1	2
	ML_Link1Cover	1	1	2
	ML_Link2	1	1	2
	ML_Link2Cover	1	1	
	ML_Link3	1	1	2
Thumb	STL file	ļ	lack	
	Thumb_Base	1		1
	Thumb_Link1	1		1
	Thumb_Link1Cover	1		1
	Thumb_Link2	1		1
	Thumb_Palm	1	\	1
	Thumb_ServoConnector	1		1
Palm	STL file	ļ		
	Palm _	1		1
	Hand_Back	1		1
	Stand	1		1
	StandFixation	1	<b>\</b>	1
				38

## Gears

STL file	meaning	Thumb	Index	Middle	Ring	Little	Amount
25Servo	25mm for servo	2	1	1	1	1	6
20A_Tip	20mm AGT at tip	1	1	1	1	1	5
12A	12mm AGT	1	1	1	1	1	5
20A	20mm AGT	1	2	2	2	2	9
14A	14mm AGT	1	3	3	3	3	13
12P1_Tip	12mm	1	1	1	1	1	5
12P1_J2	12mm PGT1 at joint 2	0	1	1	1	1	4
14P2_J1	14mm PGT2 at joint 1	0	1	1	1	1	4
14P2_J2	14mm PGT2 at joint 2	0	1	1	1	1	4
10P	10mm PGT	2	4	4	4	4	18
12P_Square	12mm PGT with square hole	1	0	0	0	0	1

AGT: Active gear train PGT: passive gear train

PGT1: passive gear train for PIP and DIP joints PGT2: passive gear train for PIP and MP joints

## Fixation

TIAUCIOII						
STL file	Thumb	Index	Middle	Ring	Little	Amount
clip	3	2	2	2	2	11
stick	3	2	2	2	2	11
fix	1	1	1	1	1	5

27