Preflight (Interior)

Turn Coordinator CHECK

	before takeon (Kun-up)	
Weather	CAPS Pin REMOVED	Lights as rqd.
Weight & Balance VERIFY OK	Flight Controls FREE & CORRECT	Fuel PumpOFF
Fire Extinguisher & Hammer ON BOARD	TrimSET TAKEOFF	Power
TODO	Altimeter SET	MixtureLEAN as rgd.
1000	Flight Instruments	Best Power: 75°F rich of peak EGT, power < 75%
Defere Charting Frains	Flaps	Best Economy: 50°F lean of peak EGT power < 65%
Before Starting Engine		Engine Parameters CHECK GREEN
Preflight Inspection COMPLETED	TransponderSET	Fuel Selector SWITCH as rqd.
Passengers BRIEF	Autopilot	
Seat Belts, A/C, Fire, Exit, Traffic/Talking, CAPS	Navigation & GPSSET	
Seat Belts ADJUST & SECURE	Fuel Quantity CONFIRM	Cruise Power Settings
CAPS PinREMOVE	Fuel Selector SWITCH TANK	TODO
	Fuel PumpB00ST	
Starting Engine	Doors	B
	Mixture FULL RICH or as rqd.	Descent
Brakes HOLD	BrakesHOLD	Altimeter SET
Ignition Key INSERTED	Power Lever	Lights
Battery Masters 2 & 1 ON, CHECK 24V	Pitot Heat & Lights ON	Fuel SelectorFULLEST TANK
Strobe LightsON	Annunciators CHECK CLEAR	Mixture RICHEN as rgd.
Propeller Area CLEAR	Alternator Load CHECK BOTH > 0	Brake Pressure CHECK
Oil Temperature CHECK	Alternator Voltage CHECK 28V	
NORMAL START	Pitot Heat & Lightsas rqd.	
MixtureFULL RICH	Magnetos CHECK L & R	Before Landing
Power LeverFULL FORWARD	Check RPM drop < 150, RPM differential < 75	Occas Balta
Fuel Pump PRIME, then BOOST	Engine Parameters CHECK GREEN	Seat BeltsSECURE
Prime for 5 secs until fuel flow reaches 15 gph	Power Lever	Fuel Pump BOOST
Power Lever OPEN ¼ INCH	MixtureLEAN as rgd.	MixtureFULL RICH or as rqd.
Ignition SwitchSTART	Flight Plan OPEN	Flaps DEPLOY
Power Lever	Takeoff & Abort Plan BRIEF	Approach (Flaps UP) 100 KIAS
HOT START IF OIL TEMP > 160°F	Takeoff Clearance (Radio 1) OBTAIN	Approach (Flaps 50%) 90 KIAS
TODO	()	Approach (Flaps 100%) 80 KIAS
TODO TODO	Maximum Power GPH (Pressure Altitudes)	Short Field (Flaps 100%) 77 KIAS
TODO TODO	27.1 (SL) 26.2 (1,000) 25.1 (2,000) 24.3 (3,000)	
FLOODED START	23.6 (4,000) 22.8 (5,000) 22.1 (6,000) 21.4 (7,000)	0. 4
Fuel PumpOFF	20.5 (8,000') 19.9 (9,000') 19.5 (10,000')	Go-Around
		Autopilot
Mixture LEAN	Takeoff	Autopilot
Mixture LEAN Power Lever FULL FORWARD	Takeoff	
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START	Takeoff Fuel Pump	Power LeverFULL FORWARD
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd.	Power LeverFULL FORWARD Flaps50%
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH	Takeoff Fuel Pump	Power Lever FULL FORWARD Flaps 50% Airspeed 75-80 KIAS
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET	Power Lever FULL FORWARD Flaps 50% Airspeed 75-80 KIAS Flaps UP
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE	Power Lever FULL FORWARD Flaps 50% Airspeed 75-80 KIAS
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD	Power Lever FULL FORWARD Flaps 50% Airspeed 75-80 KIAS Flaps UP After Landing
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM	Power Lever FULL FORWARD Flaps 50% Airspeed 75-80 KIAS Flaps UP After Landing Power Lever 1000 RPM
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN	Power Lever FULL FORWARD Flaps 50% Airspeed 75–80 KIAS Flaps UP After Landing Power Lever 1000 RPM Fuel Pump OFF
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70–73 KIAS)	Power Lever FULL FORWARD Flaps .50% Airspeed .75-80 KIAS Flaps .UP After Landing Power Lever Fuel Pump OFF Flaps UP
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70-73 KIAS) At 500 ft, CAPS CALLOUT "Available"	Power Lever FULL FORWARD Flaps .50% Airspeed .75-80 KIAS Flaps .UP After Landing Power Lever 1000 RPM Fuel Pump OFF Flaps UP Lights as rqd.
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GEEN Elevator ROTATE (70–73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP	Power Lever FULL FORWARD Flaps .50% Airspeed .75-80 KIAS Flaps .UP After Landing Power Lever Fuel Pump OFF Flaps UP
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70–73 KIAS) At 500 ft, CAPS CALOUT "Available" At 80 kts, Flaps UP Best Angle V _X 78 (st) 82 (10,000)	Power Lever FULL FORWARD Flaps .50% Airspeed .75-80 KIAS Flaps .UP After Landing Power Lever 1000 RPM Fuel Pump OFF Flaps UP Lights as rqd.
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN Taxi Clearance (Radio 2) OBTAIN	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GEEN Elevator ROTATE (70–73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP	Power Lever FULL FORWARD Flaps .50% Airspeed .75-80 KIAS Flaps .UP After Landing Power Lever .1000 RPM Fuel Pump .OFF Flaps .UP Lights .as rqd. Pitot Heat .OFF
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN Taxi Clearance (Radio 2) OBTAIN Altimeter SET	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70-73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP Best Angle V _X 78 (st.) 82 (10,000) Best Rate V _Y 101 (st.) 95 (10,000)	Power Lever
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN Taxi Clearance (Radio 2) OBTAIN Altimeter SET Flaps UP	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70-73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP Best Angle Vx 78 (st) 82 (10,000) Best Rate Vy 101 (st) 95 (10,000)	Power Lever
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN Taxi Clearance (Radio 2) OBTAIN Altimeter SET Flaps UP Mixture LEAN as rqd.	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70-73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP Best Angle V _X 78 (st.) 82 (10,000) Best Rate V _Y 101 (st.) 95 (10,000) Climb Power TODO set to what?	Power Lever
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN Taxi Clearance (Radio 2) OBTAIN Altimeter SET Flaps UP Mixture LEAN as rqd.	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70-73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP Best Angle Vx 78 (st.) 82 (10,000) Best Rate Vy 101 (st.) 95 (10,000) Climb Power TODO set to what? Mixture TODO when to lean?	Power Lever
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN Taxi Clearance (Radio 2) OBTAIN Altimeter SET Flaps UP Mixture LEAN as rqd. Taxiing Brakes CHECK	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70-73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP Best Angle V _X 78 (st) 82 (10,000) Best Rate V _Y 101 (st) 95 (10,000) Climb Power TODO set to what? Mixture TODO when to lean? Engine Parameters CHECK GREEN	Power Lever
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN Taxi Clearance (Radio 2) OBTAIN Altimeter SET Flaps UP Mixture LEAN as rqd. Taxiing Brakes CHECK HSI Orientation CHECK HSI Orientation CHECK	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70–73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP Best Angle V _X 78 (st.) 82 (10,000) Best Rate V _Y 101 (st.) 95 (10,000) Climb Power TODO set to what? Mixture TODO when to lean? Engine Parameters CHECK GREEN Fuel Pump BOOST	Power Lever
Mixture LEAN Power Lever FULL FORWARD Ignition Switch START Power Lever RETARD Mixture SLOWLY ADVANCE TO RICH AFTER ENGINE START Alternator Masters 1 & 2 ON Avionics Master ON Engine Parameters CHECK GREEN Before Taxiing Weather Information OBTAIN Taxi Clearance (Radio 2) OBTAIN Altimeter SET Flaps UP Mixture LEAN as rqd. Taxiing Brakes CHECK	Takeoff Fuel Pump BOOST Mixture FULL RICH or as rqd. Transponder SET Lights ON Brakes RELEASE Power Lever FULL FORWARD Propeller CHECK 2700 RPM Engine Parameters CHECK GREEN Elevator ROTATE (70-73 KIAS) At 500 ft, CAPS CALLOUT "Available" At 80 kts, Flaps UP Best Angle V _X 78 (st) 82 (10,000) Best Rate V _Y 101 (st) 95 (10,000) Climb Power TODO set to what? Mixture TODO when to lean? Engine Parameters CHECK GREEN	Power Lever

Enroute Climb 110-120 KIAS

ELT NOT TRANSMITTING

Before Takeoff (Run-up)

Cruise