

SŒÓVPH€ÚŒ Œ

USER MANUAL

Box Contains:

Music Receiver x 1 pc

Thank you for the purchasing our 30 pin bluetooth adapter! Please read this manual carefully to get details on how to operate the device correctly. Please keep a copy of this manual safe for future reference!

Notes

- 1. Keep unit away from high temperatures and damp environments; place it in ventilated and dry environments. Exposure to rain and severe shock is forbidden!
- 2. Do not open the cover to avoid electrical shock or any other accidents. For repairs, ask for advice from the Kogan Customer Support team.
- 3. Pull it out of the dock when you are not planning to use it.

Operation Steps

- 1. Bluetooth music receiver connects directly to iPod/iPhone4 speaker 30-pin dock, and then the red LED lamp and the blue LED lamp will flicker alternately until they enter pairing mode, which means the device starts to work normally.
- 2. After it enters pairing mode, enable the Bluetooth function for the devices such as iPad, iPhone, Bluetooth PC, cell phone and any other digital products with Bluetooth function. Search Bluetooth devices or new devices to find I-LINK and connect it. Password input for pairing is needed, the default password is: **0000**.
- 3. After successful pairing, the red LED lamp will turn off and the blue LED lamp will flicker slowly, which means the Bluetooth has been connected correctly. Then you can play music wirelessly.
- 4. To change the play device during normal operation, disconnect the connected Bluetooth PC /tablet/smartphone, and then perform the pairing connection again for other Bluetooth devices.

Technical Spec

Complies with Bluetooth 2.1 Support A2DP V1.2 Powered by 30pin Dock Transmission Distance: up to 10 meters