Self Standing Mask drying or bracelet holding rack

- 1. Sand any rough edges using the sandpaper.
- 2. Set the board on a flat surface like a table.
- 3. Gently twist and push the thinner dowel through the board.
- 4. Feel underneath to make sure the end of the dowel and the board are flush (at the same level).
- 5. Gently twist the larger dowel onto the thinner dowel until it too is flush with the top of the thinner dowel.

If your rack is slipping, you can use a small amount of glue to connect any of the pieces.

For more woodworking projects at all levels of difficulty, please visit www.maplewoodshop.com.