

SOP: InfoMag

March 26, 2026

Contents

1	Introduction	1
2	The processing pipeline	2
2.1	Data import	2
2.1.1	Marine Magnetics SeaLink import	2
2.1.2	Marine Magnetics Bob import	4
2.1.3	Custom CSV import	4
2.2	Time series processing	5
2.3	Anomaly grid processing	7
2.4	Export	10
2.5	Project	10
2.5.1	Saving a project	10
2.5.2	Loading a project	10
3	Experimental: Downward continuation	11
3.1	Bathymetry import	11

1 Introduction

InfoMag is a user interface around the a magnetometry data processing pipeline (see 1) targeted at INFOMAR’s unprocessed data. The software can either be started by cloning the repository, installing the needed packages through the provided `requirements.txt`, compiling the cython module using the provided `setup.py` and running `main_window.py` or using the bundled executable provided for windows¹. After startup the main-window will be displayed. This window is composed of three visualisation windows, a file tree, and configuration settings that support the user during the processing.

This guide assumes that you have downloaded the data snippet² containing the surveys CV_16_01, CV_16_02 and CV_16_04. This test data will be used to guide through an example walk-through through the pipeline 1.

¹Opening the executable might take some time since it needs to expand itself into a temporary folder.

²Insert url if we get permission to upload




Figure 1: The software implements a processing pipeline that reads INFOMAR’s magnetometry data, processes, visualizes it and eventually exports the result. An additional branch provides an opportunity to import bathymetry data to interpolate the downward field at the provided altitudes.

2 The processing pipeline

The processing pipeline (see Fig. 1) consists of four key steps which is importing data, processing, gridding and eventually exporting the result. An experimental branch of downward continuing the estimated grid will be discussed in section 3.

2.1 Data import

Data can be imported through a file dialogue that could be opened within the drop-down menu *File*. The software is targeted at INFOMAR’s magnetometry data acquired through Marine Magnetics SeaLink and Bob software. Therefore, we provide two custom imports that directly can process a majority of raw files created by either software. For details on assumptions of the raw files we refer to section 2.1.1 and 2.1.2. The imported surveys appear in a tree structure on the left-hand side of the main window (see 3).

Remark. We note that the import of large `*.txt` or many `*.XYZ` files might take some time. Upon completion the imported surveys will appear in the file tree.

Walkthrough 2.1. The surveys `CV16_02_23042016.txt` and `CV16_04_06082016.txt` have already been recorded using Marine Magnetics Bob software while `CV_16_01` was still recorded using SeaLink. Accordingly, both `CV16_02_23042016.txt` and `CV16_04_06082016.txt` are present as single file, while `CV_16_01` is a folder containing a nested `raw` folder with the individual lines.

2.1.1 Marine Magnetics SeaLink import

Surveys acquired using the Sealink acquisition software will be present as a folder named `CV_YY_NN`, where `YY` denotes the year of the survey and `NN` the number of the survey. The folder `CV_YY_NN` itself should contain a folder called `raw`. Inside the `raw`-folder are several files sharing the same filename but differ in their ending such as `*.txt`, `*.mag`, `*.XYZ`. The software is looking for files ending with `*.XYZ`.

To deal with the huge heterogeneity among SeaLink files the software assume a minimal standard of the imported files which will be outlined in the following. This has to be ensured by the user or the custom `csv-import` (see 2.1.3) might be tried.




Figure 2: Raw files can be imported through a file dialogue that will be triggered by the drop-down menu *File*.




Figure 3: The imported surveys appear in a tree structure on the left-hand side of the main window. The files contained in a SeaLink folder will appear under the node of its corresponding survey CV_YY_NN. Similar for surveys acquired with the Bob software will also appear as a single file within the corresponding node CV_YY_NN.

Currently, the software has two assumptions on the *.XYZ files. First, a homogeneous number of columns within each file is expected since at the moment the software is not able to process files whose number of columns changes mid-file.

Second, the software assume the existence of the following columns names: /Date,Time,Field_Mag1,Longitude,Latitude. First, we note that due to Sealinks exported file structure the name has to be without /Date without a space. Moreover, / with a space is used to filter for mid-file headers, i.e. all lines starting with / will be ignored. Second, we note that the Software will probe for UTM_Easting,UTM_Northing. If these columns are not present in the raw file they will be estimated form Longitude,Latitude. An example how a *.XYZ files is suppose to be formatted is given in listing 1.

If both requirement are meet, the user can open a file dialogue through the dropdown menu **File** (see Fig. 2). Within the spawned file dialogue the user can select either directly the desired survey folder CV_YY_NN or its contained raw folder and all files matching the requirements above will be imported.

```

/ -----
/ Marine Magnetics Corp. SeaLINK Magnetometer Data Log [ 2016/03/22,15:21:38.7 ]
/ Filename -- [ C:\Survey_Legs\CV16_01\1_000.XYZ ]
/ -----
/
/Date,Time,Field_Mag1,Alt_Mag1,Depth_Mag1,Longitude,Latitude,UTM_Easting,UTM_Northing,UTM_Zone
2016/03/22,15:21:38.7,48487.410,41.25m,5.8m,-8.238920,51.564855,552753.2,5712916.4,29U
2016/03/22,15:21:42.5,48533.000,38.56m,0.0m,-8.238836,51.564927,552759.0,5712924.5,29U
2016/03/22,15:21:43.0,48544.176,40.53m,2.0m,-8.238820,51.564934,552760.1,5712925.3,29U
2016/03/22,15:21:43.5,48549.195,38.57m,3.6m,-8.238807,51.564939,552761.0,5712925.8,29U

```

Listing 1: Preview of a raw SeaLink CSV file.

2.1.2 Marine Magnetics Bob import

Surveys acquired using the Bob acquisition software will be present as a single file named CV_YY_NN_*.txt, where YY denotes the year of the survey and NN the number of the survey and * denotes an arbitrary number unique for the survey.

Currently, the software has two assumptions on the CV_YY_NN_*.txt files. First, a homogeneous number of columns within each file is expected since at the moment the software is not able to process files whose number of columns changes mid-file.

Second, the software assume the existence of the following columns names: Reading_Date,Reading_Time,Magnetic_Field,Longitude,Latitude,UTM_Easting,UTM_Northing. An example how a *.XYZ files is suppose to be formatted is given in listing 2.

2.1.3 Custom CSV import

The software also support processing custom, meaning files different formatted than Marine Magnetics Bob or SeaLink *.csv files. However, there are a couple assumptions on the *.csv which has to be ensured by the user.

- The file has to contain in every row the same amount of columns.
- Special characters encoding a missing value or any other surprising event have to be replace with an empty string, i.e. an empty field.

```

/-----
/Marine Magnetics Corp. Magnetometer Data Log [04/23/2016 01:28:16]
/Filename -- [Z:\SURVEY_LEGS\2016\CV16_02\Geophysical\Magnetometer\Raw\CV16_02_23042016.txt]
/Datum -- [WGS-84]
/-----
Reading_Date,Reading_Time,Magnetic_Field,Signal_Quality,Depth,Altitude,Leak,Measurement_Time
,Signal_Strength,Gradient_Condition,Weak_Signal,Poor_Reading,Instrument_Mistuned,
Reading_ID,System_Time,Line_Name,Mag_Latitude,Mag_Longitude,Mag_Easting,Mag_Northing,
Mag_Zone,GPS_Latitude,GPS_Longitude,GPS_Easting,GPS_Northing,GPS_Zone,Marker,Marker_Time
16-Apr-2016,17:15:13.500,48640.927,99,8.0,34.6,0,465,201," "," "," ",2,16-Apr-2016
17:15:14.200,*,51.40192102,-8.67865835,522353.02,5694570.56,29N
,51.40192102,-8.67865835,522353.02,5694570.56,29N,"",*
16-Apr-2016,17:15:14.000,48640.847,99,7.6,36.1,0,465,197," "," "," ",3,16-Apr-2016
17:15:14.710,*,51.40192102,-8.67865835,522353.02,5694570.56,29N
,51.40192102,-8.67865835,522353.02,5694570.56,29N,"",*
16-Apr-2016,17:15:14.500,48640.546,99,8.0,33.9,0,465,192," "," "," ",4,16-Apr-2016
17:15:15.213,*,51.40192102,-8.67865835,522353.02,5694570.56,29N
,51.40192102,-8.67865835,522353.02,5694570.56,29N,"",*
16-Apr-2016,17:15:15.000,48639.929,99,8.0,33.9,0,465,190," "," "," ",5,16-Apr-2016
17:15:15.757,*,51.40192102,-8.67865835,522353.02,5694570.56,29N
,51.40192102,-8.67865835,522353.02,5694570.56,29N,"",*
16-Apr-2016,17:15:15.500,48639.620,99,7.6,36.1,0,465,190," "," "," ",6,16-Apr-2016
17:15:16.320,*,51.40192102,-8.67865835,522353.02,5694570.56,29N
,51.40192102,-8.67865835,522353.02,5694570.56,29N,"",*

```

Listing 2: Preview of a raw Bob CSV file.

- The file has to contain a header naming the columns.

A dialog, which can be spawn upon clicking on “From custom csv” in the drop-down menu (see Fig. 3), will ask for the file that is to be imported and which columns to use for what purpose.


2.2 Time series processing

Next, we recommend inspecting the time-series through the “timeseries”-window, which can be opened through the dropdown menu *view*. The “timeseries”-window facilitates two key tasks: displaying the time-series and manipulating it. The time series itself can be displayed by clicking on . This also replicates the time-series on the main window and vice versa if  is clicked on the main window. Moreover, this operation internally smooths the time series and calculates the residuals as the difference between the ambient field, estimated as a slow running mean, and the current field, estimated as a fast running mean. The used window size of both means is preset upon preliminary work. However, it can be adjusted through the text fields on the right-hand sight of either the main window or the times series window.

Remark. We note that this approach assumes a constant ambient field for the duration of the window [1]. A diurnal correction using data from the Valencia observatory³ might be included in the future.

Inside the plot, the time series could be investigated using zooming and panning. The unprocessed time-series data might show huge negative spikes as depicted in Fig. 5. This is due to the fact that some raw data values are approaching 0[nT], probably during recovering the magnetometer. The scissor tool  is designed to remove these intervals from the time-series. The tool can be activated by clicking on the corresponding icon. This allows the user

³<https://data.magie.ie/>



A screenshot of a software dialog box titled "Custom CSV import". The dialog has a standard window header with minimize, maximize, and close buttons. The main content area contains the following elements: a "File:" label followed by a "Select" button and an empty text input field; a prompt "Please provide the corresponding column names:"; a series of labels followed by empty text input fields: "Reading time:", "Reading day:", "Magnetic field:", "GPS Latitude:", "GPS Longitude:", "GPS Eastings:", "GPS Northings:", "Skip rows:", and "Delimiter:". A "Submit" button is located at the bottom right of the dialog.

Figure 4: The dialog provides an interface to the user where he can denote which names column corresponds to entity, e.g. time, longitude, etc.




Figure 5: The imported raw times series might contain values approaching 0[nT], perturbing the calculated residuals. The ✂ allows to remove an interval of undesired data points, configured as red rectangle.

to select a red rectangle by moving its edges, defining the interval that is to be excluded (see Fig.6). The rectangle can be adjusted until the selection is confirmed by clicking the scissor icon again and a final dialogue will confirm the decision. We note that at the moment the visualisation will not refresh itself automatically. This can be achieved by clicking again on .

2.3 Anomaly grid processing

The next step is the creation of the anomaly map. This can be achieved upon selecting . The initial result will look similar to Fig. 7.

Remark. We note that the gridding step might take some time in particular if a high resolution is required.

Generally, the visualization can be interacted with using panning and zooming. Additionally on the right-hand side of the main window, various layers such as the background map or the track lines can be enabled or disabled via the checkboxes and the scale of the anomaly can be adjusted between to be either linear and logarithmic.

This is due to the fact that at the moment the software interpolates the anomaly grid within the convex hull of the given data points. Outliers, such as the single point located near the coast will cause undesired artifacts as shown in Fig. 7. Those can be removed using the the scissor tool ✂. Upon, activation the user can lasso-select an arbitrary set of points which will be removed. The lasso is controlled by the user drawing a free-hand curve through left-clicking desired points on the map and subsequent closed upon deselecting ✂ again. Similar to cleaning time series, the selection can be confirmed or discarded in a final dialogue. This process is illustrated in Fig. 8. For a more fine selection, a polynomial select tool  is provided.




Figure 6: A cleaned time-series using the $\propto$ tool as depicted in Fig. 5.




Figure 7: Gridding the processed time-series of CV_16_01, CV_16_02 and CV_16_04 will interpolate an anomaly map within the convex hull of the remaining data points. Outliers might cause artifacts as depicted.




Figure 8: A free-hand curves (red dashed line) allows selecting undesired data points to be removed.




Figure 9:  allows to clip a desired region using a polygon. The clipped region will be used for further processing and export.




Figure 10: A zoomed view on the clipped region using the $\square$ as indicated in Fig. 9.

2.4 Export

Finally, the processed anomaly grid can be exported over the drop-down menu *file* and then selecting either a text-based **.csv* or a **.tiff* based export. The latter one exports a geotiff which could be imported into any GIS software and further processes.

2.5 Project

2.5.1 Saving a project

To save the current project, select *Save Project* within the drop-down menu *File* (see Fig.??). This will open a file dialogue. Within the file dialogue navigate to the desired location. The location should be an empty folder which could be arbitrary named. Within this folder the following will be created:

- A *project_name.json* file containing the project structure and meta information.
- A folder for each survey containing all associated survey frames as parquet.

2.5.2 Loading a project

To load a project, select *Load Project* within the drop-down menu *File* (see Fig.??). This will open a file dialogue. Within the file dialogue navigate to the folder where the desired project was stored and select the corresponding **.json* file.

3 Experimental: Downward continuation

3.1 Bathymetry import

Remark. This section will be added once it is implemented in its finalized form.

References

- [1] Frank Bastian, Mohit Tunwal, and Aaron Lim. *InfoMag: A graphical user interface for INFOMAR's magnetometry data*. 2026.