Congratulations on your purchase of the Remington Vacuum Beard and Stubble Trimmer MB6850. This product is specifically designed to help you achieve the perfect beard and stubble look with ease. This user guide provides complete information on the features of the product, technical specifications, usage and maintenance instructions, and other relevant details that will help you make the most of your purchase.

Features:

The Remington Vacuum Beard and Stubble Trimmer MB6850 is equipped with the following features:

- Vacuum System: Captures up to 95% of the trimmed hair, providing a clean and mess-free trimming experience.
- 2. Adjustable Length Settings: Choose from 9 length settings (1.5-18mm) for the perfect beard and stubble look.
- 3. Lithium Battery: Provides up to 90 minutes of cordless run time on a single charge.
- Self-Sharpening Blades: Provides long-lasting performance, ensuring precision trimming every time.
- 5. Washable Design: The trimmer is washable for easy cleaning.



DALL-E generated image

Technical Specifications:

Product Dimensions: 7.2 x 3.5 x 9.2 inches

Item Weight: 1.2 pounds
Manufacturer: Remington
Battery: Lithium-ion
Run Time: Up to 90 minutes
Charge Time: 4 hours

Charge Time: 4 hoursBlade Material: Titanium-coatedVoltage: 100-240V

Usage Instructions:

- 1. Before using the trimmer, ensure that the battery is fully charged.
- 2. Choose the desired length setting using the adjustable length settings.
- 3. Turn on the trimmer and start trimming your beard or stubble.
- 4. Use the vacuum system for a clean and mess-free trimming experience.
- After use, clean the trimmer by removing the blade and rinsing it under running water.



MidJourney generated image

Maintenance Instructions:

- 1. Always keep the trimmer clean and free from hair clippings.
- 2. After every use, remove the blade and clean it under running water.
- 3. Do not immerse the trimmer in water.
- 4. Use the cleaning brush provided to remove any hair clippings from the trimmer.
- 5. Store the trimmer in a cool and dry place.



Actual Image of the product

FAQs:

Q. Can I use the trimmer while it is charging?

A. No, the trimmer cannot be used while it is charging.

O. Can I replace the blades of the trimmer?

A. Yes, the blades can be replaced. Contact Remington customer support for assistance.

Q. How often should I charge the trimmer?

A. The trimmer should be charged after every use for optimal performance.

Tips for Optimal Use:

- Use the trimmer on clean and dry hair for best results.
- Use the vacuum system for mess-free trimming.
- For a closer trim, use a higher length setting.
- To ensure long-lasting performance, clean the trimmer after every use and store it in a cool and dry place.

Creative Uses:

- The trimmer can be used to trim hair on other parts of the , such as the chest and back.
- Use the trimmer to create unique beard and stubble styles.
- The vacuum system can also be used to clean up hair clippings from other surfaces, such as the bathroom sink.

We hope that this user guide has provided you with all the necessary information to make the most of your Remington Vacuum Beard and Stubble Trimmer MB6850. If you have any further questions or concerns, please do not hesitate to contact Remington customer support for assistance.

TROUBLESHOOTING:

Problem 1: The trimmer doesn't turn on.

Solution: Check to make sure the trimmer is properly charged. If it is, try resetting the trimmer by holding down the power button for 10 seconds.

Problem 2: The trimmer is not cutting evenly.

Solution: Make sure the blades are clean and properly lubricated. Also, consider using a comb attachment to help guide the trimmer for a more even cut

Problem 3: The trimmer is pulling hair instead of cutting it.

Solution: Try adjusting the trimmer's length settings and using a shorter length setting. Also, make sure the blades are clean and properly lubricated.

Problem 4: The trimmer makes a loud noise when being used.

Solution: Make sure the blades are properly placed in the trimmer and are not loose or damaged. Also, try lubricating the blades to reduce friction.

Problem 5: The trimmer's battery life is shorter than expected.

Solution: Check for any excessive battery drain, such as leaving the trimmer plugged in for too long. Also, make sure the trimmer is fully charged before each use and consider replacing the battery if necessary.

Thank you for choosing the Remington Vacuum Beard and Stubble Trimmer MB6850. We hope these troubleshooting tips have been helpful in resolving any issues with your product. If you continue to experience problems, please contact our customer support team for further assistance.