# User Guide for The Smart Oven™ Pizzaiolo

Congratulations on purchasing The Smart Oven™ Pizzaiolo! We hope you enjoy using it to create delicious, restaurant-quality pizza at home. This user guide contains all the information you need to get started, including product features, technical specifications, instructions for use and maintenance, and tips for getting the most out of your oven.

#### **Product Features:**

 The Smart Oven™ Pizzaiolo is equipped with various settings that allow you to customize your pizza cooking experience. These settings include:

Pizza Type: Choose from Neapolitan, New York, or Thin & Crispy pizza settings to achieve the perfect cook on your pizza.

Crust Type: Select from a range of crust options, including Classic, Thick, Thin, and Wood Fired, to achieve your desired crust texture and flavor.

Temperature: Adjust the temperature of the oven to suit your cooking preferences.

- The oven features a double ceramic deck that is designed to replicate the high heat environment of a wood-fired oven, ensuring that your pizzas are cooked to perfection every time.
- The oven also includes a built-in temperature gauge and an autoeject tray for easy removal of pizzas once they are done.



Power: 1800 wattsVoltage: 120 volts

• Dimensions: 18.5 x 18.5 x 10.7 inches

• Weight: 47.4 pounds

## **Instructions for Use:**

#### **BEFORE FIRST USE:**

- 1. Run the oven empty at maximum temperature for 30 minutes to burn off any manufacturing residue.
- 2. Clean the oven thoroughly with a damp cloth and mild detergent.
- 3. Rinse and dry the oven.

#### **COOKING PIZZA:**

- 1. Preheat the oven to the desired temperature.
- 2. Place your pizza on the auto-eject tray and slide it into the oven.
- 3. Use the Pizza Type, Crust Type, and Temperature settings to customize your cook.
- 4. Remove the pizza once it is done, using oven mitts or gloves.



DALL-E generated image



MidJourney generated image



Actual Image of the product

## **Maintenance:**

- Clean the oven after each use using a damp cloth and mild detergent.
- Do not use abrasive cleaners or scrubbers on the oven, as this may damage the surfaces.
- The oven should be descaled regularly to prevent mineral buildup. Follow the manufacturer's instructions for descaling.

# FAQs:

- Q: Can I cook other things besides pizza in The Smart Oven™ Pizzaiolo?

  A: While the oven is designed primarily for pizza, you can also use it to cook other foods, such as flatbreads and calzones.
- Q: How do I know when my pizza is done?

A: Use the built-in temperature gauge to monitor the temperature of the pizza as it cooks. The pizza is done when the crust is crispy and golden brown and the cheese is melted and bubbly.

Q: What kind of power source does the oven require?

A: The oven runs on standard 120-volt household power.

# **Tips for Getting the Most Out of Your Oven:**

- Experiment with different pizza types and crusts to find your perfect combination.
- Preheat the oven thoroughly before cooking to ensure a crispy crust.
- Use high-quality ingredients to achieve the best flavor in your pizza.
- Clean the oven regularly to prevent buildup of food residue.

We hope you enjoy using The Smart Oven™ Pizzaiolo to create delicious, homemade pizza. If you have any further questions or concerns, please consult the manufacturer's website or customer service team.

### TROUBLESHOOTING:

1. **Issue:** The pizza is not cooking evenly.

**Solution:** Ensure that the pizza is placed on the center of the pizza stone, and rotate it halfway through the cooking time. Use a pizza peel to slide the pizza in and out of the oven to prevent burning your hands.

2. **Issue:** The oven is not heating up.

**Solution:** Check that the oven is plugged in and that the power outlet is working. If the oven is still not heating up, check the power cord for any damage.

3. **Issue:** The pizza stone is cracked.

**Solution:** Allow the pizza stone to cool completely, and then remove it from the oven. Use a soft-bristled brush to clean off any debris, and inspect the stone for cracks. If it is cracked, contact customer service for a replacement.

4. **Issue:** The oven is producing excessive smoke.

**Solution:** Ensure that the pizza oven is on a level, stable surface. Make sure that the pizza is not being overloaded with toppings, and that the oven has been properly cleaned after previous use.

5. **Issue:** The pizza dough is not rising properly.

**Solution:** Check that the yeast is not expired, and that the dough has been given enough time to rise. Ensure that the dough has been kneaded properly and has not been overworked.

Thank you for choosing The Smart Oven™ Pizzaiolo. Enjoy your delicious homemade pizzas!