

C35


TPS-Sensor-GND D


8V/0.5A Polyfuse CPU Pin 71


C37


0.22uF


◆ TPS-CPU-Signa














D47 and D48 are only populated if you are using an external MAP sensor. Do not populate these locations if you are using the on-board sensor.

Do not populate C23 and C21 if you are using an external MAP sensor.


Change R13 value from 1k to 470 ohm if you are using an external MAP sensor.


Git: f0f0026dbb
File: inputs.sch
Sheet: /inputs/


Title: Jaguar PCB for FreeEMS
Size: A4 Date: 24 apr 2014


 Size: A4
 Date: 24 apr 2014
 Rev: 0.7-alpha

 KiCad E.D.A. eeschema (2013-07-07 BZR 4022)-stable
 Id: 4/7









GIT: TUTUU26dbb			
File: Outputs.sch			
Sheet: /Outputs/			
Title: Jaguar PCB for FreeEMS			
Size: A4	Date: 24 may 2014	Rev: 0.7-alpha	
KiCad E.D.A.	eeschema (2013-07-07 BZR 4022)-stable	ld: 5/7	

CII . CO.CO.O.C. II I

