






第 1 章 系统基本功能介绍


1.1 AMOS 登录与密码修改

图解	
	1. 双击 AMOS Business Suite 桌面图标。
	2. 在弹出的 AMOS 登录窗口中，在 Login ID 栏输入用户名，在 Password 栏输入密码。
	3. 如需变更登录密码，单击菜单栏“Tools”>“Change Password...”

	4. 弹出密码修改对话框。 在“Old Password”中输入当前的密码。 在“New Password” 中输入要变更的新密码，然后在“Confirm New Password”中再一次输入新密码。
--	--

1.2 个性化操作界面设置

图解	说明
	1. 通过选项设置可以配置登录用户个性化操作界面。如要查看或更改 Options Setting(选项设置): 打开菜单命令 “Tools” > “Options”。
	2. 各选项功能介绍: Task bar(工具栏): 用户在 Task bar 复选框中可选择是否勾选, 决定屏幕左边是否需要显示或隐藏工具栏。 工具栏有 2 种: 1. Icon bar (图标栏) 2. List bar (列表栏) General (常规): 复选框: Confirm on Exit (退出时确认) 如果勾选了该复选框, 系统会在关闭 AMOS 时要求用户确认是否退出。 Windowing Mode : 当打开窗口时默认为最大化或层叠 Mailbox/Dashboard Check Interval(sec) 为间隔多少时间刷新窗口



3. Views 窗口内显示用户可自定义的界面

“Private” 新增一条 View 记录(新增时，首先打开设置新加界面窗口、保持该窗口打开状态。最后点 OK，输入名称)


Update 为更新所选记录的数据

Delete 为删除所选记录


Set Default 设置默认界面，当设置为默认界面后、每次登陆时都会自动进入设置好的界面。

Startup using default view: 为开启系统时，自动进入到 View 窗口

注：不同用户名登陆的 View 也不同



例如：设置 View 后，在左边的工具栏会多出一项为 Views 显示配置的 View




4. **Predefined Fields** 自定义：
此项可根据不同职务、关注不同点。例如船长只关心证书的到期时间、老轨则要关注设备保养的优先级等

System: 为修改系统界面，即修改后每个人登陆时都看到相同的自定义界面

Private 个人：即自定义界面只在个人登陆时才起作用，非全局

Delete 删除：删除记录




5. **Predefined Filter** 自定义：
此项可根据不同职务、关注不同点。例如老轨如果只关注某类设备保养的情况等

System: 为修改系统界面，即修改后每个人登陆时都看到相同的自定义界面

Private 个人：即自定义界面只在个人登陆时才起作用，非全局

Delete 删除：删除记录



6. **Dashboard** 信息窗。此界面为提醒用户登陆系统时、需要处理的工作


Enable Dashboard 勾选后为启用该功能

Select 选择加入的 Alerts

Deselect 取消选择 Alerts

URL 可在主页引入 Internet 网页

Image 背景图片，可在主页加入背景图片





7. Theme 主题风格

Enable Theme 启用主题风格的设置

注意：本处建议不要修改主题风格（可能会导致使用速度慢）。

1.3 查找及筛选功能的介绍

图解	说明
	AMOS 系统中在任何一个界面都有一个查找窗口，用于筛选需要的数据。 用户有 2 种途径可打开 Filters(查找)窗口： 1. 在打开任何一个功能窗口时，AMOS 都会自动弹出一个查找或筛选窗口 2. 若功能窗口已打开后，可使用快捷键“Ctrl+F”或菜单命令“File”->“Filter...”或在已打开屏幕(如 Component)点击工具栏上的查找按钮
	举例说明： 例如在 Component 窗口： 1. Number 栏可输入需要查询的设备所属 SFI 编码（SFI 编码见后续章程介绍）

Filter

Basic Advanced Function Performing

Number: - -

Name: %Drill Search in 'Details' Also

Maker: -

Type: -

Serial No.: -

Vendor: -

Class Code: -

CHN Name: -

Account: -

Price: -

OK Cancel Clear Global Search

2. **Name** 栏可视情模糊输入
 - (1) “Drill%” 所有名称以 Drill 开头的设备
 - (2) “%Drill” 所有名称内含有 Drill 的全部设备

3. **Maker** 可根据生产厂商查找设备

左图查找所有名称内含有 Drill 的设备。

Components

General Type Details Financial Jobs Parts Counters Measure Points Attachments Work Orders

Number: 311-001-011 Type Number: 311.001.011.930 Status: In Use

Name: Driller Console

Maker: -

Component Class: A11 - Auxil. EQPT

Type: -

Serial No.: - Unplanned Maint. Template: -

Location: -

Parent Comp.: 311- - DRILL CONTROL

Vendor: -

Function: 311.001.011 Driller Console


Comp. Type Model: -

Class Code: -

CHN Name: -

#	Number	Name	Type	Serial No.	Class Code	Account:
244-	-	PIPE RACKS FOR DRILL PIPES AND CASING				
245-	-	DRILL FLOOR				
3-	-	DRILLING EQUIPMENT AND SYSTEMS				
302-	-	CROWN BLOCK WITH DRILL STRING MOTION				
304-	-	DRILL STRING HEAVE COMPENSATOR				
31-	-	DRILL FLOOR EQUIPMENT AND SYSTEMS				
311-	-	DRILL CONTROL				
311-001-011		Driller Console				
311-011-001		Smart Drilling Instrumentation System	SZJ-II			
312-017-001		Drawworks Auto Driller System	WG01621201	LD140508007		
312-017-002		Drawworks Auto Driller System	WG01621201	LD01621202		
312-017-801		Drawworks Auto Driller EL Motor	M2JA225M4A-w V1	3GC13500842427		
312-017-802		Drawworks Auto Driller EL Motor	M2JA225M4A-w V1	3GC13500842427		
316-001-801		Drill Line Reel EL Motor	YB2-132M-4	140207		
317-	-	MISC DRILLFLOOR EQUIPMENT AND SYS				
325-001-001		Drilling Pump	F-1600HL	BY14-035HL		
325-001-002		Drilling Pump	F-1600HL	BY14-033HL		
325-001-003		Drilling Pump	F-1600HL	BY14-034HL		
325-001-801		Drilling Pump EL Motor	YJ31E5	331E5140007		
325-001-802		Drilling Pump EL Motor	YJ31E5	331E5140008		
325-001-803		Drilling Pump EL Motor	YJ31E5	331E5140006		
327-	-	DRILL WATER SYSTEM				
327-002-001		Drill Water Pump	LSB 2 x 3			
327-002-002		Drill Water Pump	LSB 2 x 3			
327-002-011		Drill Water Pump EL Motor	5.5kW			


上图点 OK 后，则列出了所有名称内含有 Drill 的设备。



在查询窗口中，若后边有浏览按钮时。可点此按钮进行筛选，如点前面 Components 的 Filter 窗口中 Maker 后的浏览按钮弹出所有厂商信息

这样就更方便选择后直接筛选

以下列出常用窗口的过滤窗口



1. Maintenance->Function

Number 栏填写 SFI 编码，Description 栏填写名称描述。

Filter

Basic | Advanced | Frequencies | Risk Assessment

Number: / -

Title:

Component: - -

Contractor: -

☐ Show Project Jobs

Function: - -

☐ Include sub-functions

Non-Conformity: - - -

CBM Criteria

☐ Acknowledged

☐ Unacknowledged

Only Job Classes:

ANALYSIS

CALIBRATION

CHECK/INSPECT

CLEANING

LUBRICATION

Only Disciplines:

(Unassigned)

Assistant Driller

ASST Rig Mngt D/N

Barge Engineer

Catering

Function Criticality:

(Un-defined)

Critical

Critical & Main

Critical & Sub

Level 1

☐ Include non-responsible

Planning

☐ Due Now ☐ Overdue ☐ Due This Week ☐ Due Next Week

Due Between: -

OK

Cancel

Clear

Select All

Deselect All

Invert

Global Search

2. Maintenance->Work Orders

Number 工单编码

Title 工作标题描述

Component 设备编码 (SFI 编码)

Only Disciplines 责任人筛选

Planning

(1) Due Now 现在要做

(2) Overdue 过期

(3) Due This/Next Week 本/下周要做

Filter

Basic | Maintenance

Stock Item Criterion

Number: . . .

Alternative No.:

Name:

☐ Search in 'Details' Also

Maker: -

Maker's Ref.:

☐ Search in Vendors' Ref. Also

Preferred Vendor: -

Stock Class:

Drawing No.:

ExtraNo:

Stock Status: Stocked Items

Any criticality above or equal to: Normal

☐ Current Stock > 0 ☐ Perishable Items Only ☐ Asset Items only

Location:

☐ Include Sub-locations

Stock Grade Category:

Stock Grade Code:

Status

☒ Active ☐ Obsolete ☐ Scrapped

CHN Name:

Specification:

OK

Cancel

Clear

Global Search

3. Stock->Stock Items

Number SFI 编码

Name 材料名称



Maker's Ref. 备件号 (厂家引用号码)


Drawing No. 图纸号

Stock Class 材料类别 (如易耗品, 药品, 电气材料等)




Maintenance 标签页包含 Function 功能设备 SFI 编码

1.4 转换部门

图解	说明
 The screenshot shows the main application window with a menu bar (File, Edit, Options, Maintenance, Stock, Purchase, Financial, Tools, Window, Help) and a toolbar. A red box highlights the 'Switch Department' button, which is represented by a green gear icon with a red 'X' inside. The main area displays a 'Dashboard' with an 'Alerts Overview' section under 'Maintenance - Work Order', listing several work orders with their due dates and counts.	1. 点击图中转换部门按钮。
 The 'Switch Department' dialog box is shown. It has a title bar with a close button. Inside, there's a text field for 'Installation/Department:' with a dropdown arrow. Below it is a tree view showing a hierarchy: 'HILONG OIL S & E' (expanded) -> '001/01 Office' -> 'HL-30' (expanded) -> '930/01 Maintenance/Stores - HL30' (selected). To the right of the tree view are buttons for 'OK', 'Cancel', and 'Close Windows'. There's also a 'Sort/Search By' section with radio buttons for 'Code' (selected) and 'Name'.	2. Switch Department(转换部门)窗口弹出。选择要转换的部门，然后点击“OK”或双击该部门也可。 部门编码转换提示： 例如：930/01 930 是船舶编码 01 是位于 930 下的部门编码 3. Close Windows(关闭窗口)按钮： 如果用户在已打开某些窗口的情况下想要转换部门，就可使用该按钮。 关闭窗口按钮就是为了方便用户关闭所有的窗口。 补充说明：有时候有些已打开的窗口需要保存数据，这时候请确认是否要保存，或者先取消关闭窗口这个步骤，回到原来已打开窗口检查一下。

	4. 如果部门已转换成功，那么左图顶部就会显示转换后的部门名字。
--	---

1.5 Dashboard 使用介绍

图解	说明
	1. 用户登陆界面时，会有 Dashboard 窗口弹出 此窗口为根据个人需要设置的警报信息。如需查看提示信息，可直接双击提示栏
	2. 如此处查看所有过期工单，双击红色条
	3. 弹出所有过期工单