





第2章 常用窗口功能介绍

2.1 SFI 编码介绍

图解	说明
 The diagram illustrates the SFI Group System Main Groups and their application on a ship. It includes a ship silhouette with SFI codes (631, 6, 33, 248) and a pyramid diagram showing the hierarchy of SFI codes (6, 63, 631, 631.001) corresponding to Main Group, Group, Sub Group, and Detail Code. A circular diagram shows the SFI Group System Main Groups (SHIP SYSTEM) and their components (1. Ship general, 2. Hull, 3. Equipment for cargo, 4. Ship equipment, 5. Equipment for crew and passengers, 6. Machinery main components, 7. Systems for machinery main components, 8. Ship common system).	在介绍各常用窗口功能之前，我们需要用户对 SFI 编码有一定的认知和了解： SFI分类编码系统是航运业和海洋石油行业应用最为广泛的编码系统。它作为一项国际标准用于对船舶或钻井平台的技术功能和财务信息进行细分。SFI涵盖船舶/钻井船技术规格的所有方面。 SFI Group System的主要目标是通过分类编码的方法，帮助航运公司将所有的业务操作信息关联起来以便掌握船舶运营状况。 这些信息包括： 采购信息、财务信息、维护保养信息、设备技术信息等



2.2 Component 窗口 – 常用功能介绍

图解	说明																																																																																																																																																																																													
 Components General Additional Info Type Details Financial Jobs Parts Counters Measure Points Attachments W.O. History Maint. Log Func Number: 73 Type Number: 73 Status: In Use Name: 73 Compressed Air Systems Maker: Type: Component Class: Serial No.: Unplanned Maint. Template: Location: Parent Comp.: 7 Systems For Machinery Main Components Vendor: Function: 73 Compressed Air Systems Comp. Type Model: Frame No: Class Code: Old CompTypeNo: 73 Criticality: <table border="1"> <thead> <tr> <th>Number</th> <th>Name</th> <th>Type</th> <th>Serial No.</th> <th>Frame No.</th> <th>Class Code</th> <th>Status</th> <th>Func. No.</th> <th>Func. Description</th> </tr> </thead> <tbody> <tr> <td>73</td> <td>73 Compressed Air Systems</td> <td></td> <td></td> <td></td> <td></td> <td>In Use</td> <td>73</td> <td>73 Compressed Air System</td> </tr> <tr> <td>731.001.001</td> <td>2 - Compressor</td> <td>TMC 365-10 EWA</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>731.001.001</td> <td>Rig Air Compressor No 1</td> </tr> <tr> <td>731.001.002</td> <td>2 - Compressor</td> <td>TMC 365-10 EWA</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>731.001.002</td> <td>Rig Air Compressor No 2</td> </tr> <tr> <td>731.021.011</td> <td>1 - Valve, Pressure Relief</td> <td>S245</td> <td>1052</td> <td></td> <td></td> <td>In Use</td> <td>731.021.011</td> <td>#1 Air Compressor #1 Safety</td> </tr> <tr> <td>731.021.012</td> <td>1 - Valve, Pressure Relief</td> <td>S245</td> <td>1133</td> <td></td> <td></td> <td>In Use</td> <td>731.021.012</td> <td>#1 Air Compressor #2 Safety</td> </tr> <tr> <td>731.021.013</td> <td>1 - Valve, Pressure Relief</td> <td>S245</td> <td>1136</td> <td></td> <td></td> <td>In Use</td> <td>731.021.013</td> <td>#2 Air Compressor #1 Safety</td> </tr> <tr> <td>731.021.014</td> <td>1 - Valve, Pressure Relief</td> <td>S245</td> <td>1104</td> <td></td> <td></td> <td>In Use</td> <td>731.021.014</td> <td>#2 Air Compressor #2 Safety</td> </tr> <tr> <td>731.021.021</td> <td>1 - Valve, Pressure Relief</td> <td>CS10FL</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>731.021.021</td> <td>Main Rig Air Pipe Safety</td> </tr> <tr> <td>731.021.022</td> <td>1 - Valve, Pressure Relief</td> <td>CS10FL</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>731.021.022</td> <td>MP Room Air Pipe Safety</td> </tr> <tr> <td>731.021.023</td> <td>1 - Valve, Pressure Relief</td> <td>CS10FL</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>731.021.023</td> <td>Auxiliary Pump Room Air</td> </tr> <tr> <td>732</td> <td>732 Gen. Purpose Air Sys In E</td> <td></td> <td></td> <td></td> <td></td> <td>In Use</td> <td>732</td> <td>732 Gen. Purpose Air Sys</td> </tr> <tr> <td>733</td> <td>733 Gen. Purpose Air Sys For</td> <td></td> <td></td> <td></td> <td></td> <td>In Use</td> <td>733</td> <td>733 Gen. Purpose Air Sys</td> </tr> <tr> <td>733.010.001</td> <td>2 - Tank, Air Receiver</td> <td>WBAR02-2</td> <td>WB1125-10</td> <td></td> <td></td> <td>In Use</td> <td>733.010.001</td> <td>Drill Floor Air Receiver No</td> </tr> <tr> <td>733.010.002</td> <td>2 - Tank, Air Receiver</td> <td>WBAR02-2</td> <td>WB1133-10</td> <td></td> <td></td> <td>In Use</td> <td>733.010.002</td> <td>Drill Floor Air Receiver No</td> </tr> <tr> <td>733.017.001</td> <td>2 - Air Drier</td> <td>TMC RM 2800</td> <td>HN2059390</td> <td></td> <td></td> <td>In Use</td> <td>733.017.001</td> <td>Rig Air Drier No 1</td> </tr> <tr> <td>733.017.002</td> <td>2 - Air Drier</td> <td>TMC RM 2800</td> <td>HN 2059390</td> <td></td> <td></td> <td>In Use</td> <td>733.017.002</td> <td>Rig Air Drier No 2</td> </tr> <tr> <td>733.021.001</td> <td>1 - Valve, Pressure Relief</td> <td>TVV SV07-0811-20</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>733.021.001</td> <td>Rig Air Drier No.1 Safety</td> </tr> <tr> <td>733.021.002</td> <td>1 - Valve, Pressure Relief</td> <td>TVV SV07-0811-20</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>733.021.002</td> <td>Rig Air Drier No.2 Safety</td> </tr> <tr> <td>733.021.011</td> <td>1 - Valve, Pressure Relief</td> <td>A2BH-16</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>733.021.011</td> <td>#1 Drill Floor Air Receiver</td> </tr> <tr> <td>733.021.012</td> <td>1 - Valve, Pressure Relief</td> <td>A2BH-16</td> <td></td> <td></td> <td></td> <td>In Use</td> <td>733.021.012</td> <td>#2 Drill Floor Air Receiver</td> </tr> </tbody> </table>	Number	Name	Type	Serial No.	Frame No.	Class Code	Status	Func. No.	Func. Description	73	73 Compressed Air Systems					In Use	73	73 Compressed Air System	731.001.001	2 - Compressor	TMC 365-10 EWA				In Use	731.001.001	Rig Air Compressor No 1	731.001.002	2 - Compressor	TMC 365-10 EWA				In Use	731.001.002	Rig Air Compressor No 2	731.021.011	1 - Valve, Pressure Relief	S245	1052			In Use	731.021.011	#1 Air Compressor #1 Safety	731.021.012	1 - Valve, Pressure Relief	S245	1133			In Use	731.021.012	#1 Air Compressor #2 Safety	731.021.013	1 - Valve, Pressure Relief	S245	1136			In Use	731.021.013	#2 Air Compressor #1 Safety	731.021.014	1 - Valve, Pressure Relief	S245	1104			In Use	731.021.014	#2 Air Compressor #2 Safety	731.021.021	1 - Valve, Pressure Relief	CS10FL				In Use	731.021.021	Main Rig Air Pipe Safety	731.021.022	1 - Valve, Pressure Relief	CS10FL				In Use	731.021.022	MP Room Air Pipe Safety	731.021.023	1 - Valve, Pressure Relief	CS10FL				In Use	731.021.023	Auxiliary Pump Room Air	732	732 Gen. Purpose Air Sys In E					In Use	732	732 Gen. Purpose Air Sys	733	733 Gen. Purpose Air Sys For					In Use	733	733 Gen. Purpose Air Sys	733.010.001	2 - Tank, Air Receiver	WBAR02-2	WB1125-10			In Use	733.010.001	Drill Floor Air Receiver No	733.010.002	2 - Tank, Air Receiver	WBAR02-2	WB1133-10			In Use	733.010.002	Drill Floor Air Receiver No	733.017.001	2 - Air Drier	TMC RM 2800	HN2059390			In Use	733.017.001	Rig Air Drier No 1	733.017.002	2 - Air Drier	TMC RM 2800	HN 2059390			In Use	733.017.002	Rig Air Drier No 2	733.021.001	1 - Valve, Pressure Relief	TVV SV07-0811-20				In Use	733.021.001	Rig Air Drier No.1 Safety	733.021.002	1 - Valve, Pressure Relief	TVV SV07-0811-20				In Use	733.021.002	Rig Air Drier No.2 Safety	733.021.011	1 - Valve, Pressure Relief	A2BH-16				In Use	733.021.011	#1 Drill Floor Air Receiver	733.021.012	1 - Valve, Pressure Relief	A2BH-16				In Use	733.021.012	#2 Drill Floor Air Receiver	什么是 Component? AMOS M&P 中的维护保养数据是按实际的安装设备及组成部件、以及安装在船上的各系统组成的。Component指的是船上的维修保养单元。执行某项维护保养任务或工作的基础单元。 Component可以是设备，设备可以由部件组成，部件下面还会有另一些更小的部件组成，最底层的部件就是备件，用户通常可以对备件进行更换。在AMOS系统中的备件是指最小的更换单元。 Component可以是系统，大系统还可以包含小系统，小系统又可包含相应的部件和组件。 Component又可以扩展为任何船上的管理要素，包括证书、资料、表格、以及共享信息。 综上所述，Component是任何需要纳入船舶管理的控制元素。 每一个设备及部件都有其标准编码。 左图显示的是部件如何在AMOS排列
Number	Name	Type	Serial No.	Frame No.	Class Code	Status	Func. No.	Func. Description																																																																																																																																																																																						
73	73 Compressed Air Systems					In Use	73	73 Compressed Air System																																																																																																																																																																																						
731.001.001	2 - Compressor	TMC 365-10 EWA				In Use	731.001.001	Rig Air Compressor No 1																																																																																																																																																																																						
731.001.002	2 - Compressor	TMC 365-10 EWA				In Use	731.001.002	Rig Air Compressor No 2																																																																																																																																																																																						
731.021.011	1 - Valve, Pressure Relief	S245	1052			In Use	731.021.011	#1 Air Compressor #1 Safety																																																																																																																																																																																						
731.021.012	1 - Valve, Pressure Relief	S245	1133			In Use	731.021.012	#1 Air Compressor #2 Safety																																																																																																																																																																																						
731.021.013	1 - Valve, Pressure Relief	S245	1136			In Use	731.021.013	#2 Air Compressor #1 Safety																																																																																																																																																																																						
731.021.014	1 - Valve, Pressure Relief	S245	1104			In Use	731.021.014	#2 Air Compressor #2 Safety																																																																																																																																																																																						
731.021.021	1 - Valve, Pressure Relief	CS10FL				In Use	731.021.021	Main Rig Air Pipe Safety																																																																																																																																																																																						
731.021.022	1 - Valve, Pressure Relief	CS10FL				In Use	731.021.022	MP Room Air Pipe Safety																																																																																																																																																																																						
731.021.023	1 - Valve, Pressure Relief	CS10FL				In Use	731.021.023	Auxiliary Pump Room Air																																																																																																																																																																																						
732	732 Gen. Purpose Air Sys In E					In Use	732	732 Gen. Purpose Air Sys																																																																																																																																																																																						
733	733 Gen. Purpose Air Sys For					In Use	733	733 Gen. Purpose Air Sys																																																																																																																																																																																						
733.010.001	2 - Tank, Air Receiver	WBAR02-2	WB1125-10			In Use	733.010.001	Drill Floor Air Receiver No																																																																																																																																																																																						
733.010.002	2 - Tank, Air Receiver	WBAR02-2	WB1133-10			In Use	733.010.002	Drill Floor Air Receiver No																																																																																																																																																																																						
733.017.001	2 - Air Drier	TMC RM 2800	HN2059390			In Use	733.017.001	Rig Air Drier No 1																																																																																																																																																																																						
733.017.002	2 - Air Drier	TMC RM 2800	HN 2059390			In Use	733.017.002	Rig Air Drier No 2																																																																																																																																																																																						
733.021.001	1 - Valve, Pressure Relief	TVV SV07-0811-20				In Use	733.021.001	Rig Air Drier No.1 Safety																																																																																																																																																																																						
733.021.002	1 - Valve, Pressure Relief	TVV SV07-0811-20				In Use	733.021.002	Rig Air Drier No.2 Safety																																																																																																																																																																																						
733.021.011	1 - Valve, Pressure Relief	A2BH-16				In Use	733.021.011	#1 Drill Floor Air Receiver																																																																																																																																																																																						
733.021.012	1 - Valve, Pressure Relief	A2BH-16				In Use	733.021.012	#2 Drill Floor Air Receiver																																																																																																																																																																																						
 File Edit Options Maintenance Stock Purchase Financial Component Types Component Types Hierarchy Components Components Hierarchy Functions Functions Hierarchy	如何使用设备/部件查找窗口: 1. 点击屏幕左边的图标栏中 Main 菜单下的“Components”图标，当然也可选择菜单命令 Maintenance -> Components																																																																																																																																																																																													

Filter

Basic Advanced Function Performing

Number: [] []

Name: [] Search in 'Details' Also

Maker: [] []

Type: []

Serial No.: []

Vendor: [] []

Class Code []

CHN Name: []

Account: []

Price [] []

OK Cancel Clear Global Search

2. 弹出查找窗口:

要找到想要的部件，可输入部件名称或部件编码。

点击浏览按钮，又打开一个查找窗口。

Select

Code Name

30

Code	Name
3 - -	DRILLING EQUIPMENT AND SYSTEMS
30 - -	DERRICK WITH COMPONENTS
301 - -	DERRICK STRUCTURE
301-001-001	Derrick
301-001-011	Derrick Hoisting Wire Rope
301-002-001	Racking Board Winch
301-005-001	Casing Stabbing Board
301-011-001	Substructure
301-011-011	Substructure Hoisting Wire Rope
301-055-001	Derrick Hoisting Pulley
301-055-011	Substructure Hoisting Pulley
302 - -	CROWN BLOCK WITH DRILL STRING MOTION
302-001-001	Crown Block

OK Cancel

3. 在这个查找窗口中，我们既可以用部件名字排序也可根据编码排序，比如左图中的部件编码输入的是“30”，窗口下半部分就会显示所有编码以 30 开头的部件。

4. 如果我们要查找的是 Derrick，那么就单击该项，然后点击 OK 按钮。

Filter

Basic Advanced Function Performing

Number: 301-001-001 []

Name: [] Search in 'Details' Also

Maker: [] []

Type: []

Serial No.: []

Vendor: [] []

Class Code []

CHN Name: []


Account: []

Price [] []


OK Cancel Clear Global Search

5. 点击 OK 后，编码会自动输入到查找窗口的编码字段中。


6. 现在再点击 OK 就可查看 Component 了。



7. AMOS 查找窗口支持通配符搜索，比如要找到所有名称中包含 Engine 的部件，我们只需在 Name 字段中输入“%Engine”即可，百分号的意思是指所有。



8. “...”图标指的是该栏目可继续打开浏览窗口进一步做选择。



9. 在查找窗口中，“Advanced”标签页中可以输入更多的查找条件。

例如：

- (1) Component Status(部件状态)
- (2) Warranty Period(保修期)提供了某个部件的保修日期范围
- (3) Location (位置)表示该设备安装的位置
- (4) Component type(部件类型)
- (5) 您也可以在“Function Performing”标签页中输

入更多的查找条件。

Components

General | Type Details | Financial | Jobs | Parts | Counters | Measure Points | Attachments | Work Orders

Number: 302.001.001 Type Number: 302.001.001.930 Status: In Use

Name: Crown Block

Maker: BAO-001 BAQJI OILFIELD MACHINERY CO., LTD

Component Class: B3 - Derrick Hoist EQPT

Type: TC675-1

Serial No.: PT14-001 Unplanned Maint. Template: ▼

Location: ...

Parent Comp.: 302. CROWN BLOCK WITH DRILL STRING MOTION COMPEN ...

Vendor: ...

Function: 302.001.001 Crown Block

Comp. Type Model: ...


Class Code: ...

CHN Name: 天车


#	Number	Name	Type	Serial No.	Class Code	Account	Status
30.	.	DERRICK WITH COMPONEN					(None)
301.	.	DERRICK STRUCTURE					(None)
301.001.001		Derrick	JJ675/48-K3	JG14-001			In Use
301.001.011		Derrick Hoisting Wire Rope					In Use
301.002.001		Racking Board					In Use
301.005.001		Casing Stabbing Board		JG14-001			In Use
301.011.001		Substructure	DZ675/12×8	JG14-001			In Use
301.011.011		Substructure Hoisting Wire Roj					In Use
301.055.001		Derrick Hoisting Pulley					In Use
301.055.011		Substructure Hoisting Pulley					In Use
301.065.001		BOP Trolley Beam					In Use
302.	.	CROWN BLOCK WITH DRILL					(None)
302.001.001		Crown Block	TC675-1	PT14-001			In Use
303.	.	TRAVELLING EQUIPMENT					(None)
303.001.001		Travelling Block	YC-675	ZS14-001			In Use
303.003.001		Hook	DG675	ZS14-002			In Use
304.	.	DRILL STRING HEAVE COMF					(None)

10. 下面介绍 Components 窗口各选项卡的内容

11. General(常规)窗口显示的是该部件的详细情况，如部件名称、厂家、序列号、位置等...



12. Type Details(详细描述)标签页显示的是所选部件的技术信息，这些信息一般来自于设备说明书中。



13. Jobs:

该标签页显示的是所选部件要求实施的维护保养工作。

用户也可先选择某个工作，再点击 View 按钮来查看所选工作描述。

点击 Details 按钮可查看该工作步骤的详细情况，这些信息可指导责任人完成工作。

Component Jobs [302.001.001 - Crown Block]

General Job Specific Details Job Description JD Attachments Counters Measure Points Triggers Required

Job Description: 10006 1 Inspect Crown Block 1W

Periodic Frequency: 1 Week(s)

Resp. Discipline: Planning Method: Variable

Output Format: List Estimates

Print Template with W/O: No, Optional Total Duration: 0

History Template: Total Cost: USD 0.00

Reporting Options

History: Parameter

Resources: Parameter

Stock Usage: Parameter

Last Done: 2016/9/18 W 37/16 Window: 0

Active

CBM Status: Normal

Priority: 5

Maint. Criteria: Equip Inspection

Work Classification

Maint. Type: Check/ Inspection

Maint. Class: B - General Rig Specific

Maint. Cause: Preventive Maintenance

Planned for Component Status

(None) Available In Use Repair

Maint. Budget:

Stock Budget:

Code	Revision	Title	Frequency	Window	Last Done	Priority	Resp. Discipline
10006	1	Inspect Crown Block 1W	1 Week(s)	0	W37/165		
10007	1	Inspect Crown Block 1M	1 Month(s)	0	M09/165		
10008	1	Inspect Crown Block 12M	12 Month(s)	0	M09/165		
10111	1	Inspect Crown Block 12M	12 Month(s)	0	M09/165		
L0010	1	Lubricate Crown Block Bearing	150 Hour (150)	0	M09/165		

14. 部件的维护保养工作描述:

该标签页显示的是维护保养工作的详细情况, 如:
Periodic Frequency (工作周期)

Last Done date (上次完成日期)

Work Classification(工作类别)

Components

General Type Details Financial Job Parts Counters Measure Points Attachments Work Orders Maint. Log Function Performance Functions Perform

Item No. Name Makers Ref. In Use In Stock Drawing No. Positions Alternative No. Status

302.001.001.930.0000	SKETCH OF CROWN BLOCK, TC		0	0			Active
302.001.001.930.0001	Crown Block, TC675-1	AA675102-00	0	0	Fig 1		Active
302.001.001.930.0002	Nameplate	AA675102-01	1.00	0	Fig 1	1	Active
302.001.001.930.0003	Crown Block Frame	AA675102-0200	1.00	0	Fig 1	2	Active
302.001.001.930.0004	Main Sheave Assembly	AA675102-0300	1.00	0	Fig 1	3	Active
302.001.001.930.0005	Jumper Frame I	AA675102-0400	1.00	0	Fig 1	4	Active
302.001.001.930.0006	Jumper Frame II	AA675101-0500	1.00	0	Fig 1	5	Active
302.001.001.930.0007	Hand Rail	AA675101-0600	1.00	0	Fig 1	6	Active
302.001.001.930.0008	Jumper Frame II	AA675101-1300	2.00	0	Fig 1	7	Active
302.001.001.930.0009	Guide Sheave Assembly	AA675101-0400	1.00	0	Fig 1	8	Active
302.001.001.930.0010	Hoist Frame	AA675101-0100	1.00	0	Fig 1	9	Active
302.001.001.930.0011	Protective Covering	AA675101-1000	1.00	0	Fig 1	10	Active
302.001.001.930.0012	Crown Block Saver	AA675101-1100	1.00	0	Fig 1	11	Active
302.001.001.930.0013	Support I	AA675101-0800	1.00	0	Fig 1	12	Active
302.001.001.930.0014	Support II	AA675101-0900	1.00	0	Fig 1	13	Active

View Delete View Add Info Set Status Copy List

#	Number	Name	Type	Serial No.	Class Code	Account	Status	Func. No.	Func. Description	CHN Name
30		DERRICK WITH COMPONENT					(None)			
301		DERRICK STRUCTURE					(None)			
301.001.001		Derrick	JG675/48-K3	JG14-001			In Use	301.001.001	Derrick	井架
301.001.011		Derrick Hoisting Wire Rope					In Use	301.001.011	Derrick Hoisting Wire Rop	井架起升钢丝绳
301.002.001		Racking Board					In Use	301.002.001	Racking Board	二层台
301.005.001		Casing Stabbing Board		JG14-001			In Use	301.005.001	Casing Stabbing Board	套管扶正台
301.011.001		Substructure	DZG75/12x8	JG14-001			In Use	301.011.001	Substructure	底座
301.011.011		Substructure Hoisting Wire Rop					In Use	301.011.011	Substructure Hoisting Wire Rop	底座起升钢丝绳
301.055.001		Derrick Hoisting Pulley					In Use	301.055.001	Derrick Hoisting Pulley	起升滑轮
301.055.011		Substructure Hoisting Pulley					In Use	301.055.011	Substructure Hoisting Pulley	起升滑轮
301.065.001		BOP Trolley Beam					In Use	301.065.001	BOP Trolley Beam	防喷器横梁
302		CROWN BLOCK WITH DRILL					(None)			
302.001.001		Crown Block	TC675-1	PT14-001			In Use	302.001.001	Crown Block	块主
303		TRAVELLING EQUIPMENT					(None)			
303.001.001		Travelling Block	YC-675	ZS14-001			In Use	303.001.001	Travelling Block	游车
303.003.001		Hook	D6675	ZS14-002			In Use	303.003.001	Hook	大钩
304		DRILL STRING HEAVE COMP					(None)			

15. Parts (备件):

该标签页显示的是所有与所选部件相关联的备件。

点击 View 按钮, 就会打开 Stock Items 窗口。

Stock Items [302.001.001.930.0001 - Crown Block, TC675-1]

General | Type Details | Vendors | Outstanding Forms | Stock Transactions | Components | Component Type

Number: 302.001.001.930.0001 Status: Active
 Name: Crown Block, TC675-1
 Maker: BAO-001 BAOJI OILFIELD MACHINERY CO., LTD
 Maker's Ref.: AA675102-00
 Preferred Vendor: -
 Vendor's Ref.: -

Class for Financial:
 ExtraNo:
☐ Perishable Item

Locations

A	Location	Current Stock	Expiry Date
★	HL30	10.00	

Total Stock: 10.00

Default Add Add Remove

Stock Class: DD 9 Derrick and Drawworks
 Price Class:
 Criticality: Normal
 CHN Name:
 Specification:

A	Number	Name	QA Grading	Maker Code	Maker's Reference	Unit
	302.001.001.930.0001	Crown Block, TC675-1		BAO-001	AA675102-00	PCS

16. 在 Stock Items 窗口中查看备件详情:

General(常规)页显示的是所选备件所有基本信息, 如 Number (编码)、Name(名称)、Makers(厂家)、Vendor(供应商)等...

Location(库存位置):

库存位置显示的是所选备件的储存位置和库存数量。

Current Stock(当前库存, 即 ROB)

Components

General | Type Details | Financial | Jobs | Parts | Counters | Measure Points | Attachments | Work Orders | History | Maint. Log | Function P

Counter	Date Read	Current Value	Start Date	Latest Start Value	Latest Zeroed Date	Total at Zeroed	Total Running	Average	Calculate Average	Depends On
Hour	2016/9/18	400.00	2016/9/1	0		0	400.00	22.22	☒	...

New Delete Update Set Start Replace

A	Number	Name	Type	Serial No.	Class Code	Account	Status	Func. No.	Func. Description
30.		DERRICK WITH COMPONENT					(None)		
301.		DERRICK STRUCTURE					(None)		
301.001.001		Derrick	JJ675/49-K3	JG14-001			In Use	301.001.001	Derrick
301.001.011		Derrick Hoisting Wire Rope					In Use	301.001.011	Derrick Hoisting Wire Rope
301.002.001		Racking Board					In Use	301.002.001	Racking Board
301.005.001		Casing Stabbing Board		JG14-001			In Use	301.005.001	Casing Stabbing Board
301.011.001		Substructure	DZ675/12X8	JG14-001			In Use	301.011.001	Substructure
301.011.011		Substructure Hoisting Wire Rope					In Use	301.011.011	Substructure Hoisting Wire Rope
301.055.001		Derrick Hoisting Pulley					In Use	301.055.001	Derrick Hoisting Pulley
301.055.011		Substructure Hoisting Pulley					In Use	301.055.011	Substructure Hoisting Pulley
301.065.001		BOP Trolley Beam					In Use	301.065.001	BOP Trolley Beam
302.		CROWN BLOCK WITH DRILL					(None)		
302.001.001		Crown Block	TC675-1	PT14-001			In Use	302.001.001	Crown Block
303.		TRAVELLING EQUIPMENT					(None)		
303.001.001		Travelling Block	YC-675	ZS14-001			In Use	303.001.001	Travelling Block
303.003.001		Hook	DG675	ZS14-002			In Use	303.003.001	Hook

17. Counters (计数器/运行小时数):

该标签页显示的是所选部件的运行时间, 有以下几个时间:

Start: 运行起始日期和时间

Zeroed: 归零日期和归零值

Average: 平均每天运转小时数

AMOS M&P 会根据计数器上的 (Average) 平均每天运转小时数来计算该部件的下次维护保养日期。

Components

General | Type Details | Financial | Jobs | Parts | Counters | Measure Points | **Attachments** | Work Orders | History | Maint. Log | Function P.

Code: DEF-930-0016 Name: Crown Block

New | Delete | Import... | Find file... | **View**

Number	Name	Type	Serial No.	Class Code	Account	Status	Func. No.	Func. Description
301.001.001	DERRICK WITH COMPONENT					(None)		
301.001.001	DERRICK STRUCTURE					(None)		
301.001.001	Derrick	JJ675/48-K3	JG14-001			In Use	301.001.001	Derrick
301.001.011	Derrick Hoisting Wire Rope					In Use	301.001.011	Derrick Hoisting Wire Rope
301.002.001	Racking Board					In Use	301.002.001	Racking Board
301.005.001	Casing Stabbing Board		JG14-001			In Use	301.005.001	Casing Stabbing Board
301.011.001	Substructure	DZ675/12x8	JG14-001			In Use	301.011.001	Substructure
301.011.011	Substructure Hoisting Wire Rope					In Use	301.011.011	Substructure Hoisting Wire Rope
301.055.001	Derrick Hoisting Pulley					In Use	301.055.001	Derrick Hoisting Pulley
301.055.011	Substructure Hoisting Pulley					In Use	301.055.011	Substructure Hoisting Pulley
301.065.001	BDP Trolley Beam					In Use	301.065.001	BDP Trolley Beam
302.001.001	CROWN BLOCK WITH DRILL					(None)		
302.001.001	Crown Block	TC675-1	PT14-001			In Use	302.001.001	Crown Block

18. Attachment(附件):

该标签页显示的是部件附加文件图纸信息。

要添加附件只许点击 New 按钮。

点击 View 按钮可查看整个附件，附件可以是各种类型文件，比如 Word 或 PDF 文件。

Components

General | Type Details | Financial | Jobs | Parts | Counters | Measure Points | Attachment | **Work Orders** | History | Maint. Log | Function P.

Number	Title	Component	Priority	Resp. Discipline	Status	Due	Pt. Start	Start
930/16-00006	I0007 - Inspect Crown Block 1M	302.001.001	5		Issued	2016/10/10		
930/16-00007	I0008 - Inspect Crown Block 12M	302.001.001	5		Issued	2017/9/10		
930/16-00008	I0111 - Inspect Crown Block 12M	302.001.001	5		Issued	2017/9/10		
930/16-00009	I0006 - Inspect Crown Block 1w	302.001.001	5		Issued	2016/9/25		
930/16-00012	L0010 - Lubricate Crown Block Bearing 1E	302.001.001	5		Issued	2016/9/24		

Show Filed/Cancelled | **View**

Number	Name	Type	Serial No.	Class Code	Account	Status	Func. No.	Func. Description
301.001.001	DERRICK WITH COMPONENT					(None)		
301.001.001	DERRICK STRUCTURE					(None)		
301.001.001	Derrick	JJ675/48-K3	JG14-001			In Use	301.001.001	Derrick
301.001.011	Derrick Hoisting Wire Rope					In Use	301.001.011	Derrick Hoisting Wire Rope
301.002.001	Racking Board					In Use	301.002.001	Racking Board
301.005.001	Casing Stabbing Board		JG14-001			In Use	301.005.001	Casing Stabbing Board
301.011.001	Substructure	DZ675/12x8	JG14-001			In Use	301.011.001	Substructure
301.011.011	Substructure Hoisting Wire Rope					In Use	301.011.011	Substructure Hoisting Wire Rope
301.055.001	Derrick Hoisting Pulley					In Use	301.055.001	Derrick Hoisting Pulley
301.055.011	Substructure Hoisting Pulley					In Use	301.055.011	Substructure Hoisting Pulley
301.065.001	BDP Trolley Beam					In Use	301.065.001	BDP Trolley Beam
302.001.001	CROWN BLOCK WITH DRILL					(None)		
302.001.001	Crown Block	TC675-1	PT14-001			In Use	302.001.001	Crown Block

19. Work Order(工单):

该标签页显示的是与所选部件相关联的工单。

Work Order 编码自动生成 Title(工单)名称由工作编码和工作描述组成。

Resp. Discipline 指的是该工作的负责人。

Due (到期日)是指下一次维护保养的日期，工作必须在该日期或之前完成。

点击 View 按钮，用户可查看工作详细情况。

Components

General
 Type Details
 Financial
 Jobs
 Parts
 Counters
 Measure Points
 Attachments
 Work Orders
 History
 Maint. Log
 Function P

Date Done	Component	Job Code	Work Order	Description	Written By
2016/9/18	302.001.001	I0006	930/16-00005	I0006 - Inspect Crown Block 1	SYSDP
2016/9/18	302.001.001	L0010	930/16-00011	L0010 - Lubricate Crown Block	SYSDP

View

#	Number	Name	Type	Serial No.	Class Code	Account	Status	Func. No.	Func. Description
30.	.	DERRICK WITH COMPONENT					(None)		
301.	.	DERRICK STRUCTURE					(None)		
301.001.001		Derrick	JJ675/48-K3	JG14-001			In Use	301.001.001	Derrick
301.001.011		Derrick Hoisting Wire Rope					In Use	301.001.011	Derrick Hoisting Wire Rope
301.002.001		Racking Board					In Use	301.002.001	Racking Board
301.005.001		Casing Stabbing Board		JG14-001			In Use	301.005.001	Casing Stabbing Board
301.011.001		Substructure	DZ675/12x8	JG14-001			In Use	301.011.001	Substructure
301.011.011		Substructure Hoisting Wire Rope					In Use	301.011.011	Substructure Hoisting Wire Rope
301.055.001		Derrick Hoisting Pulley					In Use	301.055.001	Derrick Hoisting Pulley
301.055.011		Substructure Hoisting Pulley					In Use	301.055.011	Substructure Hoisting Pulley
301.065.001		BOP Trolley Beam					In Use	301.065.001	BOP Trolley Beam
302.	.	CROWN BLOCK WITH DRILL					(None)		
302.001.001		Crown Block	TC675-1	PT14-001			In Use	302.001.001	Crown Block

20. History (维护保养的历史内容):

该标签页提供了所选部件的所有历史工作内容清单。

点击 View 按钮，用户可查看历史记录详情。

Components

General	Type Details	Financial	Jobs	Parts	Counters	Measure Points	Attachments	Work Orders	History	Maint. Log	Function P
Date Done	Component	Job Code	Work Order	Title	Function	Reported By	Checked By				
2016/9/18	302.001.001	I0006	930/16-00005	I0006 - Inspect Crown Block 1W	302.001.001	SYSDP	Ch...				
2016/9/18	302.001.001	L0010	930/16-00011	L0010 - Lubricate Crown Block Bearing 150H	302.001.001	SYSDP	Lub...				



View

#	Number	Name	Type	Serial No.	Class Code	Account	Status	Func. No.	Func. Description
30.	.	DERRICK WITH COMPONENT					(None)		
301.	.	DERRICK STRUCTURE					(None)		
301.001.001		Derrick	JJ675/48-K3	JG14-001			In Use	301.001.001	Derrick
301.001.011		Derrick Hoisting Wire Rope					In Use	301.001.011	Derrick Hoisting Wire Rope
301.002.001		Racking Board					In Use	301.002.001	Racking Board
301.005.001		Casing Stabbing Board		JG14-001			In Use	301.005.001	Casing Stabbing Board
301.011.001		Substructure	DZ675/12x8	JG14-001			In Use	301.011.001	Substructure
301.011.011		Substructure Hoisting Wire Rope					In Use	301.011.011	Substructure Hoisting Wire Rope
301.055.001		Derrick Hoisting Pulley					In Use	301.055.001	Derrick Hoisting Pulley
301.055.011		Substructure Hoisting Pulley					In Use	301.055.011	Substructure Hoisting Pulley
301.065.001		BOP Trolley Beam					In Use	301.065.001	BOP Trolley Beam
302.	.	CROWN BLOCK WITH DRILL					(None)		
302.001.001		Crown Block	TC675-1	PT14-001			In Use	302.001.001	Crown Block

21. Maintenance Log(维护保养记录):

该标签页显示的是所选部件的维护保养记录。对该设备工单做的任何汇报，这里都会有一个记录，包括上次完成的时间，工单分类，汇报工单时增加的附件等等。

2.3 Sotck Items 窗口-常用功能介绍

图解	说明
	1. 在 AMOS 系统中所有的材料统一称之为 Stock Stock Items(材料条目): 点击屏幕左边的图标栏中 Stock 菜单下的 Items 图标, 当然也可选择菜单命令 Stock -> Stock Items
	2. Stock Items 查找窗口介绍: -Number: SFI 编码 -Name: 材料名称 -Maker: 厂家 -Maker's Ref: 厂家参考号 -Stock Class: 材料所属的类别 -Drawing No.: 材料图纸号 -Location: 材料库存位置
	3. General(常规)窗口介绍: -Number: SFI 编码 -Name: 材料名称 -Maker: 材料制造厂家 -Maker's Ref: 备件号 (厂家参考号) -Location: 当前材料的库存位置, 一个材料可有几个

Stock Items

General | Type Details | Vendors | Outstanding Forms | Stock Transactions | Components | Component Types | Reserved

Number: 301.005.001.930.0001 Status: Active

Name: Casing Stabbing Platform Class for Financial:

Maker: BAO-001 BAOJI OILFIELD MACHINERY CO., LTD ExtraNo:

Maker's Ref.: JJ948401-2900 Asset

Preferred Vendor:

Vendor's Ref.:

Locations

A	Location	Current Stock	Expiry Date
★	HL30	10.00	

Total Stock: 10.00

Default Add Add Remove

Stock Class: DMC 10 Drilling Machinery and Controls

Price Class: Criticality: Normal

CHN Name: 气动套管台总成

Specification:

Perishable Item

Stock Details

☒ Stocked Item Stock Maximum: 0

Stock Unit: PCS Stock Minimum: 0

Wanted: 0 Reorder Level: 0

Reserved: 0 Reorder Quantity: 0

Booked: 0 Unbooked: 10.00

Prices

Stock Average: USD 0.00

Last Purchased: USD 0.00 2016/9/18

A	Number	Name	QA Grading	Maker Code	Maker's Reference	Unit	Pref. Vendor Code
☐	301.005.001.930.0001	CASING STABBING PLATFORM					
☒	301.005.001.930.0001	Casing Stabbing Platform		BAO-001	JJ948401-2900	PCS	
☐	301.005.001.930.0001	Connecting Frame		BAO-001	JJ948401-290100	PCS	
☐	301.005.001.930.0001	Handrail		BAO-001	JJ948401-290200	PCS	

库存位置及库存数量。

-Stock Class: 备件分类

Stock Items

General | **Type Details** | Vendors | Outstanding Forms | Stock Transactions | Components | Component Types | Reserved

Section1/1 Page1/1 Line1 Column0 100% CAPS NUM

A	Number	Name	QA Grading	Maker Code	Maker's Reference	Unit	Pref. Vendor Code
☐	301.005.001.930.0001	CASING STABBING PLATFORM					
☒	301.005.001.930.0001	Casing Stabbing Platform		BAO-001	JJ948401-2900	PCS	
☐	301.005.001.930.0001	Connecting Frame		BAO-001	JJ948401-290100	PCS	
☐	301.005.001.930.0001	Handrail		BAO-001	JJ948401-290200	PCS	

4. Type Details (详细描述)为材料的描述，因 General 窗口中有备件号和型号等信息，一般在此窗口中填写一些特殊备件描述的详细信息。

Stock Items

General | Type Details | **Vendors** | Outstanding Forms | Stock Transactions | Components | Component Types

Vendor	Name	QA Grading	Vendor's Ref.	Unit	Factor	Cur
BAO-004	宝鸡市双宏液压机械有限公司			PCS	1.0000	USD

New | Delete | View

Number	Name	QA Grading	Maker Code	Maker's Reference	Unit
301.005.001.930.000	CASING STABBING PLATFORM				
301.005.001.930.000	Casing Stabbing Platform		BAO-001	JJ948401-2900	PCS
301.005.001.930.000	Connecting Frame		BAO-001	JJ948401-290100	PCS

5. Vendors(供应商):

该标签页显示的是所选材料采购或报价相关的历史。

Stock Items

General | Type Details | Vendors | **Outstanding Forms** | Stock Transactions | Components | Component Types | Reserved

Form Type	Form No.	Title	Quantity	Unit	Required	Status
Requisition Form	HL30/16-00001	Automatically Created Form	15.00	PCS	15.00	Active

View

Number	Name	QA Grading	Maker Code	Maker's Reference	Unit	Pref. Vendor Code
301.005.001.930.000	CASING STABBING PLATFORM					
301.005.001.930.000	Casing Stabbing Platform		BAO-001	JJ948401-2900	PCS	
301.005.001.930.000	Connecting Frame		BAO-001	JJ948401-290100	PCS	

6. Outstanding Forms(正在进行的申请单或采购单):

该标签页显示的是所选材料的采购单还处于采购或询价阶段。

Stock Items

General | Type Details | Vendors | Outstanding Forms | **Stock Transactions** | Components | Component Types | Reserved

Trans. Date	Item No.	Name	Trans. Type	Comp No.	Function No.	Function
2016/9/18	301.005.001.930.00	Casing Stabbing Platform	Purchased			


New | Delete | View

Number	Name	QA Grading	Maker Code	Maker's Reference	Unit	Pref. Vendor Code
301.005.001.930.000	CASING STABBING PLATFORM					
301.005.001.930.000	Casing Stabbing Platform		BAO-001	JJ948401-2900	PCS	
301.005.001.930.000	Connecting Frame		BAO-001	JJ948401-290100	PCS	

7. Stock Transactions(库存变更记录):


该标签页显示所选备件的所有库存变更记录，包括 Transaction Type(变更类型)、Date(日期)、Name(材料名称)等。

例如，左图显示在 2016 年 7 月 25 日采购了备件。如要查看详细信息，请点击 View 按钮。




8. Component(部件)

Component 标签页显示的是所选备件用于哪些设备上。



9. Attachments(附件):

附件可用于添加对所选材料的附加描述。
附件可以是图片或 Word 文件等。






10. Overview(材料库存概览):

该标签页显示的是过去 5 年中所选材料的存耗情况。

2.4 Components Hierarchy 窗口 - 常用功能介绍

图解	说明
----	----

	1. 点击屏幕左边的图标栏中 Main 菜单下的 “Components Hierarchy”图标，当然也可选择菜单命令 Maintenance -> Components Hierarchy
	2. 若 SFI 编码被隐藏，可点击 “Toggle number”(显示编码)按钮，可以在部件名称前显示设备或部件编码。





3. 左图显示已在部件树状结构中显示设备部件，图片的右边是一个包含该船舶下的所选部件的基础数据信息窗口。

部件树状结构窗口中的各个标签页显示的是该部件的所有相关信息。


如要通过编码或名称中的几个字母来查找某个树状结构，按 F3 或菜单命令“Options”->“Find”打开查找窗口

2.5 Function Hierarchy 窗口 - 常用功能介绍

图解	说明
 The diagram illustrates the Function Hierarchy for a 6-cylinder internal combustion engine. It shows the relationship between Functions (e.g., Cylinder #1 to #6), Components (e.g., Piston #1 to #6), and Stock Items (e.g., Piston #1 to #6). The diagram includes a schematic of the engine, a list of components, and a list of stock items.	1. Function(功能位置) 部件可以移动，但是功能却是固定不变的，同一个部件可以执行不同的功能作用。如一台 6 缸的内燃机中，1 至 6 号缸活塞就是一个功能位置 (Function)，这 6 个功能位置是固定的，但是可能有 7 个不同序列号的实体活塞 (Component)，其中一个为备用，这 7 个活塞在修理时可以循环的安装在不同的功能位置上。



2. 点击屏幕左边的图标栏中 Main 菜单下的“Function Hierarchy”图标，当然也可选择菜单命令 Maintenance -> Function Hierarchy”



3. 若 SFI 编码被隐藏可点击“Toggle number” (显示编码)按钮显示功能编码，这与部件树状结构一样。