## Freedom Fone

# Installation and Developers Guide

Louise Berthilson (IT46) Alberto Escudero-Pascual (IT46) December 2011

(cc) Creative Commons Share Alike Non-Commercial Attribution 3.0

## Table of Contents

1 Introduction	1
1.1 What is Freedom Fone?	1
1.2 Architecture	1
2 Code structure	3
2.1 Installing	4
2.1.1 Install Ubuntu 10.04	4
2.1.2 Install subversion	4
2.1.3 Download Freedom Fone installer	4
2.1.4 Install packages and dependencies	4
2.1.5 Download pre-compiled packages for Freeswitch and Cepstral	5
2.1.6 Install Cepstral	
2.1.7 Install Freeswitch for Freedom Fone	
2.1.8 Install rootconf	
2.1.9 Install DB Schemas	5
2.1.10 Fix permissions	
2.2 Updating a running installation	
2.3 Passwords	
3 FreeSWITCH	
3.1 Building FreeSWITCH	
3.2 Text-to-speech support	
4 The Incoming dispatcher	
4.1 FreeSWITCH events	
4.2 Dispatcher state machine	
5 Poll	
5.1 Event data and dispatcher	
5.2 Poll specific logics	
5.3 Database structure	
5.3.1 Polls	
5.3.2 Votes	
5.4 Admin functionality	
5.5 Logging	
6 Leave a message	
6.1 Event data and dispatcher	
6.2 Leave-a-message specific logics	
6.3 Admin functionality	
6.3.1 Manage messages	
6.3.2 Leave-a-message instances	
6.3.3 Leave-a-message structure	
6.4 Leave-a-message IVR architecture	
6.5 Database structure	
6.5.1 Table: messages	
6.5.2 Table: categories	
6.5.3 Table: tags.	
6.5.4 Table: messages_tags	
6.5.5 Table: lm menus	24

7 IVR (Interactive voice menus)	26
7.1 Language selector	26
7.2 Voice menus	26
7.3 Database structure	28
7.4 Mapping of services	29
7.5 Nested menus	29
7.6 Instances	30
7.7 IVR.XML	31
8 Content	32
8.1 Interaction with FreeSWITCH	32
9 The IVR XML dialplan	33
9.1 Dialplan actions	33
9.2 Freedom Fone example code	33
9.3 Content	34
9.4 Voice Menu (IVR)	35
9.5 Leave-a-Message	35
9.6 Default IVR options	
9.7 Monitoring of Voice Menus	35
10 Audio tricks	37
10.1 On-the-fly audio conversion (iWatch)	37
10.2 File duration	37
10.2.1 Known issues	37
11 Call data records (CDR)	38
11.1 CDR event types	38
11.1.1 CS_ROUTING	39
11.1.2 CS_DESTROY	39
11.2 Statistics	40
11.3 Reporting	40
12 Users and phone books	41
12.1 Validation of data	42
12.2 User activity	42
12.3 Phone books	42
12.4 Access Control Level (ACL)	42
13 Processes	43
13.1 Dispatcher	43
13.1.1 Process id (pid)	43
13.2 Dispatcher timestamps	44
13.3 Start	45
13.4 Stop	46
14 Localization	47
14.1 Add new language	48
15 Time zones and timestamps	49
16 IP address for streaming media	
17 Refresh methods / cronjob	49
18 Channels	52
19 OfficeRoute configuration	52
19.1 Load configuration file	
20 Debugging Freedom Fone	54

21 Appendix 1: Event data	56
21.1 Custom events	56
21.1.1 Leave-a-message	56
21.1.2 Monitor IVR	56
21.1.3 GSMopen::dump event	57
21.1.4 Officeroute	
21.2 Default FreeSWITCH events	59
21.2.1 Message	59
21.2.2 CHANNEL STATE	
21.2.3 HEARBEAT	
21.3 Building the Freedom Fone ISO	

## 1 Introduction

#### 1.1 What is Freedom Fone?

Freedom Fone is the result of four years of field experience with telephony information services for civil society. During the development of telephony services for small organizations, we quickly discovered that there was enough technology to build almost anything but voice remained difficult to use.

With Freedom Fone we have tried to provide basic but yet powerful voice services that allows bi-directional communication by the phone and that it is why we want to describe Freedom Fone as a voice Content Management System (vCMS).

With Freedom Fone, (mobile) phone users can leave audio messages and navigate audio content using their phone. System administrators can later on classify the audio feedback received and build new content.

Rather than presenting users with a million options to set up a telephony system, we have opted to design basic but powerful telephony applications that can be used with a great degree of flexibility. We have put special emphasis in the user interface and lowering the cost of interfacing with the GSM network.

Freedom Fone is built thanks to the power of several open source projects: FreeSWITCH, Spidermonkey, PHP5, Cake PHP MVC and Jquery. For those that want to automate the creation of audio we have included support for Cepstral, a text-to-speech voice engine capable of synthesizing voice messages.

Freedom Fone has been mostly tested using Ubuntu 10.04 LTS.

#### 1.2 Architecture

The Freedom Fone architecture is designed with modularity in mind, providing clear interfaces between the various components, to facilitate integration of new services and applications. Although Freedom Fone can run in one single computer, the architecture is designed to scale up if needed.

The main components of the system architecture are:




Illustration 1: Architectural design of Freedom Fone > 2.0.

Mobigater A single channel GSM gateway that manages incoming SMS and voice calls.

OfficeRoute A 4 channel SIP based GSM gateway that manages incoming SMS and voice calls.

FreeSWITCH PBX that routes incoming/outgoing calls and SMS. Interacts with the incoming dispatcher to feed data to the application layer.

Incoming Analyses FreeSWITCH events, matches data with Freedom Fone dispatcher applications and stores data into Spooler.

Spooler A MySQL database with one table per Freedom Fone application. The CakePHP application fetches spooler data regularly by use of a crontab job.

CakePHP The application layer consisting of CakePHP code and a SQL database. All interaction with the Administrator is done through this interface.

File storage Uploaded audio files used by Freedom Fone applications. Accessible by both CakePHP and FreeSWITCH.

Audio\_Bot A backend service that converts audio files between WAV and MP3 format

Sweeper A service that cleans up personal identifiable information from a running installation

## 2 Code structure

An installer for Freedom Fone is available here: http://www.it46.se/freedomfone/freedomfone 2S latest.tgz

The code is structured as follows:

audio_bot	Configuration files of the Audio Conversion engine (based on iwatch)
config	Shortcuts to all the main configuration files in each of the components
dispatcher_in	Code of the Incoming Dispatcher responsible of listening to Freeswtich events
cron	Configuration file for the crontab
esl	Code of the Event Socket Layer library, used by the dispatcher to communicate with FreeSWITCH
gui/app	Graphical User Interface code of Freedom Fone
gui/cake	Cake PHP MVC framework
110n	Localization files and scripts to migrate localization between versions
office_route	Code of the POP3 daemon that polls SMS received in the Office Route Backup of Office_Route for Freedom Fone
xml_curl	PHP code that delivers the dialplan and ivr XML files
rootconf	Extra configuration files for Apache2, Logrotate, Crontab, iwatch, init.d
deb_builder	Specific configuration tweaks to build FreeSWITCH for Freedom Fone. Includes Freedom Fone specific scripts, PHP ESL library, support for Cepstral, Office Route external gateway configuration, gsmopen endpoint and FreeSWITCH autoconf files.
sweeper	Code for the personal identifiable information (PII) sweeper
,dependencies	List of package dependencies for Ubuntu 10.04 LTS
*.sh	Auxiliary shell scripts used during the installation process including: fix_perms_all.sh: responsible to set up the correct permissions download_bin.sh: downloads all pre-compiled packages rootconf_install.sh: unpacks and install all the configuration files for rootconf components.
documentation	Documentation
demo	Demo data
INSTALL	How to install Freedom Fone from sources
	,

As part of the installation process the installer with download/upgrade several softweare packages and download specific FreeSWITCH packages built for the distribution.

Once Freedom Fone is installed, the code is structured in three main folders:

```
/opt/freedomfone (front-end)
/opt/freeswitch (back-end)
/opt/swift (text-to-speech back-end)
```

## 2.1 Installing

The following ten steps are needed to install Freedom Fone is a fresh Ubuntu 10.04 Linux distribution (i386, 32 bits)

#### 2.1.1 Install Ubuntu 10.04

Install Ubuntu 10.04-3 i386 Desktop edition, if you want to manage the box remotely you can consider installing the server edition instead.

#### 2.1.2 Install subversion

It is a good idea to install subversion so you can update your running installation if bug fixes are published.

```
# apt-get install subversion
```

#### 2.1.3 Download Freedom Fone installer

Using subversion checkout the installer (alternatively you can download a tar.gz from  $\underline{\text{http://www.it46.se/freedomfone/freedomfone}} \underline{\text{2S\_latest.tgz}}$ 

```
#mkdir -p /opt/freedomfone
#cd /opt/freedomfone; svn co https://dev.freedomfone.org/svn/freedomfone/branches/2.S/ .
#cd /opt/freedomfone; chmod 755 *.sh
```

#### 2.1.4 Install packages and dependencies

The software dependencies will allow you to run Freedom Fone and re-build freeswitch if

needed.

#cd /opt/freedomfone; ./download.sh

#### 2.1.5 Download pre-compiled packages for Freeswitch and Cepstral

```
#cd /opt/freedomfone; ./download bin.sh
```

At the end of this step you should have download four pre-compiled packages

```
Cepstral_Allison-8kHz_i386-linux_5.1.0.tar.gz
freeswitch_1.0.head-git.master.20110530.ffone-12_i386.deb
freeswitch-lang-en_1.0.head-git.master.20110530.ffone-12_i386.deb
freeswitch-spidermonkey 1.0.head-git.master.20110530.ffone-12_i386.deb
```

#### 2.1.6 Install Cepstral

Accept default values (/opt/swift as installation directory)

```
#cd /opt/freedomfone; tar zxvf Cepstral_Allison-8kHz_i386-linux_5.1.0.tar.gz
#cd /opt/freedomfone/Cepstral Allison-8kHz i386-linux 5.1.0; ./install.sh
```

#### 2.1.7 Install Freeswitch for Freedom Fone

```
#cd /opt/freedomfone; dpkg -i \
freeswitch_1.0.head-git.master.20110530.ffone-12_i386.deb \
freeswitch-lang-en_1.0.head-git.master.20110530.ffone-9_i386.deb \
freeswitch-spidermonkey_1.0.head-git.master.20110530.ffone-9_i386.deb
```

#### 2.1.8 Install rootconf

Rootconf that contains default configurations for PHP5, Apache2, iwatch, cron and startup services

```
#cd /opt/freedomfone; ./rootconf install.sh
```

#### 2.1.9 Install DB Schemas

```
#cd /opt/freedomfone; ./db_install.sh
```

If you want some demo data in the system run:

```
# cd /opt/freedomfone; ./demo install.sh
```

#### 2.1.10 Fix permissions

```
#cd /opt/freedomfone; fix perms all.sh
```

Rebooting your machine and point your browser to http://localhost/freedomfone

Username: Admin Password: thefone

## 2.2 Updating a running installation

A running installation can be updated by upgrading/reinstalling the freeswitch packages that bundle the Freedom Fone components or updating GUI code using subversion.

• If you need to update the FreeSWITCH bundle

```
#cd /opt/freedomfone; dpkg -i \
freeswitch_1.0.head-git.master.20110530.ffone-XX_i386.deb \
freeswitch-lang-en_1.0.head-git.master.20110530.ffone-10_i386.deb \
freeswitch-spidermonkey_1.0.head-git.master.20110530.ffone-10_i386.deb
#cd /opt/freedomfone; chmod 755 fix_perms_all.sh
#cd /opt/freedomfone; ./fix perms all.sh
```

Notice that the "XX" in the names of the packages need to replaced by the version number of the upgrade. In December 2011, the latest build was ffone-12.

• Other components of the system can be updated using Subversion.

Notice that subversion changes can alter the permissions, so you always need to re-run the fix perms scripts after any update.

#### 2.3 Passwords

If you plan to run a) Freedom Fone connected to the public Internet or b) have more than

one single user in the server, you need to change the default Freedom Fone passwords. You have been warned!

Your system is secure with the default password settings if no other user than the System Admin has access to the machine.

	DOI 1 C
/opt/freeswitch/conf/autoload_configs/event_socket.conf.xml	_
/opt/freedomfone/dispatcher_in/config.php	FreeSWITCH
/opt/freedomfone/office_route/config.php	ESL password for
	FreeSWITCH and Admin
	password for Office Route
/opt/freedomfone/dispatcher_in/config.php	Password for the API
	Callback service
/opt/freedomfone/dispatcher_in/config.php	Password for the
	dispatcher SQL databases
/opt/freedomfone/config/gui_config_core.php	Security Salt and
/opt/freedomfone/config/gui_config_database.php	Passwords for the spooler
/opt/freedomfone/config/gui_config.php	and freedomfone
	databases
/opt/freedomfone/config/officeroute_snmp_config.php	SNMP password to
	monitor Office Route

The setup script "db\_install.sh" is responsible to create all the databases and setup the access control to the different users in the SQL database. The script assumes that the default password of the root user of Mysql is blanck. <ENTER>

Edit the db install.sh to include your root password during installation if it is not blank.

## 3 FreeSWITCH

FreeSWITCH is the main backend component of Freedom Fone. The overall architecture of the backend can be summarized as follows:

FreeSWITCH receives voice calls using two main communication channels or endpoints: (1) gsmopen, a channel specifically designed to interface with low cost GSM serial modems and (2) sofia, a SIP implementation that interfaces any SIP-enabled peer like the 2N Office

Route GSM gateway<sup>1</sup>.

When a call arrives to Freedom Fone via any of the two communication channels, a call processing logic (dialplan) is requested to attend the call. FreeSWITCH requests the dialplan (a XML formatted file) by means of a HTTP request to a webserver (http://localhost/freedomfone/xml curl/)

If the caller is requesting a Leave-a-message service, a Javascript application is served. If the caller is accessing a IVR, we provide a XML IVR that FreeSWITCH can understand.

The following XML sections from the dialplan illustrate how the Leave-a-message application and IVR are called.

```
<!-- LEAVE A MESSAGE EXTENSIONS -->
    <condition field="destination number" expression="^2(\d{3})">
      <action application="ring_ready"/>
      <action application="answer"/>
      <action application="sleep" data="2000"/>
      <action application="set" data="lmIP=$${local ip v4}"/>
          <!--
          <action application="set" data="on_quick_hangup=accept"/> -->
<!--
      <action application="javascript" data="freedomfone/leave message/main.js ${instance id} ${ImIP}"/>
     </condition>
    </extension>
<!-- IVR -->
       <extension name="ivr pool">
     <condition field="destination number" expression="^4(\d{3})">
      <\!\!\!\text{action application} = \!\!\!\!\! "answer"/\!\!\!>
         <action application="ivr" data="freedomfone ivr ${instance id}"/>
     </condition>
    </extension>
```

The first section states that if the Caller is calling a 2000 extension, for example the 2102 extension, the leave-a-message application with identifier 102 will be invoked.

The second section states that if the Caller is calling a 4000 extension, for example the extension 4110, the IVR with identifier 110 will be invoked.

## 3.1 Building FreeSWITCH

From version 2.S (September 2011) it is not necessary to build FreeSWITCH from source to install Freedom Fone. We have built Debian packages of FreeSWITCH will all the

We have also successfully tested interfacing with the Skype network using the public Skype API

necessary dependencies.

If you plan to create or update the Debian packages in the future and have some previous experience building Debian packages, you need to consider the following hints:

- Modify the default modules.conf of FreeSWITCH to include non standard components as xml curl, gsmopen and cepstral.
- Build and pack the PHP ESL library (libs/esl/php) as this library is not built by default
- You need to change the default values of the following configuration files (autoconf/conf): xml\_curl.conf.xml, event\_socket.conf.xml, gsmopen.conf.xml, cepstral.conf.xml
- Include the Freedom Fone IVR and Leave-a-message scripts in the scripts folder of FreeSWITCH
- Hack the build process (debian/shlibs.local) so you can build FreeSWITCH including the Cepstral module without satisfying the package dependencies (ibswift 5 libc6)
- You will need to modify the default init, conf and postinst scripts

Configuration files of the customized build process are available under /opt/freedomfone/deb builder

## 3.2 Text-to-speech support

Freedom Fone has built in support for the commercial Cepstral Text-to-speech. As we can not package Cepstral as a Debian package, you will need to Download and install Cepstral before proceeding with the installation.

If you wish to run different voices that "Allison", download the desired voice bundle from Cepstral. Do not forget to pick always the 8 Khz voice.

The easier way to enable a new voice is to remove the all one from the system. A comprehensive FAQ is available here:

http://cepstral.com/cgi-bin/support?page=faq&type=i386-linux

With small modifications to Freedom Fone, a free TTS engine like Flite<sup>2</sup> can be used.

.

<sup>&</sup>lt;sup>2</sup> http://wiki.freeswitch.org/wiki/Mod flite

## 4 The Incoming dispatcher

### 4.1 FreeSWITCH events

The incoming dispatcher communicates with FreeSWITCH by subscribing and listening to a set of FreeSWITCH events. In Freedom Fone 2.0, the incoming dispatcher is subscribed to the following events:

Event-Name	Event-Subclass	Application
CUSTOM	leave_a_message	Leave-a-message
CUSTOM	monitor_ivr	IVR monitoring
CUSTOM	gsmopen::dump_event	Monitor Mobigater channels
CUSTOM	officeroute	Incoming SMS from OfficeRoute
MESSAGE		Incoming SMS from Mobigater. "SMS" from Skype
CHANNEL_STATE		Call data records (CDR)
HEARTBEAT		Dispatcher (is FreeSWITCH alive)

Table 1 : FreeSWITCH events for Freedom Fone 2.0

Custom events are events specific to Freedom Fone, such as leave-a-message and monitor\_ivr.

 $\boldsymbol{Message}$  events are standard FreeSWITCH events, such as incoming SMS or Skype chat messages

*Channel\_State* events are CDR details for an incoming call. One single call generators a number of CHANNEL\_STATE events.

**Heartbeat** events are used by FreeSWITCH to announce that FreeSWITCH is alive and running. A heartbeat is sent out every 20 seconds. If the dispatcher does not receive a heartbeat event within 25 seconds, it assumes that FreeSWITCH is not running. The dispatcher keeps running, and tries to re-connect to FreeSWITCH every 5 seconds.

## 4.2 Dispatcher state machine

This section describes the state machine of the dispatcher.

The illustration below shows the various Rules (orange) and Actions (pink) of the dispatcher logic.




Illustration 2: State machine of incoming dispatcher.

The dispatcher starts by checking if there is any instance of the dispatcher already running. If it finds a running dispatcher, the script exits. If not, it continues to write data (process id, timestamps, version number) to files accessible to the application layer.

Next, the dispatcher tries to connect to FreeSWITCH (Checkpoint 1). If the dispatcher does not manage to establish a connection to FreeSWITCH (meaning that FreeSWITCH is not running), the scripts waits 15 seconds, and then tries again. If the connection is successfully established, the dispatcher continues and connects to the MySQL database (the spooler database).

Thereafter, the dispatcher subscribes to the events described in Section 2,1. Next, it enters a loop that, as long as a connection to FreeSWITCH is open (Checkpoint 2), waits for incoming events and processes them. If FreeSWITCH is not running (or a connection can not be established), the dispatcher exits the loop and waits 15 seconds until it tries again (Checkpoint 1).

Installation & Developers Guide Author: Louise Berthilson, Alberto Escudero-Pascual

Event arrives from FreeSWITCH to the dispatcher in XML format. The dispatcher applies a filter<sup>3</sup> of blacklisted events to the XML data. If the event is confirmed to be blacklisted, it is ignored, and the dispatcher returns to Checkpoint 2. At the moment, a number of CHANNEL STATE events<sup>4</sup> are blacklisted.

Next, depending of the Event-Type and Event-Subclass of the event, a XSL template<sup>5</sup> is applied to the XML file, in order to filter out the data needed for the application, and drop the rest of the data.

Next, a set of rules are applied to the XML output in order to match the event with a certain application. If the data can not be matched to an application, the dispatcher returns to Checkpoint 2. This should in theory not happened.

If a matching application is found (default scenario), the event data is parsed to an SQL query and inserted into an application specific table in the spooler (in) database.

The CakePHP application fetches data from the spooler using the spooler API (spooler\_ff.php). This is done automatically five minutes, by means of a cronjob. The administrator of the system can made a manual refresh from the dispatcher, but using any of the Refresh buttons in the GUI.

The event data is finally inserted in the Freedom Fone database, which is a part of the CakePHP application.

The filter is an XSL template (/opt/freedomfone/dispatcher in/templates/blacklist.xsl)

<sup>&</sup>lt;sup>4</sup> Blocked events are: CS NEW, CS INIT, CS EXECUTE, CS HANGUP, CS REPORTING

<sup>&</sup>lt;sup>5</sup> Located at: /opt/freedomfone/dispatcher in/templates/

#### 5 Poll

The Poll application allows end users to send SMSs to Freedom Fone and participate in polls. The administrator of the system is allowed to Create, Read, Update, and Delete polls.

Several polls can be active at the same time, over the same GSM trunk.

## 5.1 Event data and dispatcher

- 1. An incoming SMS reaches a Mobigater/OfficeRoute unit, which transfers the data to FreeSWITCH.
- 2. The SMS is captured by FreeSWITCH, which creates a *message event* containing the SMS information. If the SMS comes from an Mobigater, a FreeSWITCH native "message" event in created. If the SMS comes from an OfficeRoute unit, a customized message event is created (see Table 1).
- 3. The event is captured by the incoming dispatcher and is analysed to be matched with an application. Once a matching application is found, the data is parsed to SQL and inserted into the incoming spooler database.

  If the SMS consists of "two separate words", it is matched to the application Poll (table: poll in). If not, it is classified as an incoming SMS (table: bin).
- 4. Freedom Fone (GUI) is configured to run a crontab to execute the CakePHP method "refresh". This method can also be executed manually by pointing the browser to http://<your-domain>/freedomfone/polls/refresh

The refresh method fetches *new entries* from the incoming dispatcher (from poll\_in), apply application specific logics, and insert the data in one or more tables (polls, votes) of the Freedom Fone database (freedomfone).

## 5.2 Poll specific logics

The refresh method for the poll application is responsible for two key actions; register new poll votes and keep track of existing polls status.

The business logics of the refresh method looks for the poll code (code) and the poll answer (chtext) to determine what to do with the data.




Illustration 3: State machine of incoming SMS and poll votes.

#### Rule 1: Poll code

#### 1. No match: Incorrect vote

If the poll code does not match an existing poll, the vote is classified as Incorrect. The SMS data is stored as "Incoming SMS".

#### 2. Match: Correct vote

If the poll code matches an existing poll, it is classified as *Correct vote*.

#### Rule 2: Poll answer

Rule 2 is only applied to correct votes.

#### 1. No match: Invalid vote

If the poll answer does not match any poll option, the vote is classified as Invalid vote.

#### 2. Match: Valid vote

If the poll code matches an existing poll option for the specific poll, the vote is classified as Valid vote.

#### Rule 3: Time of arrival

Rule 3 is applied to both valid and invalid votes. A vote is classified as Early, In Time or Late depending on the time of process (when the Freedom Fone application fetches the data from the spooler).

Hence, if the GSM modem has been switched off, or the Freedom Fone server has been down while users have been voting for a poll, their votes will have a timestamp that does not reflect the time when the actual SMS was sent.

#### 1. Early

The vote arrived before the poll was opened. If the vote is valid, it will be registered as "Early vote" for that specific poll option. If the vote is invalid, it will be registered as "Invalid / Early Votes". None of these votes will be a part of the statistics.

#### 2. In time

The vote arrived while the poll was open. Both valid and invalid votes will be a part of the statistics.

#### 3. Late

The vote arrived after the poll was closed. If the vote is valid, it will be registered as "Late vote" for that specific poll option. If the vote is invalid, it will be registered as "Invalid / Late Votes". None of these votes will be a part of the statistics.

The refresh method is also responsible for keeping the status updated for all polls. If the current time is greater (later) than the closing time (end\_time) for a poll, its status is changed to "closed".

#### 5.3 Database structure

The Poll application uses two database tables, Polls and Votes.

#### 5.3.1 Polls

The **Polls** table handles the individual polls configuration options such as: polls question, SMS code, time of creation, start time, end time and status (active/closed). Each poll is identified with an id.

The Polls table registered invalid votes (correct poll code, incorrect poll option). Invalid votes can be in time (invalid\_open), early (invalid\_early) or late (invalid\_closed).

The *code* must be unique, to be able to match an incoming SMS with the correct poll.

This constraint is managed by PHP, not MySQL.

Field	Туре	Кеу	Null
id	int(10) unsigned	Primary	NO
question	varchar(200)		NO
code	varcher(10)		NO
created	int(10) unsigned		NO
start_time	datetime		YES
end_time	datetime		YES
status	tinyint(4)		YES
invalid_open	int(10) unsigned		YES
invalid_closed	int(10) unsigned		YES
invalid_early	int(10) unsigned		YES

#### 5.3.2 Votes

The **Votes** table matches incoming votes with existing polls, and presents statistics to the user. Each entry in the Votes table represents one poll option (chtext) for a specific poll (poll\_id) and the number of votes it has received. Votes are classified as early (votes\_early), in-time (chvotes) or late (votes\_closed) depending on their time of arrival.

Only valid votes (correct poll code and poll option) are registered in the Votes table. Invalid votes are registered in the Polls table.

Field	Туре	Key	Null
id	int(10) unsigned	Primary	NO
poll_id	int(10) unsigned		NO
chtext	varcher(128)		YES
chvotes	int(10) unsigned		YES
votes_closed	int(10) unsigned		YES
votes_early	int(10) unsigned		YES

The *poll\_id* (poll) in combination with *chtxt* (poll answer) must be unique. This restriction is implemented in CakePHP (not MySQL).

## 5.4 Admin functionality

The administrator have access to the following functionality:

- 1. Create, Read, Update and Delete (CRUD) polls
- 2. View statistics for each poll
  - 1. total number of valid and invalid (in-time, early and late) votes
  - 2. votes per poll option
  - 3. percentage per poll option

## 5.5 Logging

All incoming votes to the poll application is logged (poll.log<sup>6</sup>). The votes are logged as follows:

Action	Message
Correct poll code and poll option	Valid {early, open,closed}
Correct poll code, incorrect poll option	<pre>Invalid {early, open,closed}</pre>
Incorrect poll code	Unclassified

For each action, these parameters are logged:

Field	Value
Message	See table above
Body	SMS body
From	Sender number
Timestamp	Time of arrival to Freeswitch

\_

 $<sup>^{6}</sup>$  Log are found at: /opt/freedomfone/gui/app/tmp/logs/

## 6 Leave a message

## 6.1 Event data and dispatcher

- 1. An incoming voice call enters the system by a GSM gateway (Mobigater/OfficeRoute), and is transferred to the dialplan of Freeswitch.
- 2. The dialplan executes a Javascript file that manages the Leave-a-Message IVR menu. FreeSwitch stores the recorded message in a file system, which can be local or remote.
- 3. Freeswitch creates a customized event containing information about the event, such as start time, end time, sender, and file name. The event is captured by the incoming dispatcher, which matches the data with a set of rules, identifies the application, and filter out the necessary data fields. The relevant data fields are inserted into the spooler (table lm in).
- 5. Freedom Fone is configured to run a crontab (every 5 min) to execute a refresh method for the Leave-a-message application. The refresh method fetches new data from the spooler and applies application specific logics to the information. Finally is stores the "refined" data in one or more SQL tables (messages) in the CakePHP database (freedomfone).

## 6.2 Leave-a-message specific logics

The refresh method of Leave-a-Message is responsible for fetching new data from the spooler (lm\_in), apply application specific logics to the data, and store the refined data in table messages.

Most of the data is a one-to-one matching between the spooler and the CakePHP table. However, the refresh method calculates the length of the messages by calculating the difference between the end time of the call, and the start time of the call.

The refresh method is responsible for logging all incoming messages.

## 6.3 Admin functionality

#### 6.3.1 Manage messages

A message is defined by a set of attributes. The table below lists the attributes with a description and an indication of what data is editable by the administrator.

Attribute	Description	Editable
Title	Title (defined by administrator)	Yes
Sender	Caller ID	
Rate	1-5	Yes
Category	Reference to entry in Category table	Yes
Tag	Tag names (one or more options)	Yes
File	File name of audio message	
URL	Absolute path to audio message	
New	Read or unread (boolean)	
Status	Inbox or archive	Yes
Length	Length of file in sec	
Created	Timestamp of incoming message	
Modified	Timestamp of last edit	Yes
Instance	Instance of the Leave-a-message service	
User	Reference to entry in Users table	
Comment	Administrators comment to message	Yes
Quick hangup	Yes / No	

#### The administrator can

- 1. Read, Update and Delete any message.
- 2. Sort messages by Status, Title, Rate, Length, Category, Created and Modified.
- 3. Listen to any message via a built in flash audio player.
- 4. Download audio file (.mp3)
- 5. Move messages between Inbox and Archive
- 6. Navigate between message with pagination
- 7. Delete or Archive<sup>7</sup> multiple messages at a time, using check boxes.
- 8. Create, Read, Update and Delete categories.
- 9. Create, Read, Update and Delete tags.

<sup>&</sup>lt;sup>7</sup> Archives messages can in the same way be moved back to the Inbox again.

#### 6.3.2 Leave-a-message instances

Freedom Fone 2.0 allows the administrator to create multiple Leave-a-message instances (maximum 20 instances). Each Leave-a-message instance will have and instance id in the range of 2100-2119. This instance id (aka Service) is important when mapping GSM trunks to a specific service. More about that in Section 17 (OfficeRoute).

All files belonging to an instance of a Leave-a-message are stored under:

/opt/freedomfone/gui/app/webroot/freedomfone/leave message/{instance id}

The folder contains three sub-directories:

#### 1. audio menu

Contains audio files (mp3/wav) of the Leave-a-message IVR

#### 2. conf

100.conf: Text-to-speech options created by user through the GUI 100\_core.conf: default base directory for application (do not edit) default.conf: fallback text for Text-to-speech (may be edited)

#### 3. messages

Contains audio files (mp3/wav) and a meta file of each message left by a user

#### 6.3.3 Leave-a-message structure

A Leave-a-Message IVR consists of eight voice messages. Each voice message (Step 1-8). Each voice messages can be either:

- 1. An audio file uploaded by the administrator (mp3/wav) OR
- 2. A text message set by the administrator synthesised by Cepstral OR
- 3. A fallback text message (defined in default.conf) synthesised by Cepstral

The prioritization between audio files, text messages and fallback text is illustrated below.




Illustration 4: Prioritization of audio files, text messages and fallback text in Leave-a-message.

The eight audio messages have the following fallback text which can be modified in default.conf.

- 1. Welcome: Welcome to Freedom Fone!
- 2. Inform: Record your message after the beep. To Finish, Press #
- 3. Select: To Play... press \*. To Delete... press 0. To Save... press 1.
- 4. Delete: Your message has been deleted.
- 5. Save: Thank you.
- 6. Goodbye: Goodbye.
- 7. Long: You talk to much. Keep it simple.
- 8. Invalid: Invalid option. Please try again.

## 6.4 Leave-a-message IVR architecture

The state machine of the IVR menu is designed as according to the illustration below. By using the buttons star (\*), hash (#), zero (0) and one (1), the user can manoeuvre between the different stages.

The IVR menu allows the end user to:

- 1. Record a message
- 2. Listen to a message
- 3. Delete a message (that was just recorded)
- 4. Save a message

The system have a time-out for long messages. The maximum message duration can be set by the administrator for each Leave-a-message instance. The default value is 120 seconds.




Illustration 5: State machine of Leave-a-message IVR.

#### 6.5 Database structure

The Leave-a-message application uses five database tables, messages, categories, tags, messages tags, and lm menus.

## 6.5.1 Table: messages

The table messages stores data regarding each message left. It has a one-to-many relationship with categories, and a many-to-many relationship with tags.

The filename must be unique in order to distinguish one audio file from another. The filename is created by FreeSWITCH.

Field	Туре	Кеу	Null
id	int(11) unsigned	primary	NO
instance_id	int(6)		NO
sender	varchar(200)		NO
title	varchar(200)		NO
rate	smallint(6)		
file	varchar(200)	unique	NO
category_id	int(11) unsigned		
created	int(11) unsigned		NO
modified	int(11) unsigned		
url	varchar(100)		
new	tinyint(1)		
status	tinyint(4)		
length	int(11)		
user_id	int(11)		
comment	varchar(300)		
quick_hangup	varchar(10)		

#### 6.5.2 Table: categories

The categories table contains name and description of categories.

Field	Туре	Key	Null
id	int(11) unsigned	primary	NO
name	varchar(100)	unique	NO
longname	varchar(200)		NO

## 6.5.3 Table: tags

The tags table contains name and description of tags.

Field	Туре	Кеу	Null
id	int(11) unsigned	primary	NO
name	varchar(100)	unique	NO
longname	varchar(200)		NO

## 6.5.4 Table: $messages\_tags$

This table manages the many-to-many relationship between messages and tags.

Field	Туре	Key	Null
id	int(11) unsigned	primary	NO
message_id	int(11) unsigned		
tag_id	int(11) unsigned		

## $6.5.5 \quad Table: lm\_menus$

This table stores the user defined options and texts of the Leave-a-message IVR menu for a certain instance.

Field	Туре	Key	Null
id	int(11) unsigned	primary	NO
instance_id	smallint(6)	unique	NO
title	varchar(50)		
created	int(11)		NO
modified	int(11)		NO
lmWelcomeMessage	text		
lmInformMessage	text		
lmInvalidMessage	text		
lmLongMessage	text		
lmSelectMessage	text		
lmDeleteMessage	text		
lmSaveMessage	text		
lmGoodbyeMessage	text		
lmForceTTS	tinyint(4)		Default: 0
lmMaxreclen	int(6)		Default: 120
lmOnHangup	varchar(20)		Default: accept

Installation & Developers Guide Author: Louise Berthilson, Alberto Escudero-Pascual

For each instance of Leave-a-message, the administrator can (through the GUI) set:

- 1. maximum recording length (int lmMaxreclen)
- 2. Do not use uploaded files (bool lmForceTTS<sup>8</sup>)

The variable lmOnHangup refers to the action of a user hanging up after leaving a message without pressing # and follow the instructions how to save the messages.

By default, lmOnHangup is set to 'accept', which implies that the system allows quick hangup (the messages are stored). Even though quick hangup is accepted, the advanced functionality with store, save, delete is still active.

To ignore calls that are terminated with quick hangup, the default value of lmOnHangup in table lm menus must be changed to "delete".

25

.

<sup>8</sup> lmForceTTS(true = ignore uploaded files, force TTS; false = use uploaded files)

## 7 IVR (Interactive voice menus)

Freedom Fone offers the possibility for the Administrator to build customized IVRs based on personal audio files, or synthesized text messages. IVR's can be of two different kinds:

- 1. Language Selector OR
- 2. Voice Menu

The system allows the creation of a total of 20 IVRs. These IVR's can be either Language Selectors or Voice Menus.

## 7.1 Language selector

A language selector is intended to be used as a top level IVR in a nested IVR. It should provide the caller two or more options depending on its language preferences. Ideally, each language branch should be composed of the same services (Voice Menu, Content, Leave-a-message), but in different languages.

A language selector composes of a title (only used in the GUI to identify a selector), two menu instructions, and a set of Services.

The menu instructions are

- 1. Instructions (For English... press 1. For Swahili....press 2.)
- 2. Invalid (Invalid option, please try again

A menu instruction can either be an audio file (mp3/wav) or a text message that is synthesised with Cepstral. If both and audio file and a text message is provided, the audio file is selected. If neither an audio file nor a text message is provided, a default fallback message will be played.

A Language Selector can link to 8 different services. A service can either be a Voice Menu, Content, or a Leave-a-message service.

A Language Selector can be created, edited and deleted by the Administrator.

#### 7.2 Voice menus

A Voice Menu consists of:

- 1. four *menu instructions* (Welcome, Instructions, Goodbye and Invalid)
- 2. one or more (max 8) pointers to **services**

Just like the Leave-a-message IVR, a Voice Menu menu instruction can be either an audio file, a text message or a fallback text. The same prioritization rules applies on Voice

Menus, except that the option of ignoring uploaded files does not exits.

A Service can either be

- 1. Leave-a-message OR
- 2. Voice Menu
- 3. Content

The administrator can at any time edit a Voice Menu (changing menu instructions and services).

The design of a Voice Menu is illustrated below.




Illustration 6: State machine of a Voice Menu.

Assuming you have created a Voice Menu with 8 services, pressing any number between 1-8 will transfer you to that specific service. Pressing 0, will take you to the Goodbye message and the phone call will be terminated. Pressing 9, will take you back to the instruction message. Pressing any other key, will take you to the Invalid messages, and then back to the Instructions.

Assuming that you have selected a Content Service. Once you have finished listening to the Content, you will be re-directed back to the Instruction message. If you of some reason do not want to finish listening to the Content, you can press any number, and you will be re-directed to the Instruction.

If you select a Leave-a-Message service, the phone call will automatically be terminated after the message has been left. It is not possible to get back in to the Voice Menu, once that you have selected the Leave-a-message Service.

If you select another Voice Menu as a Service, you will be redirected to its Welcome Message.

#### 7.3 Database structure

Field	Туре	Null	Comment
instance_id	int(6)	NO	{100-119}
title	varchar(200)	NO	
message_long	Text		TTS message
message_short	Text		TTS message
message_exit	Text		TTS message
message_invalid	Text		TTS message

file_long	Text		Original file name
file_short	Text		Original file name
file_exit	Text		Original file name
file_invalid	Text		Original file name
mode_long	tinyint(1)	Default: 0	1= Ignore uploaded file
mode_short	tinyint(1)	Default: 0	1= Ignore uploaded file
mode_exit	tinyint(1)	Default: 0	1= Ignore uploaded file
mode_invalid	tinyint(1)	Default: 0	1= Ignore uploaded file
switcher_type	varchar(50)	NO	{ivr,lam}
ivr_type	varchar(50)	NO	{ivr,switcher}

## 7.4 Mapping of services

To map services with digits pressed by the user, the table "Mappings" is used.

The Mappings table requires that ivr\_menu\_id (unique id for the ivr) in combination with digit (digit pressed by user {1-8}) must be unique.

Each IVR (language selector or Voice Menu) has by default eight entries in the Mappings table. If not all digits are assigned to a Service, the entry (type, node\_id, lam\_id, ivr\_id, instance\_id) is empty.

Field	Туре	Кеу	Comment
ivr_menu_id	int(11)	MUL	
type	varchar(10)		{node,ivr,lam}
digit	int(6)	MUL	{1-8}
node_id	int(11)		
lam_id	int(11)		
ivr_id	int(11)		
Instance_id	int(11)		Of node_id or lam_id

## 7.5 Nested menus

The illustration below shows a four level nested menu that includes all (four) building blocks. Studying the Voice Menus, shows how the commands #0 and #9 affects the IVR depending on where in the tree structure they are executed.

#9 takes the caller back to the top level, while #0 takes her one step up in the tree.




Illustration 7: An example of a nested menu consiting of all types of services.

#### 7.6 Instances

The administrator can create multiple instances of IVR's (Language Selectors and Voice Menus). The system allows up to 20 instances. They will be assigned a instance\_id in the range 100-119.

All audio files (mp3/wav) that belong to an IVR are found at:

/opt/freedomfone/gui/app/webroot/freedomfone/ivr/{instance id}/ivr/

Each IVR has its own ivr.xml file, that contains instructions to FreeSWITCH how to route call within that specific IVR. The ivr.xml file is updated every time the IVR is edited. The XML file is located at:

/opt/freedomfone/gui/app/webroot/freedomfone/ivr/{instance id}/conf/ivr.xml

The system comes pre-equipped with 20 empty folders ready to host IVRs. For example:

root@lupinus:/opt/freedomfone/qui/app/webroot/freedomfone/ivr/# tree

Installation & Developers Guide Author: Louise Berthilson, Alberto Escudero-Pascual

When an IVR is deleted, the corresponding conf and ivr folders are emptied from content, but the directories ({instance id},conf and ivr) are left.

When a new IVR is created, it is being assigned the lowest instance\_id available in that range 100-119.

#### 7.7 IVR.XML

The ivr.xml file contains instructions to FreeSWITCH how an IVR should behave as a result of user input.

Freedom Fone 2.0 implements a two-level ivr.xml structure. First, each IVR has its **individual** ivr.xml file, describing only its own behaviour. Secondly, the system has a **main** ivr.xml file that contains all IVR's (language selectors and voice menus) XML code.

The main ivr.xml file is located at:

#/opt/freedomfone/gui/app/webroot/xml curl/ivr.xml

The main ivr.xml file is composed by:

- 1.  $core.xml^9$
- 2. all individual ivr.xml files<sup>10</sup>

Whenever an individual IVR is created, added or deleted, the main ivr.xml file is updated.

All ivr.xml files are created by the Vendor  $:: ivr\_xml^{11}$ 

\_

<sup>&</sup>lt;sup>9</sup> Located at: /opt/freedomfone/gui/app/webroot/xml curl/core.xml

 $<sup>^{10} \</sup>quad Located \ at: /opt/freedomfone/gui/app/webroot/freedomfone/ivr/\{instance\_id\}/conf/ivr.xml$ 

Located at: /opt/freedomfone/gui/app/vendor/ivr xml.php

## 8 Content

A Content item is an audio file associated with a Title. There is no limit in the number of Content items the administrator can create.

Content can be used as a Menu Option in a Language selector or a Voice Menu. A Content item does not belong to a certain IVR, but can be present in multiple IVR.s

Audio files that belongs to Content items are found at:

#/opt/freedomfone/gui/app/webroot/freedomfone/ivr/nodes

A Content item that is present in one or more IVR's, can not be deleted. To delete a Content item, the administrator must first make sure that the Content is not a menu option in any IVR.

Field	Туре	Key	Null
id	int(11) unsigned	PRIMARY	NO
title	varchar(200)		NO
file	varchar(100)	UNIQUE	NO
duration	int(11) unsigned		Default: 0
created	int(11) unsigned		NO
modified	int(11) unsigned		Default: 0

## 8.1 Interaction with FreeSWITCH

The Voice Menu application interacts with FreeSWITCH in two ways;

- 1. it provides an XML file representing all existing voice menus for that instance
- 2. it provides audio files and/or text messages to be used in the Voice Menu

# 9 The IVR XML dialplan

## 9.1 Dialplan actions

Each entry in the XML dialplan has an action defined. The actions that Freedom Fone are taking advantage of, are the following:

- menu-exec-app: execute a FreeSWITCH dialplan application
- · menu-sub: load a sub-menu
- menu-back: return to the calling menu level
- menu-top: return to the top level menu

Please see FreeSWITCH Wiki for a full documentation of its IVR functionality<sup>12</sup>.

## 9.2 Freedom Fone example code

This XML file shows the instructions for Voice Menu 4102 (light blue). The Voice menu has five (1-5) menu options and two (0,9) default options common to all IVRs (orange).

Option 1-3 are Content items that are executed by using action "menu-exec-app" together with the parameter "play\_and\_get\_digits" (yellow).

Option 4 is a re-direction to another IVR menu (103), which is is reached by the action "menu-sub" and the name of the IVR (freedomfone\_ivr\_{instance\_id}) as parameter (turquoise).

Option 5 is a transfer to a Leave-a-Message (instance 100) service (green).

For each menu option there is a command that executes a Javascript (pink)<sup>13</sup> that monitors the options made by the caller.

<sup>&</sup>lt;sup>12</sup> FreeSWITCH IVR: http://wiki.freeswitch.org/wiki/Misc. Dialplan Tools ivr

For simplicity, this code has only been highlighted for menu option 1.

#### 9.3 Content

The FreeSWITCH action "menu-exec-app", together with the parameter "play and get digits" is used to execute a transfer to a Content item (node).

```
<entry action="menu-exec-app" digits="1" param="play_and_get_digits 1 1 1 1000 #
$${base_dir}/scripts/freedomfone/ivr/nodes/1292926356_file1.wav "/>
```

The parameters of the command "play and get digits" are the following:

- 1. Min: minimum number of digits to fetch (default 1)
- 2. Max: maximum number of digits to fetch (default 1)
- 3. Tries: numbers of tries for the sound to play (default 1
- 4. Timeout: number of milliseconds to wait once the file is done playing before you type a digit (default 1000)
- 5. Terminators: digit(s) used to end input if less than <min> digits have been pressed (default #)
- 6. File: sound file to play while digits are fetched
- 7. Invalid File: sound file to play when digits don't match the regular expression (not in use)

## 9.4 Voice Menu (IVR)

The FreeSWITCH action "menu\_sub" is used to transfer from one IVR to another. The action takes only one parameter, which is the name of the IVR to be transferred to.

```
<entry action="menu-sub" digits="4" param="freedomfone ivr 103"/>
```

The name of an IVR can be found in the "menu" tag (attribute = "name") of its individual ivr.xml file.

```
<menu name="freedomfone ivr 103" >
```

## 9.5 Leave-a-Message

The FreeSWITCH action "menu-exec-app" together with the command "transfer" is used to reach a Leave-a-Message service.

```
<entry action="menu-exec-app" digits="5" param="transfer 2100 XML default"/>
```

In this example, pressing digit 5 will transfer the caller to instance 100 of Leave-a-Message.

The command transfer takes the following parameters:

- 1. Extension (2 + instance id)
- 2. Dialplan ("XML")
- 3. Context ("default")

## 9.6 Default IVR options

By default, every IVR offers the caller to:

- 1. Go to the root IVR (#9)
- 2. Go to the instructions of the current IVR (#0)

These transfers are executed by the actions "menu-top" and "menu-back"

```
<entry action="menu-top" digits="9"/>
<entry action="menu-back" digits="0"/>
```

# 9.7 Monitoring of Voice Menus

For every selection made by a user that transfers them to a Service (not pressing 0 or 9 or any invalid option), a customized Java-based script<sup>14</sup> is executed.

```
<entry action="menu-exec-app" digits="1" param="javascript
    $${base_dir}/scripts/freedomfone/monitor_ivr/main.js ${uuid} 'Swedish' '1' '1' 'Node'
    '${caller_id_number}' '${destination_number}'"/>
```

<sup>&</sup>lt;sup>14</sup> Located at: /opt/freedomfone/freeswitch/scripts/freedomfone/monitor ivr/main.js

The Javascript is taking the following parameters:

Parameter	Comment	Event
IVR ID	Id of current IVR	FF-IVR-Unique-ID
IVR Name	Title of current IVR	FF-IVR-IVR-Name
IVR Digit	Digit pressed	FF-IVR-IVR-Node-Digit
Service ID	Id of service transferred to	FF-IVR-IVR-Node-Unique-ID
Service type	{Node/Lam/IvrMenu}	FF-IVR-IVR-Node-Service-ID
Caller	Caller's Caller ID	FF-IVR-Caller-ID-Number
Destination number	Number/extension called by user	FF-IVR-Destination-Number

The scripts generates a custom FreeSWITCH event called "monitor\_ivr", that the dispatcher processes and makes available to the Freedom Fone application (CakePHP).

Please see Appendix 1 for event details.

### 10 Audio tricks

## 10.1 On-the-fly audio conversion (iWatch)

By means of iWatch, the system is monitoring audio folders and converts mp3-files to wavfiles, and vice-versa as they are uploaded.

The iWatch component is located at:

#/opt/freedomfone/audio bot/iwatch

If the number of instances allowed for IVR and Leave-a-Message is increased, the iwatch.xml file must be modified accordingly.

#### 10.2 File duration

After any audio file is uploaded, but before the data is saved to the database, a script called wavDuration(\$file)<sup>15</sup> is executed, which calculates the duration of the file. The script takes a file in wav-format, and returns the length of the file in seconds.

The script is third party code<sup>16</sup>, but has been slightly modified to fit our needs.

#### 10.2.1 Known issues

This scripts assumes that the file is encoding in pure WAV format (which all WAV files should be). The length of a file is calculated based on information stored in the file's header. A non-pure WAV files does not store its header information in the same format as a pure WAV. Hence, the length of the file can not be calculated. Since there are a large number of non-pure WAV formats, we can not support all scenarios.

If the administrator is experience that uploaded audio files are presented as 0seconds long, they should make sure that the audio file are encoded in pure WAV.

Located in: usr/local/freedomfone/gui/app/app controller.php

<sup>&</sup>lt;sup>16</sup> Source: http://snipplr.com/view/285/read-wav-header-and-calculate-duration/

# 11 Call data records (CDR)

CDR are used in the application layer for reporting of incoming calls.

## 11.1 CDR event types

For each incoming call to the system, FreeSWITCH generates a number of CDRs. Each call generators at least one event of every type:

- · CS NEW
- CS INIT
- · CS ROUTING
- CS EXECUTE
- CS HANGUP
- CS REPORTING
- · CS DESTROY

The dispatcher is programmed to fetch *only* the CS\_ROUTING and CS\_DESTROY events, and store them in the spooler. All other CHANNEL-STETE events are dropped.

The structure of CS\_ROUTING and CS\_DESTROY events an incoming call generates, differs depending the channel in use (SIP, GSM, Skype, SkypeOut). Some channels generators multiple CS\_ROUTING event, that contains different caller unique information. Hence, when the application layer fetches new CDR from the spooler, some channel unique logic must be applied to the data, before it can be saved in the database.

The CakePHP file /models/cdr.php manages all CDR logic.

The tables below shows what action should be taken for CS\_ROUTING and CS\_DESTROY events for each channel.

- The action "insert" implies insertion of the event data to the freedomfone database.
- The action "ignore" implies to drop the event data.

If should be noted that calling in via GSM using OfficeRoute generates SIP CDR since the device is a GSM-SIP gateway. Calling in via a Mobigater generates CDR of type GSMopen.

# $11.1.1 \quad CS\_ROUTING$

x= service extension  $\{2 = \text{Leave-a-message}, 4 = \text{IVR}\}\$  iid = instance id  $\{100 - 119\}$ 

Channel	Channel-Name	Answer-State	Caller-Destination-Number	Action
GSMOpen	<pre>gsmopen/interface{x}</pre>	Ringing	5{iid}	Ignore
GSMOpen	gsmopen/interface{x}	Ringing	{x}{iid}	Ignore
GSMOpen	gsmopen/interface{x}	Answered	{x}{iid}	Insert
SkypeOut	gsmopen/interface{x}	Ringing	5{iid}	Ignore
SkypeOut	gsmopen/interface{x}	Ringing	{x}{iid}	Ignore
Skype0ut	gsmopen/interface{x}	Answered	{x}{iid}	Insert
Skype	skypeopen/interface{x}	Answered	{x}{iid}	Insert
SIP	sofia/internal/{a-z0-9}	Ringing	{x}{iid}	Insert

# 11.1.2 CS\_DESTROY

Only one CS\_DESTROY message is created per incoming call and channel type. Hence, all CS\_DESTROY messages from the spooler is saved to the freedomfone database.

Channel	Channel-Name	Answer-State	Caller-Destination-Number	Action
GSMOpen	gsmopen/interface{x}	Answered	NULL	Insert
SkypeOut	gsmopen/interface{x}	Answered	NULL	Insert
Skype	skypeopen/interface{x}	Answered	NULL	Insert
SIP	sofia/internal/{a-z0-9}	Answered	NULL	Insert

### 11.2 Statistics

The statistics page shows the number of incoming calls to each type of service. The statistics are based on Call Data Records. If a CDR for an incoming call is deleted, it will not show up in the statistics.

Each CDR is mapped to an application based on the "application" field in the Cdr table.

The field "application" can have the following (4) values:

- 1. lam
- 2. ivr
- 3. poll
- 4. bin (incoming SMS)

# 11.3 Reporting

The Reporting view displayed the activity for each instance of Leave-a-message and IVR (Voice Menu and Language Selector).

Just like the Statistics, the Reporting data is based on CDR entries.

# 12 Users and phone books

Freedom Fone 2.0 supports automatic and manual management of callers (users).

The system automatically creates new users in the system based on incoming calls and SMS. Users can also be manually added, edited and deleted through the GUI.

A users is defined by the following parameters:

Field	Туре	Default
name	varchar(50)	Unknown user
surname	varchar(50)	
email	varchar(50)	
skype	varchar(50)	
organization	varchar(50)	
count_poll	int(11) unsigned	
count_ivr	int(11) unsigned	
count_lam	int(11) unsigned	
count_bin	int(11) unsigned	
first_app	varchar(10)	
first_epoch	int(11) unsigned	
last_app	varchar(10)	
last_epoch	int(11) unsigned	
acl_id	int(11) unsigned	0
new	tinyint(4)	1 (true)

Additionally, a user can have {0:n} phone numbers that are stored in the table phone numbers:

Field	Туре	Null
user_id	int(11)	NO
number	varchar(200)	NO

### 12.1 Validation of data

User data are validated both for automatic and manual insertion. The following validation rules are applied:

Field	Rule	Regex	Allow empty
Name	Only letters, spaces and hyphens	^[a-zA-Z0-9\']+\$	No
Surname	Only letters, spaces and hyphens	^[a-zA-Z0-9\']+\$	Yes
Email	Valid email	CakePHP native rule	Yes
Skype	Start a with letter. 6-32 characters long. Allow {0-9,A-Z}	^[a-zA-Z]{1,1} [0-9a-zA-Z\]{5,31}\$	Yes
Phone number	May/may not start with a plus sign. 5-33 characters long Allow {+0-9}	^[+]{0,1}[0-9]{4,25}\$	Yes

## 12.2 User activity

The Users table monitors users activity, and stores the number of times a user have accesses a certain type of service.

It also stored how (through which type of service) and when a user entered the system. Finally, it keeps track of its last activity (what type of service and when).

The user activity is managed automatically, and can not be edited by the administrator.

#### 12.3 Phone books

The administrator can create/edit/delete phone books. A phone book can contain {0:n} users. A user can be assigned to a phone book via the Edit User view, or through the Edit Phone Book view.

User details can be listed and exported (to CSV) by phone book.

# $12.4 \quad Access \ Control \ Level \ (ACL)$

A user can be given an Access Control Level (White, Black, None). By default, the ACL "None" is given to new users.

In Freedom Fone > 2.0, the ACL value is not in use. ACL in intended to be used in combination with the Dialer (v 2.5) to allow/disallow users to access the callback service.

### 13 Processes

When the system boots, both FreeSWITCH and the Dispatcher is started automatically.

From the Health view (GUI), the administrator can monitor the status of FreeSWITCH and the incoming Dispatcher. The dispatcher can be stopped and started manually by the administrator.

Both of these core components can easily be stopped and started from command line whenever needed:

```
#/etc/init.d/freeswitch {start|stop|restart|force-reload}
#/etc/init.d/dispatcher_in {start|stop|restart|reload|force-reload|status}
```

## 13.1 Dispatcher

When the dispatcher starts, it writes three files that are accessible to CakePHP<sup>17</sup>.

- 1) Process id of dispatcher (pid)
- 2) Dispatcher version
- 3) Timestamp (when the dispatcher was started)

#### 13.1.1 Process id (pid)

When the dispatcher starts, it checks if the file PidFile exists (Rule 1). If the file exists, the dispatcher reads it. The file contains the process id (pid) of the previous dispatcher process. Then, the dispatcher checks if there is a process with this pid running (Rule 2).

The presence of this process id in the system, shows that an instance of the dispatcher already is running. Hence, if a process with the same pid is found, the dispatcher exits.

If there no such file (PidFile) is found, it means that the dispatcher was stopped manually (from GUI) and the file has been deleted by the application. In this case, the dispatcher writes its own pid to the PidFile and starts.

If a PidFile exists, but no process with its pid is found, the dispatcher writes its own pid to the PidFile (overwrites whatever that was in the file before) and starts.

<sup>&</sup>lt;sup>17</sup> All files located under: /opt/freedomfone/gui/app/webroot/system/{epoch|pid|version}




Illustration 8: Dispatcher management of process id's to determine whether an instance of a Dispatcher is running or not.

# 13.2 Dispatcher timestamps

There are two timestamps that are of importance to the Dispatcher:

- Start\_time: time when the dispatcher was started (visible when dispatcher is running)
- Last\_seen: last time the dispatcher was seen running (visible when dispatcher is off).

When the dispatcher starts, it writes the current timestamp to the EpochFile.

When the Processes page is reloaded (using the refresh() method), the EpochFile (created by the dispatcher) is read and the application check if there is a process with this pid running (Rule 1).

If a process with this pid is running, the dispatcher is on (green frame). If not, the dispatcher is off (red frame).

Next, the application checks the dispatcher's "status" value in the Processes table.

If the dispatcher is running AND the status is set to "false", the dispatcher has gone through a "unclean" shut-down. The same applies if the dispatcher is off, but the status is set to "true".

Installation & Developers Guide Author: Louise Berthilson, Alberto Escudero-Pascual

An "unclean shut-down" occurs either through server shut-down/reboot, or a manual shut-down from the command line. A clean shut-down of the dispatcher can only be done through the GUI.

To clean up after an "unclean" shut-down, the application takes the following measures (see table below):




Illustration 9: Dispatcher management of timestamp to determine start- and last seen timestamps.

For a "clean" shutdown, please see Section 11.3-11.4 that explains how to Stop and Start the dispatcher from the GUI.

#### 13.3 Start

When the Administrator press Start process (\$id) from the GUI, Cake fetches the corresponding entry in the database (id = \$id).

It reads the dispatcher\_in.pid file from the system (pid of last known dispatcher), and checks if there is a process running with this pid.

If no process with this pid is running, or the file does not exist, the dispatcher is started using the command found in database as "start\_cmd". The start method returns the pid of the new process that runs the dispatcher.

The Freedom Fone database entry for the incoming dispatcher is updated with start\_time, last—seen, pid, status (1 = running), interrupt = false).

Cake sends out a flash message saying either "Incoming dispatcher started", or "The incoming dispatcher is already running", if that is the case.

## 13.4 Stop

When the Administrator press Stop process (\$id) from the GUI, Cake fetches the corresponding entry in the database (id = \$id).

It reads the dispatcher\_in.pid file from the system (pid of last known dispatcher), and checks if there is a process running with this pid. If no such process exists, a flash message is sent out "Incoming dispatcher is not running".

If no pid file is found, a flash message is sent out "No pid found, Contact system admin". This should never happen.

If a process is found, it is killed (kill -9 {pid}), and the dispatcher\_in.pid file is deleted (unlink).

The Freedom Fone database entry for the incoming dispatcher is updated with start\_time, last seen, pid (0), status (0 = not running), interupt = Manual).

The incoming dispatcher is described as follows in the table Processes (Freedom Fone database).

Field	Value	
name	dispatcher_in	
status	1	
start_cmd	<pre>dispatcher_in/dispatcherESL.php -log= /var/tmp/dispatcher_in.log &gt; /dev/null 2&gt;&amp;1 &amp; echo \$!</pre>	
instance_id	100	
title	Incoming dispatcher	
start_time	{epoch}	
last_seen	{epoch}	
interupt	{Unmanaged/Manual}	
type	run	
script	/usr/bin/php	

#### 14 Localization

Freedom Fone 2.0 is available in three languages (English, Spanish, and French). It is using CakePHP native l10n support that is PO based.

To localize a string the following PHP code is required:

```
echo ("Hello world!", true);
```

To use the CakePHP built in I18n shell, issue the following command:

```
cd /opt/freedomfone/gui/cake/console/
bash cake i18n
```

To extract all string into one single PO file (freedomfone\_2.0.pot), do the following (bold text represents user input):

```
Welcome to CakePHP v1.2.4.8284 Console
App : console
Path: /opt/freedomfone/gui/cake/console
I18n Shell
[E]xtract POT file from sources
[I]nitialize i18n database table
[H]elp
[Q]uit
What would you like to do? (E/I/H/Q)
What is the full path you would like to extract?
Example: /opt/freedomfone/gui/cake/myapp
[Q]uit
[/opt/freedomfone/gui/cake/console] > /opt/freedomfone/gui/app/
What is the full path you would like to output?
Example: /opt/freedomfone/gui/app//locale
[Q]uit
[/opt/freedomfone/gui/app//locale] > /opt/freedomfone/gui/app/locale
Extracting...
Path: /opt/freedomfone/gui/app/
Output Directory: /opt/freedomfone/gui/app//locale/
______
Would you like to merge all translations into one file? (y/n)
[y] > y
What should we name this file?
[default] > freedomfone 2-0
Processing /opt/freedomfone/gui/app//app controller.php...
Processing /opt/freedomfone/gui/app//webroot/xml curl/index.php...
. . .
. . .
Done.
```

```
Il8n Shell

[E]xtract POT file from sources
[I]nitialize il8n database table
[H]elp
[Q]uit
What would you like to do? (E/I/H/Q)
> 0
```

The newly created POT file is located at:

/opt/freedomfone/gui/app/locale/freedomfone 2-0.pot

## 14.1 Add new language

To add a new language, edit the POT file with your favorite PO editor<sup>18</sup>.

Create a few folder with the three letter ISO code  $(ISO\_639-3)^{19}$  of the new language under:

```
/opt/freedomfone/gui/app/locale/{xxx}
```

Next, create a few folder named "LC MESSAGES":

```
/opt/freedomfone/gui/app/locale/{xxx}/LC_MESSAGES
```

Finally, rename your localized po-file to default.po and place it in the LC\_MESSAGES folder:

```
/opt/freedomfone/gui/app/locale/{xxx}/LC MESSAGES/default.po
```

Next, we need to add the new language to the Settings GUI of the application. Open the CakePHP configuration file config.php<sup>20</sup> and edit the \$config['LANGUAGES'] variable:

In the background, CakePHP applies the selected locale in the AppController (beforeFilter).

 $<sup>^{18}</sup>$   $\,$  Gedit is a simple and good tool for editing PO files

 $<sup>^{19}\,</sup>$  List of ISO 639-2 codes: http://www.sil.org/iso639-3/codes.asp

 $<sup>^{20}</sup>$  Located at: /opt/freedomfone/gui/app/config/config.php

# 15 Time zones and timestamps

All timestamps are managed in epoch format, which is expressed in GMT. To allow the administrator to see timestamps in local time, we allow her to set the time zone of the Freedom Fone deployment. The time zone can be set under Dashboard  $\rightarrow$  Settings.

This settings does not affect the actual time stamp (epoch) stored for each entry in the database, but only how the administrator sees the time from the application GUI.

# 16 IP address for streaming media

The Flash-player needs to know the IP address of the deployment to successfully stream audio content. To allow streaming media outside of the local network, a public IP address is required.

By default (upon first installation) the IP address is set to '127.0.0.1' (localhost). Hence the flash-player will only work if the administrator is sitting by the computer that is hosting the Freedom Fone installation. If you are trying to access Freedom Fone from another computer, the Flash player will not appear.

To allow streaming over a Local Area Network (LAN), the administrator must change ip address to one that is reachable over the LAN. The application GUI is facilitating this process, and presents an option to select "Local IP address".

If the Freedom Fone server is connected to the internet and is reachable via a Public (external) IP address, the administrator needs to select "Public IP address" to enable streaming of audio files over the Internet.

# 17 Refresh methods / cronjob

The application needs to fetch data from the spooler every now and then. That is done automatically by a cronjob that is running every 5 minutes.

The cronjob (crontab.freedomfone) is locate at:

/opt/freedomfone/cron

The cronjob runs the refresh method of the following controllers:

- 1. office route
- 2. polls

- 3. messages
- 4. cdr
- 5. monitor ivr
- 6. processes
- 7. channels
- 8. bin
- 9. newfies (version 3.0)

```
# Freedom Fone 2010, refresh/cron methods for spoolers
# App: OfficeRoute pop3 daemon
*/5 * * * * root /usr/bin/php /opt/freedomfone/office_route/pop3_daemon.php >/dev/null 2>&1
# App: SMS/Skype polls
*/5 * * * root /usr/bin/wget -O - -q -t 1 http://localhost/freedomfone/polls/refresh/cron >/dev/null 2>&1
# App: Leave a message
*/5 * * * root /usr/bin/wget -0 - -q -t 1 http://localhost/freedomfone/messages/refresh/cron >/dev/null 2>&1
# App: Call/Event data records
    * * * root /usr/bin/wget -0 - -q -t 1 http://localhost/freedomfone/cdr/refresh/cron >/dev/null 2>&1
# App: Datamining of IVR options
*/5 * * * * root /usr/bin/wget -O - -q -t 1 http://localhost/freedomfone/monitor_ivr/refresh/cron >/dev/null 2>&1
# App: System Health
*/5 * * * root /usr/bin/wget -0 - -q -t 1 http://localhost/freedomfone/processes/refresh/cron >/dev/null 2>&1
# App: GSMOPEN
*/5 * * * root /usr/bin/wget -0 - -q -t 1 http://localhost/freedomfone/channels/refresh/cron >/dev/null 2>&1
# App: Other SMS - The Bin
      * * root /usr/bin/wqet -O - -q -t 1 http://localhost/freedomfone/bin/refresh/cron >/dev/null 2>&1
# App: Dialer - Newfie
    * * * root /usr/bin/wget -0 - -q -t 1 http://localhost/freedomfone/campaigns/dialer_refresh/cron >/dev/null
```

The administrator can also execute the refresh methods manually. Each of the above listed view provides a manual Refresh method:

Main Menu	Page Title	Controller	View
Home	System Overview	cdr	overview
Polls	Polls/(poll results)	polls	index/view
Message Centre	Audio Messages	messages	index
Message Centre	Incoming SMS	bin	index
User Management	Users/Edit User	users	index/edit
System Data	Call data records	cdr	index
System Data	CDR Statistics	cdr	statistics
System Data	Monitoring of Voice Menus	monitor_ivr	index
System Data	Health	processes	index
System Data	GSM Channels	channels/officeroute	index

The (10) instances of the Refresh method calls a system wide function (app\_controller.php) that executes the same commands as the cronjob does.

```
$this->requestAction('/polls/refresh/manual');
$this->requestAction('/messages/refresh');
$this->requestAction('/cdr/refresh/manual');
$this->requestAction('/monitor ivr/refresh/manual');
```

 Freedom Fone Version 1.6

\$this->requestAction('/processes/refresh/manual');
\$this->requestAction('/channels/refresh/manual');
\$this->requestAction('/bin/refresh/manual');

### 18 Channels

Freedom Fone > 2.0 supports the following channels by default:

- 1. GSMopen (Mobigater)
- 2. SIP (OfficeRoute)

Additionally, Freedom Fone 2.0 supports Skype and SkypeIn. However, these channels need to be added manually, which is not trivial. The dispatcher and the application layer does however already support Skype and SkypeIn, without any modifications needed.

# 19 OfficeRoute configuration

To facility the configuration of the OfficeRoute device, we have taken the following measures:

- 1. Provisioning of a configuration file (backup file) to OfficeRoute (firmware 2.3.11)
- 2. Configuration of Freedom Fone 2.0 with a default IP address

The backup file is provided with the ISO, but can also be download from the SVN:

https://dev.freedomfone.org/browser/trunk/installer/sekowei/extras/backup officeroute 2.3.11.tgz

The backup file provides the following configuration:

#### 1. SIP trunk to Freedom Fone

OfficeRoute GUI: Telephony services  $\rightarrow$  Devices  $\rightarrow$  SIP lines

A SIP line pointing to 192.168.1.250 (eth0:0 of Freedom Fone > 2.0) at port 5080, with username = 1001, and password = 1234. This SIP line is associated with a Line ID (24 in this example) that will be used later to create "operators".



#### 2. Freedom Fone Services

OfficeRoute GUI: Telephony services  $\rightarrow$  GSM routing  $\rightarrow$  Operator

Two "operators" are created by default (2100 and 4100). The service name and the Description can be named anything, but the Operator number must be the Freedom Fone Service ID ( $\{2,4\}\{100\text{-}119\}$ ). The VoIP line must be set to "SIP 24", which represents the Freedom Fone SIP trunk.

The administrator can create more Operators (by pressing the "Plus" icon), and select any operator number (service id) she wish to reach.



#### 3. Channel mapping

OfficeRoute GUI: Telephony services  $\rightarrow$  GSM routing  $\rightarrow$  GSM

This view maps "Operators" with GSM modules. The OfficeRoute device has four GSM modules (1-4).

By default, GSM module 1 points to the operator "2100" which is the Freedom Fone Leave-a-message service with service id 2100.

GSM module 2-4 points to the operator "4100", which is the Freedom Fone IVR with service id 4100.



# 19.1 Load configuration file

To load the default configuration file of Freedom Fone > 2.0, follow the steps below.

- 1. Go to Administration  $\rightarrow$  Configuration backup  $\rightarrow$  Upload config
- 2. Select the file to upload (backup\_officeroute\_2.3.11.tgz), and make sure that the "Don't extract licence" option is checked.
- 3. Press Save (the bottom-right "floppy drive" icon).
- 4. Wait a few minutes for the device to reboot and apply the new configuration file.

  The OfficeRoute is rebooted when the Power led is lit Blue and the occupied channels led's are lit Red.
- 5. Navigate back to the login page of OfficeRoute, and log in again.

Freedom Fone > 2.0 comes by default with the IP address 192.168.1.250. This ip address is set as an alias to interface eth0. In this way, the default configuration script of OfficeRoute can be set to point at .250 and is independent of what local IP address Freedom Fone is assigned by its DHCP.

# 20 Debugging Freedom Fone

To narrow down the problem you need to identify in which major component is the cause of the problem (Communication Gateway (GSM/SIP), Backend (FreeSWITCH) or Frontend (GUI))

These questions might help you to narrow down the problem:

- 1. Are the calls received by the communication channel and handled over FreeSWITCH?
- 2. Is the correct application invoked in the backend?
- 3. Is the dispatcher running and listening to the events?
- 4. Has the audio arrived to the file system?
- 5. Has the audio arrived to the GUI?

If you use 2N Office Route or any other GSM Gateway, you need to familiarized yourself with the LED codes and any logs provided by the unit. Consider running a packet sniffer as Wireshark to see the traffic between your Gateway and FreeSWITCH. Having a basic understanding of SIP will help you to debug the more common problems: authentication, codec negotiation, etc)

The main mechanism to debug the backend (FreeSWITCH) is to use the fs\_cli client available under /opt/freeswitch/bin/fs\_cli and/or to review the freeswitch logs under /opt/freeswitch/log/freeswitch.log

The front-end is written in Cake PHP MVC framework, debugging the GUI implies to turn on the Cake Debug level (core.php) and being familiar with MVC programming in general.

To facilitate the debugging process we provide a checklist

- 1. Check that the call or SMS arrives to FreeSWITCH using fs\_cli or reviewing the freeswitch.log
- 2. Check that the correct application is invoked (leave-a-message, IVR)
- 3. Verify that the dispatcher is running and that the events are logged
- 4. Check that the spooler is receiving the events
- 5. Check the filesystem for incoming audio files
- 6. Review the syslog to verify that the audio converter daemon has converted the file (WAV-MP3)
- 7. Turn on Debug level in Cake
- 8. Review all the GUI logs available under /opt/freedomfone/log

# 21 Appendix 1: Event data

#### 21.1 Custom events

Event-Name	Event-Subclass	Application
CUSTOM	leave_a_message	Leave-a-message
CUSTOM	monitor_ivr	IVR monitoring
CUSTOM	gsmopen::dump_event	Monitor Mobigater (gsmopen) channels
CUSTOM	officeroute	Incoming SMS from OfficeRoute
MESSAGE		Incoming SMS from Mobigater. Incoming SMS from Skype
CHANNEL_STATE		Call data records (CDR)
HEARTBEAT		Dispatcher (is FreeSWITCH alive)

#### 21.1.1 Leave-a-message

Event-Subclass: leave\_a\_message

Event-Name: CUSTOM

Core-UUID: 0fb12e62-2d4a-11e0-a17f-b7d076781c4b

FreeSWITCH-Hostname: c10
FreeSWITCH-IPv4: 192.168.1.10
FreeSWITCH-IPv6: %3A%3A1

Event-Date-Local: 2011-02-03%2012%3A39%3A09

Event-Date-GMT: Thu, %2003%20Feb%202011%2011%3A39%3A09%20GMT

Event-Date-Timestamp: 1296733149199747
Event-Calling-File: mod\_spidermonkey.c
Event-Calling-Function: event construct

Event-Calling-Line-Number: 502

FF-InstanceID: 101

FF-URI: http%3A//192.168.1.10/freedomfone/freedomfone/leave message/101/messages/

FF-FileID: 1ea2fb34-2f8a-11e0-a29a-b7d076781c4b

FF-CallerID: 1008

FF-CallerName: OPENVZ10

FF-StartTimeEpoch: 1296733145280 FF-FinishTimeEpoch: 1296733149200

FF-OnQuickHangup: true

#### 21.1.2 Monitor IVR

Event-Subclass: monitor ivr

Event-Name: CUSTOM

Core-UUID: 0fb12e62-2d4a-11e0-a17f-b7d076781c4b

FreeSWITCH-Hostname: c10
FreeSWITCH-IPv4: 192.168.1.10
FreeSWITCH-IPv6: %3A%3A1

Event-Date-Local: 2011-02-03%2012%3A26%3A22

Event-Date-GMT: Thu, %2003%20Feb%202011%2011%3A26%3A22%20GMT

Event-Date-Timestamp: 1296732382209547 Event-Calling-File: mod\_spidermonkey.c

```
Event-Calling-Function: event_construct
Event-Calling-Line-Number: 502
FF-IVR-Unique-ID: 6a542e88-2f88-11e0-a292-b7d076781c4b
FF-IVR-IVR-Name: Selector%201
FF-IVR-IVR-Node-Digit: 1
FF-IVR-IVR-Node-Unique-ID: 2
FF-IVR-IVR-Node-Service-ID: IvrMenu
FF-IVR-Caller-ID-Number: 1008
FF-IVR-Destination-Number: 4104
```

Fields marked in bold are coming from the ivr.xml file. The other fields are generated by FreeSWITCH.

### 21.1.3 GSMopen::dump event

```
Event-Subclass: gsmopen%3A%3Adump event
Event-Name: CUSTOM
Core-UUID: f62c06de-3298-11e0-8322-ffb9470851ea
FreeSWITCH-Hostname: sekowei
FreeSWITCH-IPv4: 192.168.1.103
FreeSWITCH-IPv6: %3A%3A1
Event-Date-Local: 2011-02-07%2010%3A04%3A07
Event-Date-GMT: Mon, %2007%20Feb%202011%2009%3A04%3A07%20GMT
Event-Date-Timestamp: 1297069447921142
Event-Calling-File: mod_gsmopen.cpp
Event-Calling-Function: dump_event_full
Event-Calling-Line-Number: 3150
interface name: interface1
interface id: 1
active: 1
not registered: 0
home_network_registered: 1
roaming registered: 0
got signal: 0
running: 1
imei: 353579016738243
imsi: 240084703497964
controldev dead: 0
controldevice name: /dev/ttyACMO
no sound: 0
alsacname: plughw%3A1
alsapname: plughw%3A1
playback boost: 1619.086162
capture boost: 910.479058
dialplan: XML
context: default
destination: 5000
ib calls: 0
ob_calls: 0
ib_failed_calls: 0
ob_failed_calls: 0
interface state: 0
phone callflow: 0
session uuid str: undef
during-call: false
```

### 21.1.4 Officeroute

Generated by test script<sup>21</sup>:

Event-Subclass: officeroute

Event-Name: CUSTOM

Core-UUID: 0fb12e62-2d4a-11e0-a17f-b7d076781c4b

FreeSWITCH-Hostname: c10
FreeSWITCH-IPv4: 192.168.1.10
FreeSWITCH-IPv6: %3A%3A1

Event-Date-Local: 2011-02-03%2012%3A41%3A55

Event-Date-GMT: Thu, %2003%20Feb%202011%2011%3A41%3A55%20GMT

Event-Date-Timestamp: 1296733315250072 Event-Calling-File: mod\_spidermonkey.c Event-Calling-Function: event\_construct

Event-Calling-Line-Number:  $50\overline{2}$ FF-SMS-Sender-Number: %2B1234567
FF-SMS-Receiver-Number: localhost

proto: GSM

epoch: 1296733315000000 Content-Length: 15

#### [here goes SMS body]

Generated by SMS to OfficeRoute:

Event-Subclass: officeroute

Event-Name: CUSTOM

Core-UUID: 0fb12e62-2d4a-11e0-a17f-b7d076781c4b

FreeSWITCH-Hostname: c10 FreeSWITCH-IPv4: 192.168.1.10 FreeSWITCH-IPv6: %3A%3A1

Event-Date-Local: 2011-02-03%2012%3A52%3A01

Event-Date-GMT: Thu, %2003%20Feb%202011%2011%3A52%3A01%20GMT

Event-Date-Timestamp: 1296733921409489 Event-Calling-File: mod\_spidermonkey.c Event-Calling-Function: event construct

Event-Calling-Line-Number: 502

FF-SMS-Sender-Number: %2B46706506749

FF-SMS-Receiver-Number: 1000

proto: GSM

epoch: 1296733854000000

Content-Length: 8

[here goes SMS body]

\_

<sup>&</sup>lt;sup>21</sup> Available at: /opt/freedomfone/dispatcher in/tests/sendSMS.php

Installation & Developers Guide Author: Louise Berthilson, Alberto Escudero-Pascual

Automatic SMS from operator (missed call):

Event-Subclass: officeroute

Event-Name: CUSTOM

Core-UUID: 0fb12e62-2d4a-11e0-a17f-b7d076781c4b

FreeSWITCH-Hostname: c10 FreeSWITCH-IPv4: 192.168.1.10 FreeSWITCH-IPv6: %3A%3A1

Event-Date-Local: 2011-02-03%2012%3A52%3A01

Event-Date-GMT: Thu, %2003%20Feb%202011%2011%3A52%3A01%20GMT

Event-Date-Timestamp: 1296733921409489 Event-Calling-File: mod\_spidermonkey.c Event-Calling-Function: event\_construct

Event-Calling-Line-Number: 502

FF-SMS-Sender-Number: undefined

FF-SMS-Receiver-Number: undefined

proto: GSM
epoch: undefined
Content-Length: 20

[here goes SMS body]

## 21.2 Default FreeSWITCH events

#### 21.2.1 Message

Incoming SMS via Mobigater:

Event-Name: MESSAGE

Core-UUID: a4ellece-32be-11e0-af25-4144060e59ac

FreeSWITCH-Hostname: sekowei
FreeSWITCH-IPv4: 192.168.1.103

FreeSWITCH-IPv6: %3A%3A1

Event-Date-Local: 2011-02-07%2014%3A48%3A22

Event-Date-GMT: Mon, %2007%20Feb%202011%2013%3A48%3A22%20GMT

Event-Date-Timestamp: 1297086502128933 Event-Calling-File: mod\_gsmopen.cpp Event-Calling-Function: sms\_incoming Event-Calling-Line-Number: 3262

proto: SMS

login: interface1
from: %2B46706506749

date: 02/07/11%2014%3A48%3A17%20(%2B0100)
datacodingscheme: default%20alphabet
servicecentreaddress: %2B46708000708

messagetype: 0

subject: SIMPLE%20MESSAGE

during-call: false Content-Length: 26

[here goes SMS body]

## Installation & Developers Guide Author: Louise Berthilson, Alberto Escudero-Pascual

#### Incoming Skype chat message:

Event-Name: MESSAGE Core-UUID: 33a93134-31dc-11e0-8df9-ef94f0b5360a FreeSWITCH-Hostname: ffdemo12 FreeSWITCH-IPv4: 192.168.1.12 FreeSWITCH-IPv6: %3A%3A1 Event-Date-Local: 2011-02-06%2015%3A31%3A10 Event-Date-GMT: Sun, %2006%20Feb%202011%2014%3A31%3A10%20GMT Event-Date-Timestamp: 1297002670512049 Event-Calling-File: mod\_skypopen.c Event-Calling-Function: incoming\_chatmessage Event-Calling-Line-Number: 2426 proto: skype login: interface1 hint: Louise%20Berthilson from: berthilson subject: SIMPLE%20MESSAGE  $\verb|chatname: \$23berthilson/\$freedomfone.org\$3Bce25007d81498a3c||$ id: 821 during-call: false

#### O. C. CILLANNEL CELE

[here goes SMS body]

21.2.2 CHANNEL STATE Event-Name: CHANNEL STATE Core-UUID: 0fb12e62-2d4a-11e0-a17f-b7d076781c4b FreeSWITCH-Hostname: c10 FreeSWITCH-IPv4: 192.168.1.10 FreeSWITCH-IPv6: %3A%3A1 Event-Date-Local: 2011-02-03%2012%3A33%3A49 Event-Date-GMT: Thu, %2003%20Feb%202011%2011%3A33%3A49%20GMT Event-Date-Timestamp: 1296732829919942 Event-Calling-File: switch channel.c Event-Calling-Function: switch\_channel\_perform\_set\_running\_state Event-Calling-Line-Number: 1301 Channel-State: CS ROUTING Channel-State-Number: 2 Channel-Name: sofia/internal/1008%40192.168.1.10%3A5060 Unique-ID: 787613c2-2f89-11e0-a296-b7d076781c4b Call-Direction: inbound Presence-Call-Direction: inbound Channel-Presence-ID: 1008%40192.168.1.10 Answer-State: ringing Channel-Read-Codec-Name: PCMA Channel-Read-Codec-Rate: 8000 Channel-Write-Codec-Name: PCMA Channel-Write-Codec-Rate: 8000 Caller-Username: 1008 Caller-Dialplan: XML Caller-Caller-ID-Name: OPENVZ10 Caller-Caller-ID-Number: 1008 Caller-Network-Addr: 192.168.1.41 Caller-ANI: 1008 Caller-Destination-Number: 4104 Caller-Unique-ID: 787613c2-2f89-11e0-a296-b7d076781c4b Caller-Source: mod sofia Caller-Context: default

Freedom Fone Version 1.6

## Installation & Developers Guide Author: Louise Berthilson, Alberto Escudero-Pascual

Caller-Channel-Name: sofia/internal/1008%40192.168.1.10%3A5060
Caller-Profile-Index: 1
Caller-Profile-Created-Time: 1296732829909672
Caller-Channel-Created-Time: 1296732829909672
Caller-Channel-Answered-Time: 0
Caller-Channel-Progress-Time: 0
Caller-Channel-Progress-Media-Time: 0
Caller-Channel-Hangup-Time: 0
Caller-Channel-Transfer-Time: 0
Caller-Screen-Bit: true
Caller-Privacy-Hide-Name: false
Caller-Privacy-Hide-Number: false

Event-Name: CHANNEL STATE

Core-UUID: 0fb12e62-2d4a-11e0-a17f-b7d076781c4b

FreeSWITCH-Hostname: c10
FreeSWITCH-IPv4: 192.168.1.10
FreeSWITCH-IPv6: %3A%3A1

Event-Date-Local: 2011-02-03%2012%3A35%3A15

Event-Date-GMT: Thu, %2003%20Feb%202011%2011%3A35%3A15%20GMT

Event-Date-Timestamp: 1296732915399845 Event-Calling-File: switch\_channel.c

Event-Calling-Function: switch\_channel\_perform\_set\_running\_state

Event-Calling-Line-Number: 1301 Channel-State: CS\_DESTROY Channel-State-Number: 12

Channel-Name: sofia/internal/1008%40192.168.1.10%3A5060

Unique-ID: 787613c2-2f89-11e0-a296-b7d076781c4b

Call-Direction: inbound
Presence-Call-Direction: inbound

Answer-State: answered

#### 21.2.3 HEARBEAT

Event-Name: HEARTBEAT

Core-UUID: 398fd5cc-31db-11e0-817e-914a7b5848e2

FreeSWITCH-Hostname: ffdevel10 FreeSWITCH-IPv4: 192.168.1.10 FreeSWITCH-IPv6: %3A%3A1

Event-Date-Local: 2011-02-06%2014%3A53%3A05

Event-Date-GMT: Sun, %2006%20Feb%202011%2013%3A53%3A05%20GMT

Event-Date-Timestamp: 1297000385226097 Event-Calling-File: switch\_core.c Event-Calling-Function: send heartbeat

Event-Calling-Line-Number: 65 Event-Info: System%20Ready

Up-Time:0%20years,%200%20days,%203%20hours,%2028%20minutes,%2059%20seconds,

%20782%20milliseconds,%209%20microseconds

Session-Count: 0 Session-Per-Sec: 30 Session-Since-Startup: 0

## 21.3 Building the Freedom Fone ISO

Once you have built Freedom Fone using the installer you can create an ISO bootable image using remastersys<sup>22</sup>.

These notes compile the things you need to consider to generate the ISO

[m]: minor

[M]: major

[N]: only needed if you build FreeSWITCH from sources

[m] plymouth-splash is disabled in upstart

Some slow systems hit a bug with Plymouth https://bugs.launchpad.net/ubuntu/+source/plymouth/+bug/534861

[m] change version name in core.php

Consider reflecting the build version in the core.php file of the GUI /opt/freedomfone/gui/config/ or /usr/local/freedomfone/gui/config/

[m] create symbolic link to access fs cli

Create symbolic links to command tools like fs\_cli in the Desktop. Alternatively edit the .bashrc of root user to create Aliases

[m] create symbolic link to firefox and add logo

Create a shortcut to the browser in the Desktop and replace the logo

[m] create home page and other shorcut

Edit the default profile of Firefox to include <a href="http://localhost/freedomfone">http://localhost/freedomfone</a> as default Home

[M] add remastersys to the apt repositories (Lucid)

See: <a href="http://www.geekconnection.org/remastersys/ubuntu.html">http://www.geekconnection.org/remastersys/ubuntu.html</a>

[M] verify dialplan.xml/ivr.xml

Verify that the dialplan.xml and ivr.xml come from a fresh install.

[M] verify debug in Cake

<sup>&</sup>lt;sup>22</sup> http://www.geekconnection.org/remastersys/

Verify that Cake Debug level is disabled

[M] documentation, user guide create shortcuts to documentation

[M] clean cake cache

Ensure that the cache of Cake is clean

[m] global config sortcuts for officeroute and other components

Consider creating a shortcut to the [log] [config] folders in the Desktop

[M] clean subversion passwords

If you have admin rights, remove the subversion cache password Check /root/.subversion/auth/svn.simple for cached passwords

[M] clean deb packages apt-get clean

[M] fix grub (Advanced, risky!!)

If building in a dual boot system, you will need to recreate a grub for the building process. Grub should have ONLY one bootable system

- [M] check that default LAM 100.conf has good values
- m radiance ubuntu theme

Change the Ubuntu theme and background image. Alight icons to the top-left corner

[M] clean old audio files

Use the reset script to reset the DB and populate all the demo data. Fix permissions

[m] Ensure that openssh-server is installed in the box

dpkg-reconfigure openssh-server will be needed once the system is installed to recreate keys!

[N] edit Makefile from libs/esl to disable -Werror flag

libs/esl does not cleanly compile in Freeswitch, it is necessary to disable the Warning->Error flag in gcc/Makefile

[N] check that memory limit and max upload size are 128M and 5M

Freedom fone does not use the default values in php.ini. Double check that /etc/apache2/php.ini matches our requirements

[N] /etc/rc.local sets 192.168.1.250 as an alias of eth0

In order to make sure that Office Route can find our installation we set a default IP in eth0 interface in /etc/rc.local This is done by the rootconf build script in the Security Edition