ower cycle FRX Pro Attempting o update FW? FRX PRO
TROUBLE SHOOTING TREE Finish FW update Turn on the gimbal and controller What color is the Status Light? White Bind the FRX Pro pair Flashing Update FW
Ensure it is
the correct
file What is the LED state? **Solid** Enduring **Solid** Temporary Set Radio Type to USB Is the mbal on and unctioning? Fix gimbal Is FRX Pro working? Do Nothing Done!