# Micropython usermod documentation

Release 1.622

**Zoltán Vörös** 

## Content:

1	Introduction       1.1 Code blocks	2
2	The micropython code base 2.1 User modules in micropython	<b>3</b>
3	micropython internals 3.1 Object representation	5 6 6
4	Developing your first module 4.1 Header files	7 8 8 9
	5.1 Integer constants	13 13 14 17
7	7.1 Positional arguments	21 21 23 25
8	8.1 Printing class properties	31 34 34 39
9	Creating new types	43
10	8	<b>17</b> 17

	10.2 Returning iterables	49				
	10.3 Creating iterables	51				
	10.4 Subscripts					
	10.5 Slicing	59				
11	Profiling 11.1 Profiling in python	<b>65</b> 65 67				
12	Working with larger modules	69				
13	13 A word for the lazy					
14	Outline of a math library 14.1 Requirements	<b>75</b> 75				
15	Indices and tables	77				

Introduction

So, you have somehow bumped into micropython, fallen in love with it in an instance, broken your piggy bank, and run off, head over heels, to order a pyboard. You have probably paid extra for the expedited shipping. Once the pyboard arrived, you became excited like a puppy with a bone. You played with the hardware, learnt how to access the accelerometer, switch, LEDs, and temperature sensor, and you successfully communicated with other devices via the I2C, SPI, USART, or CAN interfaces. You have plugged the board in a computer, and driven someone crazy by emulating a seemingly disoriented mouse on it. You have even tried to divide by zero, just to see if the chip would go up in flames (this was vicious, by the way), and noticed that the interpreter smartly prevented such things from happening. You have written your own python functions, even compiled them into frozen modules, and burnt the whole damn thing onto the microcontroller. Then you have toyed with the on-board assembler, because you hoped that you could gain some astronomical factors in speed. (But you couldn't.)

And yet, after all this, you feel somewhat unsatisfied. You find that you want to access the periphery in a special way, or you need some fancy function that, when implemented in python itself, seems to consume too much RAM, and takes an eternity to execute, and assembly, with its limitations, is just far too awkward for it. Or perhaps, you are simply dead against making your code easily readable by writing everything in python, and you want to hide the magic, just for the heck of it. But you still want to retain the elegance of python.

If, after thorough introspection and soul-searching, you have discovered these latter symptoms in yourself, you have two choices: either you despair, scrap your idea, and move on, or you learn how the heavy lifting behind the micropython facade is done, and spin your own functions, classes, and methods in C. As it turns out, it is not that hard, once you get the hang of it. The sole trick is to get the hang of it. And this is, where this document intends to play a role.

On the following pages, I would like to show how new functionality can be added and exposed to the python interpreter. I will try to discuss all aspects of micropython in an approachable way. Each concept will be presented in an implementation, stripped to the bare minimum, that you can compile right away, and try yourself. (The code here has been tested against micropython v.1.11.) At the end of each chapter, I will list the discussed code in its entirety, and I also include a link the the source, so that copying and pasting does not involve copious amounts of work. Moreover, I include a small demonstration, so that we can actually see that our code works. The code, as well as the source of this document are also available under https://github.com/v923z/micropython-usermod. The simplest way of getting started is probably cloning the repository with

git clone https://github.com/v923z/micropython-usermod.git

As for the source: all that you see here originates from a single jupyter notebook. That's right, the documentation, the C

source, the compilation, and the testing. You can find the notebook at https://github.com/v923z/micropython-usermod/blob/master/docs/micropython-usermod.ipynb. And should you wonder, everything is under the MIT licence.

I start out with a very simple module and slowly build upon it. At the very end of the discussion, I will outline my version of a general-purpose math library, similar to numpy. In fact, it was when I was working on this math module that I realised that a decent programming guide to micropython is sorely missing, hence this document. Obviously, numpy is a gigantic library, and we are not going to implement all aspects of it. But we will be able to define efficiently stored arrays on which we can do vectorised computations, work with matrices, invert and contract them, fit polynomials to measurement data, and get the Fourier transform of an arbitrary sequence. I do hope that you find the agenda convincing enough!

One last comment: I believe, all examples in this document could be implemented with little effort in python itself, and I am definitely not advocating the inclusion of such trivial cases in the firmware. I chose these examples on two grounds: First, they are all simple, almost primitive, but for this very reason, they demonstrate a single idea without distraction. Second, having a piece of parallel python code is useful insofar as it tells us what to expect, and it also encourages us to implement the C version such that it results in *pythonic* functions.

#### 1.1 Code blocks

You'll encounter various kinds of code blocks in this document. These have various scopes, which are listed here:

- if a code block begins with an exclamation mark, the content is meant to be executed on the command line.
- if the code block looks like a piece of python code, it should be run in a python interpreter.
- if the heading of the code block is %%micropython, then, well, you guessed it right, the content should be passed to the micropython interpreter of your port of choice.
- other code segments can be C code, or a makefile. These should be easy to recognise, because both of these have a header with a link to the location of the file.

## The micropython code base

Since we are going to test our code mainly on the unix port, we set that as the current working directory.

```
!cd ../../micropython/ports/unix/
```

```
/home/v923z/sandbox/micropython/v1.11/micropython/ports/unix
```

The micropython codebase itself is set up a rather modular way. Provided you cloned the micropython repository with

```
!git clone https://github.com/micropython/micropython.git
```

onto your computer, and you look at the top-level directories, you will see something like this:

```
!ls ../../micropython/
```

```
ACKNOWLEDGEMENTS
                 docs
                          lib
                                pic16bit
                                                  zephyr
                                        teensy
bare-arm drivers LICENSE
                                         tests
                              ру
                     esp8266 logo
cc3200
                                       qemu-arm
                                                 tools
CODECONVENTIONS.md examples minimal
                                       README.md unix
CONTRIBUTING.md
                 extmod
                          mpy-cross
                                             windows
```

Out of all the directoties, at least two are of particular interest. Namely, /py/, where the python interpreter is implemented, and /ports/, which contains the hardware-specific files. All questions pertaining to programming micropython in C can be answered by browsing these two directories, and perusing the relevant files therein.

## 2.1 User modules in micropython

Beginning with the 1.10 version of micropython, it became quite simple to add a user-defined C module to the firmware. You simply drop two or three files in an arbitrary directory, and pass two compiler flags to make like so:

```
!make USER_C_MODULES=../../user_modules CFLAGS_EXTRA=-DMODULE_EXAMPLE_ENABLED=1 all
```

Here, the USER\_C\_MODULES variable is the location (relative to the location of make) of your files, while CFLAGS\_EXTRA defines the flag for your particular module. This is relevant, if you have many modules, but you want to include only some of them.

Alternatively, you can set the module flags in mpconfigport.h (to be found in the port's root folder, for which you are compiling) as

```
#define MODULE_SIMPLEFUNCTION_ENABLED (1)
#define MODULE_SIMPLECLASS_ENABLED (1)
#define MODULE_SPECIALCLASS_ENABLED (1)
#define MODULE_KEYWORDFUNCTION_ENABLED (1)
#define MODULE_CONSUMEITERABLE_ENABLED (1)
#define MODULE_VECTOR_ENABLED (1)
#define MODULE_RETURNITERABLE_ENABLED (1)
#define MODULE_RETURNITERABLE_ENABLED (1)
#define MODULE_MAKEITERABLE_ENABLED (1)
#define MODULE_SUBSCRIPTITERABLE_ENABLED (1)
#define MODULE_SUBSCRIPTITERABLE_ENABLED (1)
#define MODULE_SLICEITERABLE_ENABLED (1)
#define MODULE_VARARG_ENABLED (1)
#define MODULE_STRINGARG_ENABLED (1)
```

and then call make without the CFLAGS\_EXTRA flag:

```
!make USER_C_MODULES=../../user_modules all
```

This separation of the user code from the micropython code base is definitely a convenience, because it is much easier to keep track of changes, and also because you can't possibly screw up micropython itself: you can also go back to a working piece of firmware by dropping the USER\_C\_MODULES argument of make.

### micropython internals

Before exploring the exciting problem of micropython function implementation in C, we should first understand how python objects are stored and treated at the firmware level.

## 3.1 Object representation

Whenever you write

```
>>> a = 1
>>> b = 2
>>> a + b
```

on the python console, first the two new variables, a, and b are created and a reference to them is stored in memory. Then the value of 1, and 2, respectively, will be associated with these variables. In the last line, when the sum is to be computed, the interpreter somehow has to figure out, how to decipher the values stored in a, and b: in the RAM, these two variables are just bytes, but depending on the type of the variable, different meanings will be associated with these bytes. Since the type cannot be known at compile time, there must be a mechanism for keeping stock of this extra piece of information. This is, where mp\_obj\_t, defined in obj.h, takes centre stage.

If you cast a cursory glance at any of the C functions that are exposed to the python interpreter, you will always see something like this

```
mp_obj_t some_function(mp_obj_t some_variable, ...) {
    // some_variable is converted to fundamental C types (bytes, ints, floats, ...
    pointers, structures, etc.)
    ...
}
```

Variables of type mp\_obj\_t are passed to the function, and the function returns the results as an object of type mp\_obj\_t. So, what is all this fuss this about? Basically, mp\_obj\_t is nothing but an 8-byte segment of the memory, where all concrete objects are encoded. There can be various object encodings. E.g., in the A encoding, integers are those objects, whose rightmost bit in this 8-byte representation is set to 1, and the value of the integer can then be retrieved by shifting these 8 bytes by one to the right, and then applying a mask. In the B encoding, the

variable is an integer, if its value is 1, when ANDed with 3, and the value will be returned, if we shift the 8 bytes by two to the right.

## 3.2 Type checking

Fortunately, we do not have to be concerned with the representations and the shifts, because there are pre-defined macros for such operations. So, if we want to find out, whether some\_variable is an integer, we can inspect the value of the Boolean

```
MP_OBJ_IS_SMALL_INT(some_variable)
```

The integer value stored in some\_variable can then be gotten by calling MP\_OBJ\_SMALL\_INT\_VALUE:

```
int value_of_some_variable = MP_OBJ_SMALL_INT_VALUE(some_variable);
```

These decoding steps take place somewhere in the body of some\_function, before we start working with native C types. Once we are done with the calculations, we have to return an mp\_obj\_t, so that the interpreter can handle the results (e.g., show it on the console, or pipe it to the next instruction). In this case, the encoding is done by calling

```
mp_obj_new_int(value_of_some_variable)
```

More generic types can be treated with the macro mp\_obj\_is\_type, which takes the object as the first, and a pointer to the type as the second argument. Now, if you want to find out, whether some\_variable is a tuple, you could apply the mp\_obj\_is\_type macro,

```
mp_obj_is_type(some_variable, &mp_type_tuple)
```

While the available types can be found in obj.h, they all follow the mp\_type\_ + python type pattern, so in most cases, it is not even necessary to look them up. We should also note that it is also possible to define new types. When done properly, mp\_obj\_is\_type can be called on objects with this new type, i.e.,

```
mp_obj_is_type(myobject, &my_type)
```

will just work. We return to this question later.

## 3.3 python constants

At this point, we should mention that python constants, True (in C mp\_const\_true), False (in C mp\_const\_false), None (in C mp\_const\_none) and the like are also defined in obj.h. These are objects of type mp\_obj\_t, as almost anything else, so you can return them from a function, when the function is meant to return directly to the interpreter.

## Developing your first module

Having seen, what the python objects look like to the interpreter, we can start with our explorations in earnest. We begin by adding a simple module to micropython. The module will have a single function that takes two numbers, and adds them. I know that this is the most exciting thing since sliced bread, and you have always wondered, why there isn't a built-in python function for such a fascinating task. Well, wonder no more! From this moment, *your* micropython will have one.

First I show the file in its entirety (20 something lines all in all), and then discuss the parts.

https://github.com/v923z/micropython-usermod/tree/master/snippets/simplefunction/simplefunction.c

```
#include "py/obj.h"
#include "py/runtime.h"
STATIC mp_obj_t simplefunction_add_ints(mp_obj_t a_obj, mp_obj_t b_obj) {
   int a = mp_obj_get_int(a_obj);
   int b = mp_obj_get_int(b_obj);
   return mp_obj_new_int(a + b);
STATIC MP_DEFINE_CONST_FUN_OBJ_2(simplefunction_add_ints_obj, simplefunction_add_
→ints);
STATIC const mp_rom_map_elem_t simplefunction_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_simplefunction) },
    { MP_ROM_QSTR(MP_QSTR_add_ints), MP_ROM_PTR(&simplefunction_add_ints_obj) },
STATIC MP DEFINE CONST DICT (simplefunction module globals, simplefunction module
const mp_obj_module_t simplefunction_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&simplefunction_module_globals,
};
MP_REGISTER_MODULE(MP_QSTR_simplefunction, simplefunction_user_cmodule, MODULE_
→SIMPLEFUNCTION_ENABLED);
                                                                        (continues on next page)
```

#### 4.1 Header files

A module will not be too useful without at least two includes: py/obj.h, where all the relevant constants and macros are defined, and py/runtime.h, which contains the declaration of the interpreter. Many a time you will also need py/builtin.h, where the python built-in functions and modules are declared.

## 4.2 Defining user functions

After including the necessary headers, we define the function that is going to do the heavy lifting. By passing variables of mp\_obj\_t type, we make sure that the function will be able to accept values from the python console. If you happen to have an internal helper function in your module that is not exposed in python, you can pass whatever type you need. Similarly, by returning an object of mp\_obj\_t type, we make the results visible to the interpreter, i.e., we can assign the value returned to variables.

The downside of passing  $mp\_obj\_ts$  around is that you cannot simply assign them to usual C variables, i.e., when you want to operate on them, you have to extract the values first. This is why we have to invoke the  $mp\_obj\_get\_int()$  function, and conversely, before returning the results, we have to do a type conversion to  $mp\_obj\_t$  by calling  $mp\_obj\_new\_int()$ . These are the decoding/encoding steps that we discussed above.

#### 4.2.1 Referring to user functions

We have now a function that should be sort of OK (there is no error checking whatsoever, so you are at the mercy of the firmware, when, e.g., you try to pass a float to the function), but the python interpreter still cannot work with. For that, we have to turn our function into a function object. This is what happens in the line

```
STATIC MP_DEFINE_CONST_FUN_OBJ_2(simplefunction_add_ints_obj, simplefunction_add_ints);
```

The first argument of the macro is the name of the function object to which our actual function, the last argument, will be bound. Now, these MP\_DEFINE\_CONST\_FUN\_OBJ\_\* macros, defined in the header file py/obj.h (one more reason not to forget about py/obj.h), come in seven flavours, depending on what kind of, and how many arguments the function is supposed to take. In the example above, our function is meant to take two arguments, hence the 2 at the end of the macro name. Functions with 0 to 4 arguments can be bound in this way.

But what, if you want a function with more than four arguments, as is the case many a time in python? Under such circumstances, one can make use of the

```
STATIC MP_DEFINE_CONST_FUN_OBJ_VAR(obj_name, n_args_min, fun_name);
```

macro, where the second argument, an integer, gives the minimum number of arguments. The number of arguments can be bound from above by wrapping the function with

```
STATIC MP_DEFINE_CONST_FUN_OBJ_VAR_BETWEEN(obj_name, n_args_min, n_args_max, fun_

n_args_min, n_args_max, fun_
```

Later we will see, how we can define functions that can also take keyword arguments.

At this point, we are more or less done with the C implementation of our function, but we still have to expose it. This we do by adding a table, an array of key/value pairs to the globals of our module, and bind the table to the

\_module\_globals variable by applying the MP\_DEFINE\_CONST\_DICT macro. This table should have at least one entry, the name of the module, which is going to be stored in the string MP\_QSTR\_\_\_name\_\_.

These MP\_QSRT\_ items are the C representation of the python strings that come at the end of them. So, MP\_QSRT\_foo\_bar in C will be turned into a name, foo\_bar, in python. foo\_bar can be a constant, a function, a class, a type, etc., and depending on what is associated with it, different things will happen on the console, when foo\_bar is invoked. But the crucial point is that, if you want foo\_bar to have any meaning in python, then somewhere in your C code, you have to define MP\_QSRT\_foo\_bar.

The second key-value pair of the table is the pointer to the function that we have just implemented, and the name that we want to call the functions in python itself. So, in the example below, our simplefunction\_add\_ints function will be invoked, when we call add\_ints in the console.

This three-step pattern is common to all function implementations, so I repeat it here:

- 1. implement the function
- 2. then turn it into a function object (i.e., call the relevant form of MP\_DEFINE\_CONST\_FUN\_OBJ\_\*)
- 3. and finally, register the function in the name space of the module (i.e., add it to the module's globals table, and turn the table into a dictionary by applying MP\_DEFINE\_CONST\_DICT)

It doesn't matter, whether our function takes positional arguments, or keyword argument, or both, these are the required steps.

Having defined the function object, we have finally to register the module with

```
MP_REGISTER_MODULE(MP_QSTR_simplefunction, simplefunction_user_cmodule, MODULE_

SIMPLEFUNCTION_ENABLED);
```

This last line is particularly useful, because by setting the MODULE\_SIMPLEFUNCTION\_ENABLED variable in mpconfigport.h, you can selectively exclude modules from the linking, i.e., if in mpconfigport.h, which should be in the root directory of the port you want to compile for,

```
#define MODULE_SIMPLEFUNCTION_ENABLED (1)
```

then simplefunction will be included in the firmware, while with

```
#define MODULE_SIMPLEFUNCTION_ENABLED (0)
```

the module will be dropped, even though the source is in your modules folder. (N.B.: the module will still be compiled, but not linked.)

## 4.3 Compiling our module

The implementation is done, and we would certainly like to see some results. First we generate a makefile, which will be inserted in the module's own directory, simplefunction/.

https://github.com/v923z/micropython-usermod/tree/master/snippets/simplefunction/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/simplefunction.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

If mpconfigport.h is augmented with

```
#define MODULE_SIMPLEFUNCTION_ENABLED (1)
```

you should be able to compile the module above by calling

```
!make clean
!make USER_C_MODULES=../../usermod/snippets all
```

As mentioned earlier, if you do not want to touch anything in the micropython code base, you can simply pass the definition to make as

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_SIMPLEFUNCTION_

SENABLED=1 all
```

You will also note that we ran make clean before the compilation. This is always good practice, when you are developing your own modules.

We can then test the module as

```
%%micropython

import simplefunction

print(simplefunction.add_ints(123, 456))
```

```
579
```

What a surprise! It works! It works!

## 4.4 Compiling for the microcontroller

As pointed out at the very beginning, our first module was compiled for the unix port, and that it, why we set . . / . . / micropython/ports/unix/ as our working directory. In case, we would like to compile for the microcontroller, we would have to modify the mpconfigport.h file of the port (e.g., in micropython/ports/stm32/) as shown in Section *User modules*.

Next, in the compilation command, one has to specify the target board, e.g., pyboard, version 1.1, and probably the path to the cross-compiler, if that could not be installed system-wide. You would issue the make command in the directory of the port, e.g., micropython/ports/stm32/, and the path in the CROSS\_COMPILE argument must be either absolute, or given relative to micropython/ports/stm32/.

You will find your firmware under micropython/ports/stm32/build-PYBV11/firmware.dfu, and you can upload it by issuing

!python ../../tools/pydfu.py -u build-PYBV11/firmware.dfu

on the command line. More detailed explanation can be found under https://github.com/micropython/micropython/wiki/Pyboard-Firmware-Update.

#### Module constants

We have just seen, how we add a function to python. But functions are not the only objects that can be attached to a module, and of particular interest are constants. If for nothing else, you can give your module a version number. So, let us see, how that can be achieved.

Contstants, if they are true to their name, won't change at run time, hence, they can be stored in ROM. We have already seen this, because the globals table of our very first module kicked out with the line

```
{ MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_simplefunction) }
```

Here, the MP\_QSTR\_simplefunction was a constant, namely, the string simplefunction stored in ROM. This is why it is wrapped by the macro MP\_ROM\_QSTR. There are two other MP\_ROM macros defined in obj.h, namely, MP\_ROM\_INT, and MP\_ROM\_PTR.

## 5.1 Integer constants

It should not be a big surprise that the MP\_ROM\_INT macro generates ROM objects from integers. Thus, the following code will give you the magic constant 42:

```
#define MAGIC_CONSTANT 42
...
{ MP_ROM_QSTR(MP_QSTR_magic), MP_ROM_INT(MAGIC_CONSTANT) },
...
```

## 5.2 Strings

Now, in MP\_QSTR\_simplefunction, simplefunction is a well-behaved string, containing no special characters. But are we doomed, if we do want to print out a version string, which would probably look like 1.2.3, or something similar? And should we give up all hope, if our string contains an underscore? The answer to these questions is no, and no! This is, where the MP\_ROM\_PTR macro comes to the rescue.

In general, MP\_ROM\_PTR will take the address of an object, and convert it to a 32-bit unsigned integer. At run time, micropython works with this integer, if it has to access the constant. And this is exactly what happens in the second line of the globals table of simplefunction:

```
{ MP_ROM_QSTR(MP_QSTR_add_ints), MP_ROM_PTR(&simplefunction_add_ints_obj) },
```

we associated the string add\_ints (incidentally, also stored in ROM) with the 32-bit unsigned integer generated from the address of simplefunction\_add\_ints\_obj. So, the bottom line is, if we can somehow get hold of the address of an object, we can wrap it with MP\_ROM\_PTR, and we are done.

Thus, if we want to define a string constant, we have to convert it to something that has an address. The MP\_DEFINE\_STR\_OBJ of objstr.h does exactly that:

```
STATIC const MP_DEFINE_STR_OBJ(version_string_obj, "1.2.3");
```

takes 1.2.3 as a string, and turns is into a micropython object of type mp\_obj\_str\_t. After this, &version\_string\_obj can be passed to the MP\_ROM\_PTR macro.

## 5.3 Tuples

We don't have to be satisfied with integers and strings, we can definitely go further. There is a python type, the tuple, that is, by definition, constant (not mutable), and for this reason, we can easily define a tuple type module constant. objtuple.h defines mp\_rom\_obj\_tuple\_t for this purpose. This is a structure with three members, and looks like this:

The first member defines the base type of the object, the second is the number of elements of the tuple that we want to define, and the third is itself a structure, listing the tuple elements. The key point here is that we can apply the address-of operator to version\_tuple\_obj, and pass it to the MP\_ROM\_PTR macro.

https://github.com/v923z/micropython-usermod/tree/master/snippets/constants/constants.c

https://github.com/v923z/micropython-usermod/tree/master/snippets/constants/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/constants.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

One comment before trying out what we have just implemented: the module is definitely pathological. If all you need is a set of constants organised in some way, then you should write it in python. There is nothing to be gained by working in C, while python is much more flexible.

```
%%micropython -unix 1

import constants

print(constants.magic)
print(constants.__version__)
print(constants.version_tuple)
```

```
42
1.2.3
(1, '1.2.3')
```

5.3. Tuples 15

## Error handling

There will be cases, when something goes wrong, and you want to bail out in an elegant way. If bailing out, and elegance can be used in the same sentence, that is. Depending on what kind of difficulty you are facing, you can indicate this to the user in different ways, and there seems to be a divide between programmers as to whether one should return an error code, or do something else.

But in the python world, the most common method is to raise some sort of exception, and let the user handle the problem. In the following snippet, we will see a couple of ways of going about exceptions. We implement a single function that raises an exception, no matter what. When developing user-friendly code, that is as vicious as you can get, I guess.

First, the code listing:

https://github.com/v923z/micropython-usermod/tree/master/snippets/sillyerrors/sillyerrors.c

```
#include "py/obj.h"
#include "py/builtin.h"
#include "py/runtime.h"
#include <stdlib.h>
STATIC mp_obj_t mean_function(mp_obj_t error_code) {
   int e = mp_obj_get_int(error_code);
   if(e == 0) {
       mp_raise_msg(&mp_type_ZeroDivisionError, "thou shall not try to divide by 0_
→on a microcontroller!");
    } else if(e == 1) {
       mp_raise_msg(&mp_type_IndexError, "dude, that was a silly mistake!");
    } else if(e == 2) {
        mp_raise_TypeError("look, chap, you can't be serious!");
    } else if(e == 3) {
        mp_raise_OSError(e);
    } else if(e == 4) {
        char *buffer;
       buffer = malloc(100);
        sprintf(buffer, "you are really out of luck today: error code d", e);
       mp_raise_NotImplementedError(buffer);
```

Now, not all exceptions are created equal. Some are more exceptional than the others: ValueError, TypeError, OSError, and NotImplementedError can be raised with the syntax

```
mp_raise_ValueError("wrong value");
```

which will, in addition to raising the exception at the C level (i.e., interrupting the execution of the code), also return a pretty traceback:

```
Traceback (most recent call last):
   File "<stdin>", line 1, in <module>
   ValueError: wrong value
```

with the error message that we supplied to the mp\_raise\_ValueError function. If you want to have a trace-back message that is not a compile-time constant, you could deal with the problem as in case 4 in the function mean\_function. Such a message might be useful, if the nature of the exception is somehow related to a quantity that is not known at compile time, e.g., if you have a function that should not ever run, if the up-time is shorter than some predefined value. Of course, one can just say that the "microcontroller hasn't run long enough yet", and this is a pretty good constant string, but perhaps we can give the user a bit more information, if we can also indicate, how much time is still missing.

Other exceptions can be raised as in the e == 1 case, with the mp\_raise\_msg(&mp\_type\_IndexError, "dude, that was a silly mistake!") function. Here one also has to specify the type of the exception, which is always of the form mp\_type\_. A complete list can be found in obj.h.

Incidentally, mp\_raise\_ValueError, mp\_raise\_TypeError, and mp\_raise\_NotImplementedError are nothing but a wrapper for mp\_raise\_msg, which in turn is a wrapper for nlr\_raise of nlr.c/nlr.h. The OSError is somewhat curious in this respect, because it is raised directly through nlr\_raise, and its argument is not a string, but an integer error code. All these wrappers are defined in runtime.c, by the way.

In our ultimate mean function, we raised a lot of exceptions by now, but we still have to return some value, because the function signature stipulates that, and the compiler would be unsatisfied otherwise, even though code execution will actually never reach the return statement. Since we are in denial mode anyway, I cast my vote for a return value of mp\_const\_false. mp\_const\_none was the other candidate, but ended up as the runner-up.

#### I think, it is high time to compile our code.

import sillyerrors

print(sillyerrors.mean(4))

```
https://github.com/v923z/micropython-usermod/tree/master/snippets/sillyerrors/micropython.mk
USERMODULES_DIR := $(USERMOD_DIR)
# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/sillyerrors.c
CFLAGS_USERMOD += -I$ (USERMODULES_DIR)
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_SILLYERRORS_
→ENABLED=1 all
%%micropython
import sillyerrors
print(sillyerrors.mean(0))
Traceback (most recent call last):
 File "/dev/shm/micropython.py", line 3, in <module>
ZeroDivisionError: thou shall not try to divide by 0 on a microcontroller!
%%micropython
import sillyerrors
print(sillyerrors.mean(1))
Traceback (most recent call last):
 File "/dev/shm/micropython.py", line 3, in <module>
IndexError: dude, that was a silly mistake!
%%micropython
import sillyerrors
print(sillyerrors.mean(2))
Traceback (most recent call last):
 File "/dev/shm/micropython.py", line 3, in <module>
TypeError: look, chap, you can't be serious!
%%micropython
import sillyerrors
print(sillyerrors.mean(3))
Traceback (most recent call last):
 File "/dev/shm/micropython.py", line 3, in <module>
OSError: 3
%%micropython
```

```
19
```

```
Traceback (most recent call last):
   File "/dev/shm/micropython.py", line 3, in <module>
NotImplementedError: you are really out of luck today: error code 4
```

One can't but wonder, why we had to invoke our mean function in four separate statements, and why we couldn't execute everything in a nice nifty package like

```
import sillyerrors
print(sillyerrors.mean(0))
print(sillyerrors.mean(1))
print(sillyerrors.mean(2))
print(sillyerrors.mean(3))
print(sillyerrors.mean(4))
```

```
Traceback (most recent call last):
File "/dev/shm/micropython.py", line 3, in <module>
ZeroDivisionError: you shall not try to divide by 0 on a microcontroller!
```

Well, we could have, but since we specifically raised an exception in the first statement, our code would never have gotten beyond

```
sillyerror.mean(0)
```

After all, this is what exceptions do: they interrupt the execution of the code.

## Argument parsing

In practically all cases, you will have to inspect the arguments of your function. Even if you can resort to functions in the micropython implementation, that simply means that the burden of inspection was taken off your shoulders, but not that the inspection does not happen at all. In this section, we are going to see what we can do with both positional, and keyword arguments, and how we can retrieve their values.

### 7.1 Positional arguments

#### 7.1.1 Known number of arguments

A known number of positional arguments are pretty much a done deal: we have seen how to get the C values of such arguments: in our very first module, we called  $mp\_obj\_get\_int()$ , because we wanted to sum two integers. Should we like to work with float, we could call  $mp\_obj\_get\_float()$ . (This function will properly work, if the value is an integer, by the way.)

If we have a more complicated construct, like a tuple or a list, we can turn the argument into a pointer with

```
mp_obj_t some_function(mp_obj_t object_in) {
    mp_obj_tuple_t *object = MP_OBJ_TO_PTR(object_in);
    ...
}
```

and continue with \*object. We can then retrieve the tuple's structure members with object->items (the elements in the tuple), and object->len (the length of the tuple). This procedure works even with newly-defined object types. A complete example can be found in Section *Creating new types*:

```
typedef struct _vector_obj_t {
   mp_obj_base_t base;
   float x, y, z;
} vector_obj_t;
```

```
mp_obj_t some_function(mp_obj_t object_in) {
    vector_obj_t *vector = MP_OBJ_TO_PTR(object_in);
    ...
}
```

#### 7.1.2 Unknown number of arguments

Now, we pointed out that the macros generating the function objects can be of the form

```
MP_DEFINE_CONST_FUN_OBJ_VAR_BETWEEN(some_function_obj, n_argmin, n_argmax, some_

$\to$function);
```

In such a case, we surely can't just enumerate the arguments of the function without any checks, especially, that we don't even know how far we have to go, and the behaviour of the function can depend on the number of arguments. What shall we do in such an instance?

We have to reckon that the signature of a function with a variable number of arguments looks like

```
mp_obj_t some_function(size_t n_args, const mp_obj_t *args) {
    if (n_args == 2) {
        ...
    }
    ...
}
```

and the first argument of the C function will store the number of positional arguments of the python function. Once n\_args is known, we are set. It is important to note that the work is done by the MP\_DEFINE\_CONST\_FUN\_OBJ\_VAR\_BETWEEN macro, we do not have to set up the C function in any particular way.

Here is a small example that will drive this point home.

https://github.com/v923z/micropython-usermod/tree/master/snippets/vararg/vararg.c

```
#include "py/obj.h"
#include "py/runtime.h"
STATIC mp_obj_t vararg_function(size_t n_args, const mp_obj_t *args) {
   if(n_args == 0) {
       printf("no arguments supplied\n");
    } else if(n_args == 1) {
       printf("this is a %lu\n", mp_obj_get_int(args[0]));
    } else if(n_args == 2) {
       printf("hm, we will sum them: lu\n", mp_obj_get_int(args[0]) + mp_obj_get_
\rightarrowint(args[1]));
   } else if(n_args == 3) {
       printf("Look at that! A triplet: lu, lu, lu, lu, mp_obj_get_int(args[0]),
→mp_obj_get_int(args[1]), mp_obj_get_int(args[2]));
   return mp_const_none;
STATIC MP_DEFINE_CONST_FUN_OBJ_VAR_BETWEEN(vararg_function_obj, 0, 3, vararg_
→function);
```

https://github.com/v923z/micropython-usermod/tree/master/snippets/vararg/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/vararg.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
%%micropython

import vararg

vararg.vararg()

vararg.vararg(1)

vararg.vararg(10, 20)

vararg.vararg(1, 22, 333)
```

```
no arguments supplied
this is a 1
hm, we will sum them: 30
Look at that! A triplet: 1, 22, 333
```

## 7.2 Working with strings

We have discussed numerical values in micropython at length. We know how we convert an mp\_obj\_t object to a native C type, and we also know, how we can turn an integer or float into an mp\_obj\_t, and return it at the end of the function. The key components were the mp\_obj\_get\_int(), mp\_obj\_new\_int(), and mp\_obj\_get\_float(), and mp\_obj\_new\_float() functions. Later we will see, what we can do with various iterables, like lists and tuples, but before that, I would like to explain, how one handles strings. (Strings are also iterables in python, by the way, however, they also have a native C equivalent.)

At the beginning, we said that in micropython, almost everything is an mp\_obj\_t object. Strings are no exception: however, the mp\_obj\_t that denotes the string does not store its value, but a pointer to the memory location, where the characters are stored. The reason is rather trivial: the mp\_obj\_t has a size of 8 bytes, hence, the object can't possibly store a string that is longer than 7 bytes. (The same applies to more complicated objects, e.g., lists, or tuples.)

Now, the procedure of working with the string would kick out with retrieving the pointer, and then we could increment its value till we encounter the \0 character, which indicates that the string has ended. Fortunately, micropython has a handy macro for retrieving the string's value and its length, so we don't have to concern ourselves with the really low-level stuff. For the string utilities, we should include py/objstr.h (for the micropython things), and string.h (for stropy). py/objstr.c contains a number of tools for string manipulation. Before you try to implement your own functions, it might be worthwhile to check that out. You might find something useful.

Our next module is going to take a single string as an argument, print out its length (you already know, how to return the length, don't you?), and return the contents backwards. All this in 33 lines.

https://github.com/v923z/micropython-usermod/tree/master/snippets/stringarg/stringarg.c

```
#include <string.h>
#include "py/obj.h"
#include "py/runtime.h"
#include "py/objstr.h"
#define byteswap(a,b) char tmp = a; a = b; b = tmp;
STATIC mp_obj_t stringarg_function(const mp_obj_t o_in) {
   mp_check_self(mp_obj_is_str_or_bytes(o_in));
   GET_STR_DATA_LEN(o_in, str, str_len);
   printf("string length: %lu\n", str_len);
   char out_str[str_len];
   strcpy(out_str, (char *)str);
   for(size_t i=0; i < (str_len-1)/2; i++) {</pre>
       byteswap(out_str[i], out_str[str_len-i-1]);
   return mp_obj_new_str(out_str, str_len);
STATIC MP_DEFINE_CONST_FUN_OBJ_1(stringarg_function_obj, stringarg_function);
STATIC const mp_rom_map_elem_t stringarg_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_stringarg) },
    { MP_ROM_QSTR(MP_QSTR_stringarg), MP_ROM_PTR(&stringarg_function_obj) },
};
STATIC MP_DEFINE_CONST_DICT(stringarg_module_globals, stringarg_module_globals_table);
const mp_obj_module_t stringarg_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&stringarg_module_globals,
};
MP_REGISTER_MODULE(MP_QSTR_stringarg, stringarg_user_cmodule, MODULE_STRINGARG_
→ENABLED);
```

The macro defined in objstr.h takes three arguments, out of which only the first one is actually defined. The other two are defined in the macro itself. So, in the line

```
GET_STR_DATA_LEN(o_in, str, str_len);
```

only o\_in is known at the moment the macro is called, str, which will be a pointer to type character, and str\_len, which is of type size\_t, and holds the length of the string, are created by GET\_STR\_DATA\_LEN itself. This is, why we can later stick str\_len, and str into print statements, though, we never declared these variables.

After GET\_STR\_DATA\_LEN has been called, we are in C land. First, we print out the length, then reverse the string. But why can't we do the string inversion on the original string, and why do we have to declare a new variable, out\_str? The reason for that is that the GET\_STR\_DATA\_LEN macro declares a const string, which we can't

change anymore, so we have to copy the content (stropy from string.h), and swap the bytes in out\_str. When doing so, we should keep in mind that the very last byte in the string is the termination character, hence, we exchange the ith position with the  $str_len-i-1$ th position. If you fail to notice the -1, you'll end up with an empty string: even though the byte swapping would run without complaints, the very first byte would be equal to  $\setminus 0$ .

At the very end, we return from our function with a call to mp\_obj\_new\_str, which creates a new mp\_obj\_t object that points to the content of the string. And we are done! All there is left to do is compilation. Let's take care of that!

https://github.com/v923z/micropython-usermod/tree/master/snippets/stringarg/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/stringarg.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_STRINGARG_

SENABLED=1 all
```

```
%%micropython

import stringarg

print(stringarg.stringarg('...krow ta eludom gragnirts eht'))
```

```
string length: 31 the stringarg module at work...
```

## 7.3 Keyword arguments

One of the most useful features of python is that functions can accept positional as well as keyword arguments, thereby providing a very flexible and instructive function interface. (Instructive, insofar as the intent of a variable is very explicit, even at the user level.) In this subsection, we will learn how the processing of keyword arguments is done. Our new module will be the sexed-up version of our very first one, where we added two integers. We will do the same here, except that the second argument will be a keyword, and will assume a default value of 0.

Before jumping into the implementation, we should contemplate the task for a second. It does not matter, whether we have positional or keyword arguments, at one point, the interpreter has to turn all arguments into a deterministic sequence of objects. We stipulate this sequence in the constant variable called allowed\_args[]. This is an array of type mp\_arg\_t, which is nothing but a structure with two uint16 values, and a union named mp\_arg\_val\_t. This union holds the default value and the type of the variable that we want to pass. The mp\_arg\_t structure, defined in runtime.h, looks like this:

```
typedef struct _mp_arg_t {
    uint16_t qst;
    uint16_t flags;
    mp_arg_val_t defval;
} mp_arg_t;
```

The last member, mp\_arg\_val\_t is

```
typedef union _mp_arg_val_t {
   bool u_bool;
   mp_int_t u_int;
   mp_obj_t u_obj;
   mp_rom_obj_t u_rom_obj;
} mp_arg_val_t;
```

Keyword arguments come in three flavours: MP\_ARG\_BOOL, MP\_ARG\_INT, and MP\_ARG\_OBJ.

#### 7.3.1 Keyword arguments with numerical values

And now the implementation:

https://github.com/v923z/micropython-usermod/tree/master/snippets/keywordfunction/keywordfunction.c

```
#include <stdio.h>
#include "py/obj.h"
#include "py/runtime.h"
#include "py/builtin.h"
STATIC mp_obj_t keywordfunction_add_ints(size_t n_args, const mp_obj_t *pos_args, mp_
→map_t *kw_args) {
    static const mp_arg_t allowed_args[] = {
       { MP_QSTR_a, MP_ARG_REQUIRED | MP_ARG_INT, {.u_int = 0} },
        { MP_QSTR_b, MP_ARG_KW_ONLY | MP_ARG_INT, {.u_int = 0} },
   } ;
   mp_arg_val_t args[MP_ARRAY_SIZE(allowed_args)];
   mp_arg_parse_all(n_args, pos_args, kw_args, MP_ARRAY_SIZE(allowed_args), allowed_
→args, args);
   int16_t = args[0].u_int;
   int16_t b = args[1].u_int;
   printf("a = %d, b = %d\n", a, b);
   return mp_obj_new_int(a + b);
}
STATIC MP_DEFINE_CONST_FUN_OBJ_KW (keywordfunction_add_ints_obj, 1, keywordfunction_
→add_ints);
STATIC const mp_rom_map_elem_t keywordfunction_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_keywordfunction) },
    { MP_ROM_QSTR(MP_QSTR_add_ints), (mp_obj_t)&keywordfunction_add_ints_obj },
} ;
STATIC MP_DEFINE_CONST_DICT(keywordfunction_module_globals, keywordfunction_module_
→globals_table);
const mp_obj_module_t keywordfunction_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&keywordfunction_module_globals,
};
MP_REGISTER_MODULE(MP_QSTR_keywordfunction, keywordfunction_user_cmodule, MODULE_
→ KEYWORDFUNCTION_ENABLED);
```

One side effect of a function with keyword arguments is that we do not have to care about the arguments in the C implementation: the argument list is always the same, and it is passed in by the interpreter: the number of arguments

of the python function, an array with the positional arguments, and a map for the keyword arguments.

After parsing the arguments with mp\_arg\_parse\_all, whatever was at the zeroth position of allowed\_args[] will be called args[0], the object at the first position of allowed\_args[] will be turned into args[1], and so on.

This is, where we also define, what the name of the keyword argument is going to be: whatever comes after MP\_QSTR\_. But hey, presto! The name should be an integer with 16 bits, shouldn't it? After all, this is the first member of mp\_arg\_t. So what the hell is going on here? Well, for the efficient use of RAM, all MP\_QSTRs are turned into unint16\_t internally. This applies not only to the names in functions with keyword arguments, but also for module and function names, in the \_module\_globals\_table[].

The second member of the mp\_arg\_t structure is the flags that determine, e.g., whether the argument is required, if it is of integer or mp\_obj\_t type, and whether it is a positional or a keyword argument. These flags can be combined by ORing them, as we have done in the example above.

The last member in mp\_arg\_t is the default value. Since this is a member variable, when we make use of it, we have to extract the value by adding .u\_int to the argument.

When turning our function into a function object, we have to call a special macro, MP DEFINE CONST FUN OBJ KW, defined in obj.h, which is somewhat similar MP DEFINE CONST FUN OBJ VAR: in addition to the function object and the function, one also has to specify the minimum number of arguments in the python function.

Other examples on passing keyword arguments can be found in some of the hardware implementation files, e.g., ports/stm32/pyb\_i2c.c, or ports/stm32/pyb\_spi.c.

Now, let us see, whether we can add two numbers here.

https://github.com/v923z/micropython-usermod/tree/master/snippets/keywordfunction/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR) / keywordfunction.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_KEYWORDFUNCTION_
→ENABLED=1 all
```

```
%%micropython

import keywordfunction
print(keywordfunction.add_ints(-3, b=4))
print(keywordfunction.add_ints(3))
```

```
a = -3, b = 4
1
a = 3, b = 0
3
```

As advertised, both function calls do what they were supposed to do: in the first case, b assumes the value of 4, while in the second case, it takes on 0, even though we didn't supply anything to the function.

#### 7.3.2 Arbitrary keyword arguments

We have seen how integer values can be extracted from keyword arguments, but unfortunately, that method is going to get you only that far. What if we want to pass something more complicated, in particular a string, or a tuple, or some other non-trivial python type?

A simple solution could be to implement the C function without keywords at all, and do the parsing in python. After all, it is highly unlikely that parsing would be expensive in comparison to the body of the function. But perhaps, you have your reasons for not going down that rabbit hole.

For such cases, we can still resort to objects of type .u\_rom\_obj. In order to experiment with the possibilities, in the next module, we define a function that simply returns the values passed to it. The input arguments are going to be a single positional argument, and four keyword arguments with type int, string, tuple, and float.

https://github.com/v923z/micropython-usermod/tree/master/snippets/arbitrarykeyword/arbitrarykeyword.c

```
#include <stdio.h>
#include "py/obj.h"
#include "py/objlist.h"
#include "py/runtime.h"
#include "py/builtin.h"
// This is lifted from objfloat.c, because mp_obj_float_t is not exposed there (there,
→is no header file)
typedef struct _mp_obj_float_t {
   mp_obj_base_t base;
   mp_float_t value;
} mp_obj_float_t;
const mp_obj_float_t my_float = {{&mp_type_float}, 0.987};
const mp_rom_obj_tuple_t my_tuple = {
    {&mp_type_tuple},
    3,
    {
        MP_ROM_INT(0),
        MP_ROM_QSTR(MP_QSTR_float),
        MP_ROM_PTR(&my_float),
    },
};
STATIC mp_obj_t arbitrarykeyword_print(size_t n_args, const mp_obj_t *pos_args, mp_
→map_t *kw_args) {
    static const mp_arg_t allowed_args[] = {
        { MP_QSTR_a, MP_ARG_INT, {.u_int = 0} },
        { MP_QSTR_b, MP_ARG_KW_ONLY | MP_ARG_INT, {.u_int = 1} },
        { MP_QSTR_c, MP_ARG_KW_ONLY | MP_ARG_OBJ, {.u_rom_obj = MP_ROM_QSTR(MP_QSTR_
\hookrightarrowfloat)}},
        { MP_QSTR_d, MP_ARG_KW_ONLY | MP_ARG_OBJ, {.u_rom_obj = MP_ROM_PTR(&my_float)}
→ },
        { MP_QSTR_e, MP_ARG_KW_ONLY | MP_ARG_OBJ, {.u_rom_obj = MP_ROM_PTR(&my_tuple)}
→ },
   } ;
   mp_arg_val_t args[MP_ARRAY_SIZE(allowed_args)];
   mp_arg_parse_all(1, pos_args, kw_args, MP_ARRAY_SIZE(allowed_args), allowed_args,_
→args);
   mp_obj_t tuple[5];
```

```
tuple[0] = mp_obj_new_int(args[0].u_int); // a
    tuple[1] = mp_obj_new_int(args[1].u_int); // b
    tuple[2] = args[2].u_obj; // c
    tuple[3] = args[3].u_obj; // d
    tuple[4] = args[4].u_obj; // e
    return mp_obj_new_tuple(5, tuple);
STATIC MP_DEFINE_CONST_FUN_OBJ_KW(arbitrarykeyword_print_obj, 1, arbitrarykeyword_
→print);
STATIC const mp_rom_map_elem_t arbitrarykeyword_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR__name__), MP_ROM_QSTR(MP_QSTR_arbitrarykeyword) },
    { MP_ROM_QSTR(MP_QSTR_print), (mp_obj_t)&arbitrarykeyword_print_obj },
};
STATIC MP_DEFINE_CONST_DICT(arbitrarykeyword_module_globals, arbitrarykeyword_module_
\rightarrowglobals_table);
const mp_obj_module_t arbitrarykeyword_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&arbitrarykeyword_module_globals,
};
MP_REGISTER_MODULE(MP_QSTR_arbitrarykeyword, arbitrarykeyword_user_cmodule, MODULE_
→ARBITRARYKEYWORD_ENABLED);
```

Before compiling the code, let us think a bit about what is going on here. The first argument, a, is straightforward: that is a positional argument, and we deal with that as we did in the last example. The same applies to the second argument, b, which is our first keyword argument with an integer default value.

Matters become more interesting with the third argument, c: that is supposed to be a string, whose default value is "float". We generate the respective C representation by prepending the MP\_QSTR\_. At this point, we have a string, but we still can't assign it as a default value. We do that by first applying the MP\_ROM\_QSTR macro, and assigning the results to the .u\_rom\_obj member of the mp\_arg\_t structure. You most certainly will want to inspect the value at one point. We have already discussed the drill in *Working with strings*.

The fourth argument, d, is meant to be a float. Since there is no equivalent of a float in the mp\_arg\_t structure, we have to turn our number into an MP\_ROM\_PTR, so we have to retrieve the address of the float object. To this end, we define the number in the line

```
const mp_obj_float_t my_float = {{&mp_type_float}, 0.987};
```

Note that since mp\_obj\_float\_t is not exposed in objfloat.c, where it is defined, we had to copy the type declaration. This is certainly not very elegant, but desperate times call for desperate measures. In addition, we also have to declare my\_float as a constant. The reason for this is that we have to assure the compiler that this value is not going to change in the future, so that it can be saved into the read-only memory.

The last argument, e, is a tuple, which has a special type for such cases, namely, the <code>mp\_rom\_obj\_tuple\_t</code>, so we define <code>my\_tuple</code> as an <code>mp\_rom\_obj\_tuple\_t</code> object, with a base type of <code>mp\_type\_tuple</code>, and three elements, an integer, a string, and a float. The elements go into the tuple as if they were assigned to the <code>.u\_rom\_obj</code> members directly, hence the <code>macros MP\_ROM\_INT</code>, <code>MP\_ROM\_QSTR</code>, and <code>MP\_ROM\_PTR</code>.

When we return the default values at the end of our function, we declare an array of type mb\_obj\_t, and of length 5, assign the elements, and turn the array into a tuple with mp\_obj\_new\_tuple.

One final comment to this section: I referred to our function as returning the values of the arguments, yet, I called it print. Had I called the function return, it wouldn't have worked for the simple reason, that return is a keyword

of the language itself. As a friendly advice, do not try to override that!

Having thoroughly discussed the code, we should compile it, and see what happens.

https://github.com/v923z/micropython-usermod/tree/master/snippets/arbitrarykeyword/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR) / arbitrarykeyword.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_ARBITRARYKEYWORD_

DENABLED=1 all
```

```
%%micropython

import arbitrarykeyword

print(arbitrarykeyword.print(1, b=123))
print(arbitrarykeyword.print(-35, b=555, c='foo', d='bar', e=[1, 2, 3]))
```

```
(1, 123, 'float', 0.98699999999999, (0, 'float', 0.9869999999999))
(-35, 555, 'foo', 'bar', [1, 2, 3])
```

We should note that the particular definition of the float constant will work in the A, and B object representations only. If your micropython platform uses either the C, or the D representation, your code will still compile, but you'll be surprised by the results.

## Working with classes

Of course, python would not be python without classes. A module can also include the implementation of classes. The procedure is similar to what we have already seen in the context of standard functions, except that we have to define a structure that holds at least a string with the name of the class, a pointer to the initialisation and printout functions, and a local dictionary. A typical class structure would look like

The locals dictionary, .locals\_dict, contains all user-facing methods and constants of the class, while the simpleclass\_type structure's name member is what our class is going to be called. .print is roughly the equivalent of \_\_str\_\_, and .make\_new is the C name for \_\_init\_\_.

In order to see how this all works, we are going to implement a very simple class, which holds two integer variables, and has a method that returns the sum of these two variables. In python, a possible realisation could look like this:

```
class myclass:

def __init__(self, a, b):
    self.a = a
    self.b = b

def mysum(self):
    return self.a + self.b
```

```
A = myclass(1, 2)
A.mysum()
```

```
3
```

In addition to the class implementation above and in order to show how class methods and regular functions can live in the same module, we will also have a function, which is not bound to the class itself, and which adds the two components in the class, i.e., that is similar to

```
def add(class_instance):
    return class_instance.a + class_instance.b
add(A)
```

```
3
```

(Note that retrieving values from the class in this way is not exactly elegant, nor is it pythonic. We would usually implement a getter method for that.)

https://github.com/v923z/micropython-usermod/tree/master/snippets/simpleclass/simpleclass.c

```
#include <stdio.h>
#include "py/runtime.h"
#include "py/obj.h"
typedef struct _simpleclass_myclass_obj_t {
   mp_obj_base_t base;
   int16_t a;
   int16_t b;
} simpleclass_myclass_obj_t;
const mp_obj_type_t simpleclass_myclass_type;
STATIC void myclass_print(const mp_print_t *print, mp_obj_t self_in, mp_print_kind_t_
⇒kind) {
    (void) kind;
   simpleclass_myclass_obj_t *self = MP_OBJ_TO_PTR(self_in);
   mp_print_str(print, "myclass(");
   mp_obj_print_helper(print, mp_obj_new_int(self->a), PRINT_REPR);
   mp_print_str(print, ", ");
   mp_obj_print_helper(print, mp_obj_new_int(self->b), PRINT_REPR);
   mp_print_str(print, ")");
STATIC mp_obj_t myclass_make_new(const mp_obj_type_t *type, size_t n_args, size_t n_
→kw, const mp_obj_t *args) {
   mp_arg_check_num(n_args, n_kw, 2, 2, true);
   simpleclass_myclass_obj_t *self = m_new_obj(simpleclass_myclass_obj_t);
    self->base.type = &simpleclass_myclass_type;
    self->a = mp_obj_get_int(args[0]);
   self->b = mp_obj_get_int(args[1]);
   return MP_OBJ_FROM_PTR(self);
}
```

```
// Class methods
STATIC mp_obj_t myclass_sum(mp_obj_t self_in) {
    simpleclass_myclass_obj_t *self = MP_OBJ_TO_PTR(self_in);
    return mp_obj_new_int(self->a + self->b);
MP_DEFINE_CONST_FUN_OBJ_1 (myclass_sum_obj, myclass_sum);
STATIC const mp_rom_map_elem_t myclass_locals_dict_table[] = {
    { MP_ROM_QSTR(MP_QSTR_mysum), MP_ROM_PTR(&myclass_sum_obj) },
};
STATIC MP_DEFINE_CONST_DICT(myclass_locals_dict, myclass_locals_dict_table);
const mp_obj_type_t simpleclass_myclass_type = {
    { &mp_type_type },
    .name = MP_QSTR_simpleclass,
    .print = myclass_print,
    .make_new = myclass_make_new,
    .locals_dict = (mp_obj_dict_t*)&myclass_locals_dict,
};
// Module functions
STATIC mp_obj_t simpleclass_add(const mp_obj_t o_in) {
    simpleclass_myclass_obj_t *class_instance = MP_OBJ_TO_PTR(o_in);
    return mp_obj_new_int(class_instance->a + class_instance->b);
MP_DEFINE_CONST_FUN_OBJ_1(simpleclass_add_obj, simpleclass_add);
STATIC const mp_map_elem_t simpleclass_globals_table[] = {
    { MP_OBJ_NEW_QSTR(MP_QSTR___name__), MP_OBJ_NEW_QSTR(MP_QSTR_simpleclass) },
    { MP_OBJ_NEW_QSTR(MP_QSTR_myclass), (mp_obj_t)&simpleclass_myclass_type },
    { MP_OBJ_NEW_QSTR(MP_QSTR_add), (mp_obj_t)&simpleclass_add_obj },
};
STATIC MP_DEFINE_CONST_DICT (
   mp_module_simpleclass_globals,
    simpleclass_globals_table
);
const mp_obj_module_t simpleclass_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&mp_module_simpleclass_globals,
};
MP_REGISTER_MODULE(MP_QSTR_simpleclass, simpleclass_user_cmodule, MODULE_SIMPLECLASS_
→ENABLED);
```

One more thing to note: the functions that are pointed to in simpleclass\_myclass\_type are not registered with the macro MP\_DEFINE\_CONST\_FUN\_OBJ\_VAR or similar. The reason for this is that this happens automatically: myclass\_print does not require user-supplied arguments beyond self, so it is known what the signature should look like. In myclass\_make\_new, we inspect the argument list, when calling

```
mp_arg_check_num(n_args, n_kw, 2, 2, true);
```

so, again, there is no need to turn our function into a function object.

#### 8.1 Printing class properties

In my\_print, instead of the standard the C function printf, we made use of mp\_print\_str, and mp\_obj\_print\_helper, which are options in this case. Both take print as their first argument. The value of print is supplied by the .print method of the class itself. The second argument is a string (in the case of mp\_print\_str), or a micropython object (for mp\_obj\_print\_helper). In addition, mp\_obj\_print\_helper takes a pre-defined constant, PRINT\_REPR as its third argument. By resorting to these micropython printing functions, we can make certain that the output is formatted nicely, independent of the platform. Whenever print is available, these function should be used instead of printf. For debugging purposes, printf is also fine. More on the subject can be found in mpprint.c.

https://github.com/v923z/micropython-usermod/tree/master/snippets/simpleclass/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR) / simpleclass.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_SIMPLECLASS_
→ENABLED=1 all
```

```
%%micropython

import simpleclass
a = simpleclass.myclass(2, 3)
print(a)
print(a.mysum())
```

```
myclass(2, 3)
5
```

#### 8.2 Special methods of classes

Python has a number of special methods, which will make a class behave as a native object. So, e.g., if a class implements the \_\_add\_\_(self, other) method, then instances of that class can be added with the + operator. Here is an example in python:

```
class Adder:
    def __init__(self, value):
        self.value = value

    def __add__(self, other):
        self.value = self.value + other.value
        return self

a = Adder(1)
b = Adder(2)
```

```
c = a + b c.value
```

```
3
```

Note that, while the above example is not particularly useful, it proves the point: upon calling the + operator, the values of a, and b are added. If we had left out the implementation of the \_\_add\_\_ method, the python interpreter would not have a clue as to what to do with the objects. You can see for yourself, how sloppiness makes itself manifest:

```
class Adder:
    def __init__(self, value):
        self.value = value

a = Adder(1)
b = Adder(2)

c = a + b
c.value
```

Indeed, we do not support the + operator.

Now, the problem is that in the C implementation, these special methods have to be treated in a special way. The naive approach would be to add the pointer to the function to the locals dictionary as

but that would not work. Well, this is not entirely true: the + operator would not work, but one could still call the method explicitly as

```
a = Adder(1)
b = Adder(2)
a.__add__(b)
```

Before we actually add the + operator to our class, we should note that there are two kinds of special methods, namely the unary and the binary operators.

In the first group are those, whose sole argument is the class instance itself. Two frequently used cases are the length operator, len, and bool. So, e.g., if your class implements the \_\_len\_\_(self) method, and the method returns an integer, then you can call the len function in the console

```
len (myclass)
```

In the second category of operators are those, which require a left, as well as a right hand side: the operand on the left hand side is the class instance itself, while the right hand side can, in principle, be another instance of the same class, or some other type. An example for this was the <u>\_\_add\_\_</u> method in our Adder class. To prove that the right hand side needn't be of the same type, think of the *multiplication* of lists:

```
[1, 2, 3]*5
```

```
[1, 2, 3, 1, 2, 3, 1, 2, 3, 1, 2, 3]
```

is perfectly valid, and has a well-defined meaning. It is the responsibility of the C implementation to inspect the right hand side, and decide how to interpret the operation. The complete list of unary, as well as binary operators can be found in runtime.h.

The module below implements five special methods altogether. Two unary, namely, bool, and len, and three binary operators, ==, +, and  $\star$ . Since the addition and multiplication will return a new instance of specialclass\_myclass, we define a new function, create\_new\_class, that, well, creates a new instance of specialclass\_myclass, and initialises the members with the two input arguments. This function will also be called in the class initialisation function, myclass\_make\_new, immediately after the argument checking.

When implementing the operators, we have to keep a couple of things in mind. First, the specialclass\_myclass\_type has to be extended with the two methods, .unary\_op, and .binary\_op, where .unary\_op is equal to the function that handles the unary operation (specialclass\_unary\_op in the example below), and .binary\_op is equal to the function that deals with binary operations (specialclass\_binary\_op below). These two functions have the signatures

```
STATIC mp_obj_t specialclass_unary_op(mp_unary_op_t op, mp_obj_t self_in)
```

and

```
STATIC mp_obj_t specialclass_binary_op(mp_binary_op_t op, mp_obj_t lhs, mp_obj_t rhs)
```

respectively, and we have to inspect the value of op in the implementation. This is done in the two switch statements.

Second, if .unary\_op, or .binary\_op are defined for the class, then the handler function must have an implementation of all possible operators. This doesn't necessarily mean that you have to have all cases in the switch, but if you haven't, then there must be a default case with a reasonable return value, e.g., MP\_OBJ\_NULL, or mp\_const\_none, so as to indicate that that particular method is not available.

https://github.com/v923z/micropython-usermod/tree/master/snippets/specialclass/specialclass.c

```
(void) kind;
    specialclass_myclass_obj_t *self = MP_OBJ_TO_PTR(self_in);
   mp_print_str(print, "myclass(");
   mp_obj_print_helper(print, mp_obj_new_int(self->a), PRINT_REPR);
   mp_print_str(print, ", ");
   mp_obj_print_helper(print, mp_obj_new_int(self->b), PRINT_REPR);
   mp_print_str(print, ")");
mp_obj_t create_new_myclass(uint16_t a, uint16_t b) {
   specialclass_myclass_obj_t *out = m_new_obj(specialclass_myclass_obj_t);
   out->base.type = &specialclass_myclass_type;
   out->a = a;
   out->b = b;
   return MP_OBJ_FROM_PTR(out);
}
STATIC mp_obj_t myclass_make_new(const mp_obj_type_t *type, size_t n_args, size_t n_
→kw, const mp_obj_t *args) {
   mp_arg_check_num(n_args, n_kw, 2, 2, true);
   return create_new_myclass(mp_obj_get_int(args[0]), mp_obj_get_int(args[1]));
}
STATIC const mp_rom_map_elem_t myclass_locals_dict_table[] = {
STATIC MP_DEFINE_CONST_DICT(myclass_locals_dict, myclass_locals_dict_table);
STATIC mp_obj_t specialclass_unary_op(mp_unary_op_t op, mp_obj_t self_in) {
    specialclass_myclass_obj_t *self = MP_OBJ_TO_PTR(self_in);
    switch (op) {
        case MP_UNARY_OP_BOOL: return mp_obj_new_bool((self->a > 0) && (self->b > 0));
        case MP_UNARY_OP_LEN: return mp_obj_new_int(2);
        default: return MP_OBJ_NULL; // operator not supported
    }
}
STATIC mp_obj_t specialclass_binary_op(mp_binary_op_t op, mp_obj_t lhs, mp_obj_t rhs)
\hookrightarrow {
   specialclass_myclass_obj_t *left_hand_side = MP_OBJ_TO_PTR(lhs);
    specialclass_myclass_obj_t *right_hand_side = MP_OBJ_TO_PTR(rhs);
    switch (op) {
        case MP_BINARY_OP_EQUAL:
            return mp_obj_new_bool((left_hand_side->a == right_hand_side->a) && (left_
→hand_side->b == right_hand_side->b));
        case MP_BINARY_OP_ADD:
            return create_new_myclass(left_hand_side->a + right_hand_side->a, left_
→hand_side->b + right_hand_side->b);
        case MP_BINARY_OP_MULTIPLY:
           return create_new_myclass(left_hand_side->a * right_hand_side->a, left_
→hand_side->b * right_hand_side->b);
        default:
            return MP_OBJ_NULL; // operator not supported
   }
const mp_obj_type_t specialclass_myclass_type = {
```

```
{ &mp_type_type },
    .name = MP_QSTR_specialclass,
    .print = myclass_print,
    .make_new = myclass_make_new,
    .unary_op = specialclass_unary_op,
    .binary_op = specialclass_binary_op,
    .locals_dict = (mp_obj_dict_t*)&myclass_locals_dict,
};
STATIC const mp_map_elem_t specialclass_globals_table[] = {
   { MP_OBJ_NEW_QSTR(MP_QSTR___name__), MP_OBJ_NEW_QSTR(MP_QSTR_specialclass) },
    { MP_OBJ_NEW_QSTR(MP_QSTR_myclass), (mp_obj_t)&specialclass_myclass_type },
};
STATIC MP_DEFINE_CONST_DICT (
   mp_module_specialclass_globals,
    specialclass_globals_table
);
const mp_obj_module_t specialclass_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*) &mp_module_specialclass_globals,
};
MP_REGISTER_MODULE(MP_QSTR_specialclass, specialclass_user_cmodule, MODULE_
→SPECIALCLASS_ENABLED);
```

https://github.com/v923z/micropython-usermod/tree/master/snippets/specialclass/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/specialclass.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_SPECIALCLASS_
→ENABLED=1 all
```

```
%%micropython

import specialclass

a = specialclass.myclass(1, 2)
b = specialclass.myclass(10, 20)
print(a)
print(b)
print(a + b)
```

```
myclass(1, 2)
myclass(10, 20)
myclass(11, 22)
```

#### 8.3 Properties

In addition to methods, in python, classes can also have properties, which will basically return some read-only attributes of the class. Take the following example:

```
class PropClass:
    def __init__(self, x):
        self._x = x

    @property
    def x(self):
        return self._x
```

We can now create an instance of PropClass, and access the value of \_x by "calling" the decorated x method without the brackets characteristic of function calls:

```
c = PropClass(12.3)
c.x
```

```
12.3
```

One use case is, when you want to protect the value of \_x, and want to prevent accidental changes: if you want to write to the x property, you'll get a nicely-formatted exception:

```
\mathbf{c.x} = 55.5
```

```
AttributeError Traceback (most recent call last)

<ipython-input-50-63b5601caccb> in <module>
----> 1 c.x = 55.5

AttributeError: can't set attribute
```

It is nifty, isn't it? Now, let us see, how we can deal with this in micropython. In order to simplify things, we will implement what we have just seen above: a class that holds a single floating point value, and does nothing else.

Most of the code should be familiar from our first example on classes, so I will discuss the single new function that is relevant to properties. At the C level, a property is nothing but a void function with exactly three arguments

```
STATIC void some_attr(mp_obj_t self_in, qstr attribute, mp_obj_t *destination) {
...
}
```

where self\_in is the class instance, attribute is a string with the property's name, and destination is a pointer to the return value of the function that is going to be called, when querying for the property. So, in the python example above, attribute is x, because we queried the x property, and destination will be the equivalent of self.\_x, because self.\_x is what is returned by the PropClass.x() method.

In the C function, we do not return anything, instead, we assign the desired property (attribute) of the class to destination[0] as in the snippet below:

8.3. Properties 39

```
STATIC void propertyclass_attr(mp_obj_t self, qstr attribute, mp_obj_t *destination) {
   if(attribute == MP_QSTR_x) {
      destination[0] = propertyclass_x(self);
   }
}
```

The qstr is required, because a class might have multiple properties, but all these properties are retrieved by a single function, propertyclass\_attr. Thus, should we want to return another property with name y, we would augment the function as

```
STATIC void propertyclass_attr(mp_obj_t self, qstr attribute, mp_obj_t *destination) {
   if(attribute == MP_QSTR_x) {
      destination[0] = propertyclass_x(self);
   } else if(attribute == MP_QSTR_y) {
      destination[0] = propertyclass_y(self);
   }
}
```

Now, we are almost done, but we still have to implement the function that actually retrieves the attribute. This is what happens here:

```
STATIC mp_obj_t propertyclass_x(mp_obj_t self_in) {
    propertyclass_obj_t *self = MP_OBJ_TO_PTR(self_in);
    return mp_obj_new_float(self->x);
}
```

Remember, destination was a pointer to mp\_obj\_t, so whatever function we have, it must return mp\_obj\_t. In this particular case, the implementation is trivial: we fetch the value of self->x, and turn it into an mp\_obj\_new\_float.

We are now done, right? Not quite: while the required functions are implemented, they will never be called. We have to attach them to the class, so that the interpreter knows what is to do, when we try to access c.x. This act of attaching the function happens in the type definition of the class: we equate the .attr member of the structure with our propertyclass attr functions, so that the interpreter can fill in the three arguments.

And with that, we are ready to compile the code.

https://github.com/v923z/micropython-usermod/tree/master/snippets/properties/properties.c

```
#include <stdio.h>
#include "py/runtime.h"
#include "py/obj.h"

typedef struct _propertyclass_obj_t {
    mp_obj_base_t base;
    mp_float_t x;
} propertyclass_obj_t;

const mp_obj_type_t propertyclass_type;

STATIC mp_obj_t propertyclass_make_new(const mp_obj_type_t *type, size_t n_args, size_
    →t n_kw, const mp_obj_t *args) {
    mp_arg_check_num(n_args, n_kw, 1, 1, true);
    propertyclass_obj_t *self = m_new_obj(propertyclass_obj_t);
    self->base.type = &propertyclass_type;
    self->x = mp_obj_get_float(args[0]);
    return MP_OBJ_FROM_PTR(self);
}
```

```
STATIC mp_obj_t propertyclass_x(mp_obj_t self_in) {
   propertyclass_obj_t *self = MP_OBJ_TO_PTR(self_in);
   return mp_obj_new_float(self->x);
MP_DEFINE_CONST_FUN_OBJ_1(propertyclass_x_obj, propertyclass_x);
STATIC const mp_rom_map_elem_t propertyclass_locals_dict_table[] = {
   { MP_ROM_QSTR(MP_QSTR_x), MP_ROM_PTR(&propertyclass_x_obj) },
};
STATIC MP_DEFINE_CONST_DICT(propertyclass_locals_dict, propertyclass_locals_dict_
→table);
STATIC void propertyclass_attr(mp_obj_t self_in, qstr attribute, mp_obj_t_
if (attribute == MP_QSTR_x) {
        destination[0] = propertyclass_x(self_in);
    }
}
const mp_obj_type_t propertyclass_type = {
   { &mp_type_type },
   .name = MP_QSTR_propertyclass,
   .make_new = propertyclass_make_new,
    .attr = propertyclass_attr,
    .locals_dict = (mp_obj_dict_t*)&propertyclass_locals_dict,
} ;
STATIC const mp_map_elem_t propertyclass_globals_table[] = {
    { MP_OBJ_NEW_QSTR(MP_QSTR___name__), MP_OBJ_NEW_QSTR(MP_QSTR_propertyclass) },
    { MP_OBJ_NEW_QSTR(MP_QSTR_propertyclass), (mp_obj_t)&propertyclass_type },
};
STATIC MP_DEFINE_CONST_DICT (
   mp_module_propertyclass_globals,
   propertyclass_globals_table
);
const mp_obj_module_t propertyclass_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&mp_module_propertyclass_globals,
};
MP_REGISTER_MODULE (MP_QSTR_propertyclass, propertyclass_user_cmodule, MODULE_
→PROPERTYCLASS_ENABLED);
```

Before we compile the module, I would like to add two comments to what was said above.

First, in the function that we assigned to .attr,

(continues on next page)

8.3. Properties 41

```
}
```

we called a function on self\_in, propertyclass\_x(), and assigned the results to destination[0]. However, this extra trip is not absolutely necessary: we could have equally done something along these lines:

The case in point being that destination[0] is simply an mp\_obj\_t object, it does not matter, where and how it is produced. Since self is available to propertyclass\_attr, if the property is simple, as above, one can save the function call, and do everything in place.

Second, more examples on implementing properties can be found in py/profile.c. Just look for the .attr string, and the associated functions!

https://github.com/v923z/micropython-usermod/tree/master/snippets/properties/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/properties.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_PROPERTYCLASS_

→ENABLED=1 all
```

```
%%micropython
import propertyclass
a = propertyclass.propertyclass(12.3)
print(a.x)
```

```
12.3
```

## CHAPTER 9

#### Creating new types

Sometimes you might need something beyond the standard python data types, and you have to define your own. At first, the task seems daunting, but types are really nothing but a C structure with a couple of special fields. The steps required are very similar to those for classes. Take the following type definition, which could be regarded as the Cartesian components of a vector in three-dimensional space:

```
typedef struct _vector_obj_t {
   mp_obj_base_t base;
   float x, y, z;
} vector_obj_t;
```

Now, in order to see, how we can work with this structure, we are going to define a new type that simply stores the three values. The module will also have a method called length, returning the absolute value of the vector. Also note that here we check the type of the argument, and bail out, if it is not a vector. The beauty of all this is that once the type is defined, the available micropython methods just work. Can you still recall the

```
mp_obj_is_type(myobject, &my_type)
```

macro in Section Type checking? I thought so.

We have our vector structure at the C level. It has four members: an  $mp_obj_base_t$ , and three floats called x, y, and z. But this is still not usable in the python interpreter. We have to somehow tell the interpreter, what it is supposed to do with this new type, and how a variable of this type is to be presented to the user. This is, where the structure

takes centre stage. Does this look familiar? This structure contains the new type's name (a string, vector), how it presents itself to users (a function, vector\_print), and how a new instance is to be created (a function, vector\_make\_new). These latter two we have to implement ourselves.

In vector\_print we have three arguments, namely const mp\_print\_t \*print, which is a helper that we don't call, mp\_obj\_t self\_in which is a reference to the vector itself, and mp\_print\_kind\_t kind, which we can graciously ignore, because we are not going to use it anyway.

Having seen the bits and pieces, we should build some new firmware.

https://github.com/v923z/micropython-usermod/tree/master/snippets/vector/vector.c

```
#include <math.h>
#include <stdio.h>
#include "py/obj.h"
#include "py/runtime.h"
const mp_obj_type_t vector_type;
typedef struct _vector_obj_t {
   mp_obj_base_t base;
    float x, y, z;
} vector_obj_t;
STATIC mp_obj_t vector_length(mp_obj_t o_in) {
    if(!mp_obj_is_type(o_in, &vector_type)) {
        mp_raise_TypeError("argument is not a vector");
    }
   vector_obj_t *vector = MP_OBJ_TO_PTR(o_in);
   return mp_obj_new_float(sqrtf(vector->x*vector->x + vector->y*vector->y + vector->
\hookrightarrowz*vector->z));
}
STATIC MP_DEFINE_CONST_FUN_OBJ_1 (vector_length_obj, vector_length);
STATIC void vector_print(const mp_print_t *print, mp_obj_t self_in, mp_print_kind_t_
⇔kind) {
    (void) kind;
    vector_obj_t *self = MP_OBJ_TO_PTR(self_in);
   mp_print_str(print, "vector(");
   mp_obj_print_helper(print, mp_obj_new_float(self->x), PRINT_REPR);
   mp_print_str(print, ", ");
   mp_obj_print_helper(print, mp_obj_new_float(self->y), PRINT_REPR);
   mp_print_str(print, ", ");
   mp_obj_print_helper(print, mp_obj_new_float(self->z), PRINT_REPR);
   mp_print_str(print, ")");
}
STATIC mp_obj_t vector_make_new(const mp_obj_type_t *type, size_t n_args, size_t n_kw,
→ const mp_obj_t *args) {
   mp_arg_check_num(n_args, n_kw, 3, 3, true);
   vector_obj_t *vector = m_new_obj(vector_obj_t);
   vector->base.type = &vector_type;
   vector->x = mp_obj_get_float(args[0]);
   vector->y = mp_obj_get_float(args[1]);
   vector->z = mp_obj_get_float(args[2]);
   return MP_OBJ_FROM_PTR(vector);
}
const mp_obj_type_t vector_type = {
    { &mp_type_type },
    .name = MP_QSTR_vector,
```

https://github.com/v923z/micropython-usermod/tree/master/snippets/vector/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR) / vector.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_VECTOR_ENABLED=1_

→all
```

```
%%micropython

import vector

a = vector.vector(1, 20, 30)
print(a)
print(vector.length(a))
```

```
vector(1.0, 20.0, 30.0)
36.06937789916993
```

Just to convince ourselves, when calculated in python proper, the length of the vector is

```
import math
print(math.sqrt(1**2 + 20**2 + 30**2))
```

```
36.069377593742864
```

Close enough.

Micropython usermod documentation, Release 1.622						

# CHAPTER 10

#### Dealing with iterables

Without going too deeply into specifics, in python, an iterable is basically an object that you can have in a for loop:

```
for item in my_iterable:
    print(item)
```

Amongst others, lists, tuples, and ranges are iterables, as are strings. The key is that these objects have a special internal method, an iterator, attached to them. This iterator is responsible for keeping track of the index during the iteration, and serving the objects in the iterable one by one to the for loop. When writing our own iterable, we will look under the hood, and see how this all works at the C level. For now, we are going to discuss only, how we can *consume* the content of an iterable in the C code.

### 10.1 Iterating over built-in types

In order to demonstrate the use of an iterator, we are going to write a function that sums the square of the values in an iterable. The python version of the function could be something like this:

```
def sumsq(some_iterable):
    return sum([item**2 for item in some_iterable])
sumsq([1, 2, 3, 4, 5, 6, 7, 8, 9, 10])
```

```
385
```

#### In C, the key is in the snippet

```
mp_obj_iter_buf_t iter_buf;
mp_obj_t item, iterable = mp_getiter(o_in, &iter_buf);
while ((item = mp_iternext(iterable)) != MP_OBJ_STOP_ITERATION) {
    // do something with the item just retrieved
}
```

This is more or less the equivalent of the for item in some\_iterable instruction. In C, the mp\_obj\_t object o\_in is the argument of our python function, which is turned into an iterable by passing it into the mp\_getiter function. This function also needs a buffer object that is of type mp\_obj\_iter\_buf\_t. The buffer type is defined in obj.h as

```
typedef struct _mp_obj_iter_buf_t {
    mp_obj_base_t base;
    mp_obj_t buf[3];
} mp_obj_iter_buf_t;
```

where .buf[2] holds the index value, and this is how mp\_iternext keeps track of the position in the loop.

Once item is retrieved, the rest of the code is trivial: you do whatever you want to do with the value, and return at the very end.

Now, what happens, if you pass a non-iterable object to the function? For a while, nothing. Everything will work till the point item = mp\_iternext(iterable), where the interpreter will raise a TypeError exception. So, on the python console, you can either enclose your function in a

```
try:
    sumsq(some_iterable)
except TypeError:
    print('something went terribly wrong`)
```

construct, or you can inspect the type of the variable at the C level. Unfortunately, there does not seem to be a type identifier for iterables in general, so you have to check, whether the argument is a list, tuple, range, etc. This can be done by calling the mp\_obj\_is\_type macro, and see which Boolean it returns, if you pass &mp\_type\_tuple, &mp\_type\_list, &mp\_type\_range etc. to it, as we discussed in the section *Object representation*.

The complete code listing of consumeiterable.c follows below. If you ask me, this is a lot of code just to replace a python one-liner.

https://github.com/v923z/micropython-usermod/tree/master/snippets/consumeiterable/consumeiterable.c

```
#include "py/obj.h"
#include "py/runtime.h"
STATIC mp_obj_t consumeiterable_sumsq(mp_obj_t o_in) {
   mp_float_t _sum = 0.0, itemf;
   mp_obj_iter_buf_t iter_buf;
   mp_obj_t item, iterable = mp_getiter(o_in, &iter_buf);
   while ((item = mp_iternext(iterable)) != MP_OBJ_STOP_ITERATION) {
       itemf = mp_obj_get_float(item);
        _sum += itemf*itemf;
    }
   return mp_obj_new_float(_sum);
}
STATIC MP_DEFINE_CONST_FUN_OBJ_1 (consumeiterable_sumsq_obj, consumeiterable_sumsq);
STATIC const mp_rom_map_elem_t consumeiterable_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_consumeiterable) },
    { MP_ROM_QSTR(MP_QSTR_sumsq), MP_ROM_PTR(&consumeiterable_sumsq_obj) },
STATIC MP_DEFINE_CONST_DICT(consumeiterable_module_globals, consumeiterable_module_
→globals_table);
const mp_obj_module_t consumeiterable_user_cmodule = {
```

https://github.com/v923z/micropython-usermod/tree/master/snippets/consumeiterable/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/consumeiterable.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_CONSUMEITERABLE_

SENABLED=1 all
```

```
%*micropython

import consumeiterable

a = [1, 2, 3, 4, 5, 6, 7, 8, 9, 10]
print(a)
print(consumeiterable.sumsq(a))
```

```
[1, 2, 3, 4, 5, 6, 7, 8, 9, 10]
385.0
```

### 10.2 Returning iterables

Let us suppose that the result of some operation is an iterable, e.g., a tuple, or a list. How would we return such an object? How about a function that returns the powers of its argument? In python

```
def powerit(base, exponent):
    return [base**e for e in range(0, exponent+1)]
powerit(2, 10)
```

```
[1, 2, 4, 8, 16, 32, 64, 128, 256, 512, 1024]
```

and in C,

https://github.com/v923z/micropython-usermod/tree/master/snippets/returniterable/returniterable.c

```
#include "py/obj.h"
#include "py/runtime.h"

STATIC mp_obj_t powers_iterable(mp_obj_t base, mp_obj_t exponent) {
   int e = mp_obj_get_int(exponent);
   mp_obj_t tuple[e+1];
```

```
int b = mp_obj_get_int(base), ba = 1;
    for(int i=0; i <= e; i++) {</pre>
        tuple[i] = mp_obj_new_int(ba);
       ba *= b;
   return mp_obj_new_tuple(e+1, tuple);
}
STATIC MP_DEFINE_CONST_FUN_OBJ_2 (powers_iterable_obj, powers_iterable);
STATIC const mp_rom_map_elem_t returniterable_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_returniterable) },
    { MP_ROM_QSTR(MP_QSTR_powers), MP_ROM_PTR(&powers_iterable_obj) },
STATIC MP_DEFINE_CONST_DICT(returniterable_module_globals, returniterable_module_
const mp_obj_module_t returniterable_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*) & returniterable_module_globals,
};
MP_REGISTER_MODULE(MP_QSTR_returniterable, returniterable_user_cmodule, MODULE_
→ RETURNITERABLE_ENABLED);
```

As everything else, the elements of tuples and lists are objects of type mp\_obj\_t, so, after finding out how far we have got to go with the exponents, we declare an array of the required length. Values are generated and assigned in the for loop. Since on the left hand side of the assignment we have an mp\_obj\_t, we convert the results with mp\_obj\_new\_int. Once we are done with the computations, we return the array with mp\_obj\_new\_tuple. This functions takes the array as the second argument, while the first argument specifies the length.

If you happen to want to return a list instead of a tuple, all you have to do is use mp\_obj\_new\_list instead at the very end.

https://github.com/v923z/micropython-usermod/tree/master/snippets/returniterable/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/returniterable.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_RETURNITERABLE_
→ENABLED=1 all
```

```
%%micropython

import returniterable

print(returniterable.powers(3, 10))
```

```
(1, 3, 9, 27, 81, 243, 729, 2187, 6561, 19683, 59049)
```

#### 10.3 Creating iterables

Having seen how we can consume the elements in an iterable, it is time to explore what this .getiter magic is doing. So, let us create a new type, itarray, and make it iterable! This new type will have a constructor method, square, generating 16-bit integers, where the values are simply the squares of the indices, i.e., 1, 4, 9, 16... We are interested only in the iterability of the object, and for this reason, we will implement only the .getiter special method, and skip .binary\_op, and .unary\_op. If needed, these can easily be added based on the discussion in Special methods of classes.

Before listing the complete code, we discuss the relevant code snippets. The first chunk is the assignment of .getiter in the iterable\_array\_type structure. .getiter will be made equal to a function called iterarray\_getiter, which simply returns mp\_obj\_new\_itarray\_iterator. Why can't we simply assign mp\_obj\_new\_itarray\_iterator, instead of wrapping it in iterarray\_getiter? The reason for that is that iterarray\_getiter has a strict signature, and we want to pass an extra argument, 0. This is nothing but the very first index in the sequence.

So, it appears that we have to scrutinise mp\_obj\_new\_itarray\_iterator. This is a special object type in micropython, with a base type of mp\_type\_polymorph\_iter. In addition, it holds a pointer to the \_\_next\_\_ method, which is itarray\_iternext in this case, stores a pointer to the variable (the one that we are iterating over), and the current index (which we initialised to 0 in mp\_obj\_new\_itarray\_iterator).

mp\_obj\_new\_itarray\_iterator is not much more than a declaration and assignments. The object that we return is of type mp\_obj\_itarray\_it\_t, which has the above-mentioned structure

```
// itarray iterator
typedef struct _mp_obj_itarray_it_t {
    mp_obj_base_t base;
    mp_fun_1_t iternext;
    mp_obj_t itarray;
    size_t cur;
} mp_obj_itarray_it_t;
mp_obj_t itarray_iternext(mp_obj_t self_in) {
```

```
mp_obj_itarray_it_t *self = MP_OBJ_TO_PTR(self_in);
itarray_obj_t *itarray = MP_OBJ_TO_PTR(self->itarray);
if (self->cur < itarray->len) {
    // read the current value
    uint16_t *arr = itarray->elements;
    mp_obj_t o_out = MP_OBJ_NEW_SMALL_INT(arr[self->cur]);
    self->cur += 1;
    return o_out;
} else {
    return MP_OBJ_STOP_ITERATION;
}
```

Now, the complete code in one chunk:

https://github.com/v923z/micropython-usermod/tree/master/snippets/makeiterable/makeiterable.c

```
#include <stdlib.h>
#include "py/obj.h"
#include "py/runtime.h"
typedef struct _itarray_obj_t {
   mp_obj_base_t base;
   mp_fun_1_t iternext;
   uint16_t *elements;
   size_t len;
} itarray_obj_t;
const mp_obj_type_t iterable_array_type;
mp_obj_t mp_obj_new_itarray_iterator(mp_obj_t , size_t , mp_obj_iter_buf_t *);
STATIC void itarray_print(const mp_print_t *print, mp_obj_t self_in, mp_print_kind_t_
⇒kind) {
    (void) kind;
   itarray_obj_t *self = MP_OBJ_TO_PTR(self_in);
   mp_print_str(print, "itarray: ");
   uint16_t i;
   for(i=0; i < self->len-1; i++) {
       mp_obj_print_helper(print, mp_obj_new_int(self->elements[i]), PRINT_REPR);
       mp_print_str(print, ", ");
   mp_obj_print_helper(print, mp_obj_new_int(self->elements[i]), PRINT_REPR);
}
STATIC mp_obj_t itarray_make_new(const mp_obj_type_t *type, size_t n_args, size_t n_
→kw, const mp_obj_t *args) {
   mp_arg_check_num(n_args, n_kw, 1, 1, true);
   itarray_obj_t *self = m_new_obj(itarray_obj_t);
   self->base.type = &iterable_array_type;
   self->len = mp_obj_get_int(args[0]);
   uint16_t *arr = malloc(self->len * sizeof(uint16_t));
   for(uint16_t i=0; i < self->len; i++) {
        arr[i] = i*i;
    self->elements = arr;
    return MP_OBJ_FROM_PTR(self);
```

```
STATIC mp_obj_t itarray_getiter(mp_obj_t o_in, mp_obj_iter_buf_t *iter_buf) {
   return mp_obj_new_itarray_iterator(o_in, 0, iter_buf);
const mp_obj_type_t iterable_array_type = {
   { &mp_type_type },
   .name = MP_QSTR_itarray,
   .print = itarray_print,
    .make_new = itarray_make_new,
    .getiter = itarray_getiter,
};
STATIC const mp_rom_map_elem_t makeiterable_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_makeiterable) },
    { MP_OBJ_NEW_QSTR(MP_QSTR_square), (mp_obj_t)&iterable_array_type },
STATIC MP_DEFINE_CONST_DICT(makeiterable_module_globals, makeiterable_module_globals_
→table);
const mp_obj_module_t makeiterable_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&makeiterable_module_globals,
} ;
MP_REGISTER_MODULE(MP_QSTR_makeiterable, makeiterable_user_cmodule, MODULE_
→MAKEITERABLE_ENABLED);
// itarray iterator
typedef struct _mp_obj_itarray_it_t {
   mp_obj_base_t base;
   mp_fun_1_t iternext;
   mp_obj_t itarray;
   size_t cur;
} mp_obj_itarray_it_t;
mp_obj_t itarray_iternext(mp_obj_t self_in) {
   mp_obj_itarray_it_t *self = MP_OBJ_TO_PTR(self_in);
    itarray_obj_t *itarray = MP_OBJ_TO_PTR(self->itarray);
   if (self->cur < itarray->len) {
       // read the current value
       uint16_t *arr = itarray->elements;
       mp_obj_t o_out = MP_OBJ_NEW_SMALL_INT(arr[self->cur]);
       self->cur += 1;
       return o_out;
    } else {
        return MP_OBJ_STOP_ITERATION;
}
mp_obj_t mp_obj_new_itarray_iterator(mp_obj_t itarray, size_t cur, mp_obj_iter_buf_t_
→*iter_buf) {
   assert (sizeof (mp_obj_itarray_it_t) <= sizeof (mp_obj_iter_buf_t));</pre>
   mp_obj_itarray_it_t *o = (mp_obj_itarray_it_t*)iter_buf;
   o->base.type = &mp_type_polymorph_iter;
   o->iternext = itarray_iternext;
   o->itarray = itarray;
```

```
o->cur = cur;
return MP_OBJ_FROM_PTR(o);
}
```

https://github.com/v923z/micropython-usermod/tree/master/snippets/makeiterable/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/makeiterable.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_MAKEITERABLE_

SENABLED=1 all
```

```
%%micropython

import makeiterable

a = makeiterable.square(15)
print(a)
for j, i in enumerate(a):
    if j == 1: print('%dst element: %d'%(j, i))
    elif j == 2: print('%dnd element: %d'%(j, i))
    elif j == 3: print('%drd element: %d'%(j, i))
    else:
        print('%dth element: %d'%(j, i))
```

```
itarray: 0, 1, 4, 9, 16, 25, 36, 49, 64, 81, 100, 121, 144, 169, 196
Oth element: 0
1st element: 1
2nd element: 4
3rd element: 9
4th element: 16
5th element: 25
6th element: 36
7th element: 49
8th element: 64
9th element: 81
10th element: 100
11th element: 121
12th element: 144
13th element: 169
14th element: 196
```

#### 10.4 Subscripts

We now know, how we construct something that can be passed to a for loop. This is a good start. But iterables have other very useful properties. For instance, have you ever wondered, what actually happens in the following snippet?

```
a = 'micropython'
a[5]
```

```
'p'
```

a is a string, therefore, an iterable. Where does the interpreter know from, that it has got to return p, when asked for a [5]? Or have you ever been curious to know, how the interpreter replaces p by q, if

```
a = [c for c in 'micropyton']
a[5] = 'q'
a
```

```
['m', 'i', 'c', 'r', 'o', 'q', 'y', 't', 'o', 'n']
```

is passed to it? If so, then it is your lucky day, because we are going to make our iterable class be able to deal with such requests.

The code snippets above rely on a single special method, the subscription. In the C code of micropython, this method is called .subscr, and it should be assigned to in the class declaration, i.e., if we take makeiterable.c as our basis for the following discussion, then we would have to extend the iterable\_array\_type as

```
const mp_obj_type_t iterable_array_type {
    ...
    .subscr = itarray_subscr
}
```

where the signature of itarray\_subscr has the form

```
STATIC mp_obj_t itarray_subscr(mp_obj_t self_in, mp_obj_t index, mp_obj_t value)
```

If .subscr is not implemented, but you are daring enough to call

```
>>> a[5]
```

all the same, then the interpreter is going to throw a TypeError:

```
Traceback (most recent call last):
   File "<stdin>", line 1, in <module>
TypeError: 'itarray' object isn't subscriptable
```

So, what happens in the method that we assigned in iterable\_array\_type? A possible scenario is given below:

```
STATIC mp_obj_t subitarray_subscr(mp_obj_t self_in, mp_obj_t index, mp_obj_t value) {
    subitarray_obj_t *self = MP_OBJ_TO_PTR(self_in);
    size_t idx = mp_obj_get_int(index);
    if(self->len <= idx) {
        mp_raise_ValueError("index is out of range");
    }
    if (value == MP_OBJ_SENTINEL) { // simply return the value at index, no assignment
        return MP_OBJ_NEW_SMALL_INT(self->elements[idx]);
    } else { // value was passed, replace the element at index
        self->elements[idx] = mp_obj_get_int(value);
    }
    return mp_const_none;
}
```

10.4. Subscripts 55

subitarray\_subscr takes three arguments: the first is the instance on which the method is called, i.e., self. The second is the index, i.e., what stands in []. And finally, the third argument is the value. This is what we assign to the element at index idx, or, when we do not assign anything (i.e., when we *load* a value from the iterable), then value takes on a special value. If we have

```
>>> a[5]
```

on the python console, then the interpreter will automatically assign value = MP\_OBJ\_SENTINEL (this is defined in obj.h), so that, though we did not explicitly set anything to it, we can still inspect value. This is what happens, when we evaluate value == MP\_OBJ\_SENTINEL: if this statement is true, then we query for a[5]. Note that we also implemented some very rudimentary error checking: we raise an IndexError, whenever the index is out of range. We do this by calling

```
mp_raise_msg(&mp_type_IndexError, "index is out of range");
```

For a thorough discussion on how to raise exceptions see the Section Error handling.

There is one more thing that we should notice: at the very beginning of the function, in the line

```
size_t idx = mp_obj_get_int(index);
```

we call mp\_obj\_get\_int. This means that any python object with an integer value is a valid argument, i.e., the following instruction would still work

```
%%micropython

a = 'micropython'
b = 5
print(a[b])
```

```
p
```

For compiling, here is the complete code:

https://github.com/v923z/micropython-usermod/tree/master/snippets/subscriptiterable/subscriptiterable.c

```
#include <stdlib.h>
#include "py/obj.h"
#include "py/runtime.h"
typedef struct _subitarray_obj_t {
   mp_obj_base_t base;
   mp_fun_1_t iternext;
   uint16_t *elements;
   size_t len;
} subitarray_obj_t;
const mp_obj_type_t subiterable_array_type;
mp_obj_t mp_obj_new_subitarray_iterator(mp_obj_t , size_t , mp_obj_iter_buf_t *);
STATIC void subitarray_print(const mp_print_t *print, mp_obj_t self_in, mp_print_kind_
→t kind) {
    (void) kind;
    subitarray_obj_t *self = MP_OBJ_TO_PTR(self_in);
   mp_print_str(print, "subitarray: ");
   uint16_t i;
    for(i=0; i < self->len-1; i++) {
```

```
mp_obj_print_helper(print, mp_obj_new_int(self->elements[i]), PRINT_REPR);
       mp_print_str(print, ", ");
   mp_obj_print_helper(print, mp_obj_new_int(self->elements[i]), PRINT_REPR);
STATIC mp_obj_t subitarray_make_new(const mp_obj_type_t *type, size_t n_args, size_t,
→n_kw, const mp_obj_t *args) {
   mp_arg_check_num(n_args, n_kw, 1, 1, true);
   subitarray_obj_t *self = m_new_obj(subitarray_obj_t);
   self->base.type = &subiterable_array_type;
   self->len = mp_obj_get_int(args[0]);
   uint16_t *arr = malloc(self->len * sizeof(uint16_t));
   for(uint16_t i=0; i < self->len; i++) {
        arr[i] = i*i;
   self->elements = arr;
    return MP_OBJ_FROM_PTR(self);
STATIC mp_obj_t subitarray_getiter(mp_obj_t o_in, mp_obj_iter_buf_t *iter_buf) {
   return mp_obj_new_subitarray_iterator(o_in, 0, iter_buf);
STATIC mp_obj_t subitarray_subscr(mp_obj_t self_in, mp_obj_t index, mp_obj_t value) {
   subitarray_obj_t *self = MP_OBJ_TO_PTR(self_in);
   size_t idx = mp_obj_get_int(index);
   if(self->len <= idx) {</pre>
       mp_raise_msg(&mp_type_IndexError, "index is out of range");
   if (value == MP_OBJ_SENTINEL) { // simply return the value at index, no assignment
        return MP_OBJ_NEW_SMALL_INT(self->elements[idx]);
    } else { // value was passed, replace the element at index
       self->elements[idx] = mp_obj_get_int(value);
   return mp_const_none;
const mp_obj_type_t subiterable_array_type = {
   { &mp_type_type },
   .name = MP_QSTR_subitarray,
    .print = subitarray_print,
    .make_new = subitarray_make_new,
    .getiter = subitarray_getiter,
    .subscr = subitarray_subscr,
};
STATIC const mp_rom_map_elem_t subscriptiterable_module_globals_table[] = {
   { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_subscriptiterable) },
    { MP_OBJ_NEW_QSTR(MP_QSTR_square), (mp_obj_t)&subiterable_array_type },
};
STATIC MP_DEFINE_CONST_DICT(subscriptiterable_module_globals, subscriptiterable_
→module_globals_table);
const mp_obj_module_t subscriptiterable_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*) & subscriptiterable_module_globals,
```

(continues on next page)

10.4. Subscripts 57

```
};
MP_REGISTER_MODULE(MP_QSTR_subscriptiterable, subscriptiterable_user_cmodule, MODULE_
→SUBSCRIPTITERABLE_ENABLED);
// itarray iterator
typedef struct _mp_obj_subitarray_it_t {
   mp_obj_base_t base;
   mp_fun_1_t iternext;
   mp_obj_t subitarray;
   size_t cur;
} mp_obj_subitarray_it_t;
mp_obj_t subitarray_iternext(mp_obj_t self_in) {
    mp_obj_subitarray_it_t *self = MP_OBJ_TO_PTR(self_in);
    subitarray_obj_t *subitarray = MP_OBJ_TO_PTR(self->subitarray);
    if (self->cur < subitarray->len) {
        // read the current value
        uint16_t *arr = subitarray->elements;
        mp_obj_t o_out = MP_OBJ_NEW_SMALL_INT(arr[self->cur]);
        self->cur += 1;
        return o_out;
    } else {
        return MP_OBJ_STOP_ITERATION;
}
mp_obj_t mp_obj_new_subitarray_iterator(mp_obj_t subitarray, size_t cur, mp_obj_iter_
→buf_t *iter_buf) {
    assert (sizeof (mp_obj_subitarray_it_t) <= sizeof (mp_obj_iter_buf_t));</pre>
   \label{eq:mp_obj_subitarray_it_t*} \verb|mp_obj_subitarray_it_t*| iter_buf|;
   o->base.type = &mp_type_polymorph_iter;
   o->iternext = subitarray_iternext;
   o->subitarray = subitarray;
   o->cur = cur;
   return MP_OBJ_FROM_PTR(o);
```

https://github.com/v923z/micropython-usermod/tree/master/snippets/subscriptiterable/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/subscriptiterable.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
!make clean
!make USER_C_MODULES=../../usermod/snippets CFLAGS_EXTRA=-DMODULE_

$\times \text{SUBSCRIPTITERABLE_ENABLED=1} all
```

```
%%micropython

import subscriptiterable

a = subscriptiterable.square(15)

print(a)
```

```
print('the fourth element is d'a[3])
a[10] = 0
print(a)
```

```
subitarray: 0, 1, 4, 9, 16, 25, 36, 49, 64, 81, 100, 121, 144, 169, 196 the fourth element is 9 subitarray: 0, 1, 4, 9, 16, 25, 36, 49, 64, 81, 0, 121, 144, 169, 196
```

#### 10.4.1 Index reversing

Now, the code above works for non-negative indices, but in python it is quite customary to have something like

```
a = 'micropython'
a[-2]
```

```
'0'
```

which is equivalent to querying for the last but one element (second from the right) in the iterable. Knowing how long the iterable is (this is stored in self->len), it is a trivial matter to modify our code in such a way that it can return the values at negative indices.

#### 10.5 Slicing

In the previous two sections we have worked with single elements of an iterable. But python wouldn't be python without slices. Slices are index ranges specified in a start:end:step format. Taking our earlier example, we can print every second character in micropython by

```
a = 'micropython'
a[0:8:2]
```

```
'mcoy'
```

This behaviour is also part of the .subscr special method. Let us implement it, shall we? In order to simplify the discussion, we will treat one case only: returning values, and we return a new instance of the array, if a slice was requested, while a single number, if we passed a single index.

Since we want to return an array if the indices stem from a slice, we split our original subscriptitarray\_make\_new function, and separate those parts that reserve space for the array from those that do the assignments.

It shouldn't come as a surprise that we have to modify the function that was hooked up to .subscr. Let us take a look at the following snippet:

(continues on next page)

10.5. Slicing 59

```
mp_bound_slice_t slice;
    mp_seq_get_fast_slice_indexes(self->len, index, &slice);
    uint16_t len = (slice.stop - slice.start) / slice.step;
    sliceitarray_obj_t *res = create_new_sliceitarray(len);
    for(size_t i=0; i < len; i++) {
        res->elements[i] = self->elements[slice.start+i*slice.step];
    }
    return MP_OBJ_FROM_PTR(res);
}
#endif

// we have a single index, return a single number
    size_t idx = mp_obj_get_int(index);
    return MP_OBJ_NEW_SMALL_INT(self->elements[idx]);
} else { // do not deal with assignment, bail out
    return mp_const_none;
}
return mp_const_none;
}
```

As advertised, we treat only the case, when value is empty, i.e., it is equal to an MP\_OBJ\_SENTINEL. Now, there is no point in trying to read out the parameters of a slice, if the slice object is not even defined, is there? This is the case for the minimal ports. So, in order to prevent nasty things from happening, we insert the #if/#endif macro with the parameter MICROPY\_PY\_BUILTINS\_SLICE. Provided that MICROPY\_PY\_BUILTINS\_SLICE is defined, we inspect the index, and find out if it is a slice by calling

```
mp_obj_is_type(index, &mp_type_slice)
```

If so, we attempt to load the slice parameters into the slice object with

```
mp_seq_get_fast_slice_indexes(self->len, index, &slice)
```

The function mp\_seq\_get\_fast\_slice\_indexes returns Boolean true, if the increment in the slice is 1, and false otherwise. For the goal that we are trying to pursue here, it doesn't matter what the step size is, so we don't care about the return value. But the main purpose of the function is actually something different: the function expands the start:end:step slice into a triplet, and it does so, even if one or two of the slice parameters are missing. So, start::step, start::, :end:step etc. will also work. In fact, this is why we have to pass the length of the array: self->len will be substituted, if the :end: parameter is missing.

Equipped with the values of slice.start, slice.stop, and slice.step, we can determine the length of the new array, and assign the values in the for loop.

https://github.com/v923z/micropython-usermod/tree/master/snippets/sliceiterable/sliceiterable.c

```
#include <stdlib.h>
#include "py/obj.h"
#include "py/runtime.h"

typedef struct _sliceitarray_obj_t {
    mp_obj_base_t base;
    mp_fun_1_t iternext;
    uint16_t *elements;
    size_t len;
} sliceitarray_obj_t;

const mp_obj_type_t sliceiterable_array_type;
mp_obj_t mp_obj_new_sliceitarray_iterator(mp_obj_t , size_t , mp_obj_iter_buf_t *);
```

```
STATIC void sliceitarray_print(const mp_print_t *print, mp_obj_t self_in, mp_print_
→kind_t kind) {
    (void) kind;
    sliceitarray_obj_t *self = MP_OBJ_TO_PTR(self_in);
   mp_print_str(print, "sliceitarray: ");
   uint16_t i;
    for(i=0; i < self->len-1; i++) {
       mp_obj_print_helper(print, mp_obj_new_int(self->elements[i]), PRINT_REPR);
       mp_print_str(print, ", ");
   mp_obj_print_helper(print, mp_obj_new_int(self->elements[i]), PRINT_REPR);
sliceitarray_obj_t *create_new_sliceitarray(uint16_t len) {
   sliceitarray_obj_t *self = m_new_obj(sliceitarray_obj_t);
    self->base.type = &sliceiterable_array_type;
   self->len = len;
   uint16_t *arr = malloc(self->len * sizeof(uint16_t));
    self->elements = arr;
   return self;
}
STATIC mp_obj_t sliceitarray_make_new(const mp_obj_type_t *type, size_t n_args, size_
→t n_kw, const mp_obj_t *args) {
   mp_arg_check_num(n_args, n_kw, 1, 1, true);
   sliceitarray_obj_t *self = create_new_sliceitarray(mp_obj_qet_int(arqs[0]));
   for(uint16_t i=0; i < self->len; i++) {
        self->elements[i] = i*i;
   return MP_OBJ_FROM_PTR(self);
STATIC mp_obj_t sliceitarray_getiter(mp_obj_t o_in, mp_obj_iter_buf_t *iter_buf) {
   return mp_obj_new_sliceitarray_iterator(o_in, 0, iter_buf);
STATIC mp_obj_t sliceitarray_subscr(mp_obj_t self_in, mp_obj_t index, mp_obj_t value)
←→ {
   sliceitarray_obj_t *self = MP_OBJ_TO_PTR(self_in);
   if (value == MP_OBJ_SENTINEL) { // simply return the values at index, no...
→assignment
#if MICROPY_PY_BUILTINS_SLICE
        if (mp_obj_is_type(index, &mp_type_slice)) {
            mp_bound_slice_t slice;
            mp_seq_get_fast_slice_indexes(self->len, index, &slice);
            printf("start: %1d, stop: %1d, step: %1d\n", slice.start, slice.stop,...
⇒slice.step);
            uint16_t len = (slice.stop - slice.start + slice.step - 1) / slice.step;
            sliceitarray_obj_t *res = create_new_sliceitarray(len);
            for(size_t i=0; i < len; i++) {</pre>
                res->elements[i] = self->elements[slice.start+i*slice.step];
            return MP_OBJ_FROM_PTR(res);
        }
#endif
```

(continues on next page)

10.5. Slicing 61

```
// we have a single index, return a single number
        size_t idx = mp_obj_get_int(index);
        return MP_OBJ_NEW_SMALL_INT(self->elements[idx]);
    } else { // do not deal with assignment, bail out
        return mp_const_none;
   return mp_const_none;
const mp_obj_type_t sliceiterable_array_type = {
   { &mp_type_type },
   .name = MP_QSTR_sliceitarray,
   .print = sliceitarray_print,
    .make_new = sliceitarray_make_new,
    .getiter = sliceitarray_getiter,
    .subscr = sliceitarray_subscr,
};
STATIC const mp_rom_map_elem_t sliceiterable_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_sliceiterable) },
    { MP_OBJ_NEW_QSTR(MP_QSTR_square), (mp_obj_t)&sliceiterable_array_type },
};
STATIC MP_DEFINE_CONST_DICT(sliceiterable_module_globals, sliceiterable_module_
→globals_table);
const mp_obj_module_t sliceiterable_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&sliceiterable_module_globals,
};
MP_REGISTER_MODULE(MP_QSTR_sliceiterable, sliceiterable_user_cmodule, MODULE_
→SLICEITERABLE_ENABLED);
// itarray iterator
typedef struct _mp_obj_sliceitarray_it_t {
   mp_obj_base_t base;
   mp_fun_1_t iternext;
   mp_obj_t sliceitarray;
   size_t cur;
} mp_obj_sliceitarray_it_t;
mp_obj_t sliceitarray_iternext(mp_obj_t self_in) {
   mp_obj_sliceitarray_it_t *self = MP_OBJ_TO_PTR(self_in);
    sliceitarray_obj_t *sliceitarray = MP_OBJ_TO_PTR(self->sliceitarray);
    if (self->cur < sliceitarray->len) {
        // read the current value
        uint16_t *arr = sliceitarray->elements;
       mp_obj_t o_out = MP_OBJ_NEW_SMALL_INT(arr[self->cur]);
       self->cur += 1;
       return o_out;
    } else {
        return MP_OBJ_STOP_ITERATION;
mp_obj_t mp_obj_new_sliceitarray_iterator(mp_obj_t sliceitarray, size_t cur, mp_obj_
→iter_buf_t *iter_buf) {
```

```
assert(sizeof(mp_obj_sliceitarray_it_t) <= sizeof(mp_obj_iter_buf_t));
mp_obj_sliceitarray_it_t *o = (mp_obj_sliceitarray_it_t*)iter_buf;
o->base.type = &mp_type_polymorph_iter;
o->iternext = sliceitarray_iternext;
o->sliceitarray = sliceitarray;
o->cur = cur;
return MP_OBJ_FROM_PTR(o);
}
```

https://github.com/v923z/micropython-usermod/tree/master/snippets/sliceiterable/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/sliceiterable.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
%%micropython

import sliceiterable
a = sliceiterable.square(20)

print(a)
print(a[1:15:3])
```

```
sliceitarray: 0, 1, 4, 9, 16, 25, 36, 49, 64, 81, 100, 121, 144, 169, 196, 225, 256, 289, 324, 361
start: 1, stop: 15, step: 3
sliceitarray: 1, 16, 49, 100, 169
```

A word of caution is in order here: if the step size is negative, the array is reversed. This means that slice.start is larger than slice.stop, and when we calculate the length of the new array, we end up with a negative number. Just saying.

10.5. Slicing 63

# CHAPTER 11

#### **Profiling**

There are times, when you might want to find out what resources (time and RAM) a particular operation requires. Not because you are nosy, but because the resources of a microcontroller are limited, therefore, if you are out of luck, the desired operation might not even fit within the constraints of the chip. In order to locate the bottleneck, you will need to do a bit of profiling. Or perhaps, a lot. This is what we are going to discuss now.

Since you are not going to face serious difficulties when running micropython on a computer, profiling makes really sense only in the context of the microcontroller, so this might be a golden opportunity to brush up on how the firmware has to be compiled and uploaded. It is not by accident that we spent some time on this at the very beginning of this document.

## 11.1 Profiling in python

#### 11.1.1 Measuring time

If you are interested in the execution time of a complete function, you can measure it simply by making use of the python interpreter

```
%%micropython

from utime import ticks_us, ticks_diff

def test_function(n):
    for i in range(n):
        q = i*i*i
    return q # return the last

now = ticks_us()
test_function(100)
then = ticks_diff(ticks_us(), now)

print("function test_function() took %d us to run"%then)
```

```
function test_function() took 27 us to run
```

In fact, since our function is flanked by two other statements, this construct easily lends itself to a decorator implementation, as in (taken from http://docs.micropython.org/en/v1.9.3/pyboard/reference/speed\_python.html)

```
%%micropython
import utime
def timed_function(f, *args, **kwargs):
   myname = str(f).split(' ')[1]
    def new_func(*args, **kwargs):
        t = utime.ticks_us()
       result = f(*args, **kwargs)
        delta = utime.ticks_diff(utime.ticks_us(), t)
        print('Function {} time = {:6.3f}ms'.format(myname, delta/1000))
        return result
    return new_func
@timed_function
def test_function(n):
    for i in range(n):
        utime.sleep_ms(10)
test_function(10)
```

```
Function test_function time = 100.682ms
```

(If you need an even better estimate, you can get the ticks twice, and yank run\_my\_function() in the second pass: in this way, you would get the cost of measuring time itself:

```
from utime import ticks_us, ticks_diff

now = ticks_us
then = ticks_diff(ticks_us(), now)

print("the time measurement took %d us"%then)
```

Then you subtract the results of the second measurement from those of the first.)

#### 11.1.2 The memory cost of a function

While time is money, RAM is gold. We shouldn't pass up on that! The micropython has a very handy function for printing a pretty summary of the state of the RAM. You would call it like

```
%%micropython

import micropython

print(micropython.mem_info())
```

```
mem: total=2755, current=663, peak=2289 stack: 928 out of 80000 GC: total: 2072832, used: 704, free: 2072128 No. of 1-blocks: 6, 2-blocks: 3, max blk sz: 6, max free sz: 64745 None
```

If you call mem\_info() after you executed your function, but before calling the garbage collector (if that is enabled, that is), then from the two reports, you can figure out how many bytes the function has eaten.

#### 11.2 Profiling in C

With the profiling method above, we can measure the cost of a complete function only, but we cannot say anything about individual instructions in the body. Execution time is definitely a significant issue, but even worse is the problem of RAM: it might happen that the function allocates a huge amount of memory, but cleans up properly before returning. Such a function could certainly wreak havoc, even if it is rather inocuous-looking from the outside. So, what do we do? We should probably just measure. It is not going to hurt.

In the example below (profiling.c), I discuss both time and RAM measurements in a single module, because splitting them wouldn't be worth the trouble. The function, whose behaviour we inspect, does nothing, but calculate the length of a three-dimensional vector. With that, we can figure out, how much the assignment, and how much the actual calculation cost.

https://github.com/v923z/micropython-usermod/tree/master/snippets/profiling/profiling.c

```
#include <math.h>
#include <stdio.h>
#include "py/obj.h"
#include "py/runtime.h"
#include "mphalport.h" // needed for mp_hal_ticks_cpu()
#include "py/builtin.h" // needed for mp_micropython_mem_info()
STATIC mp_obj_t measure_cpu(mp_obj_t _x, mp_obj_t _y, mp_obj_t _z) {
    size_t start, middle, end;
    start = m_get_current_bytes_allocated();
    float x = mp_obj_get_float(_x);
   float y = mp_obj_get_float(_y);
   float z = mp_obj_get_float(_z);
   middle = m_get_current_bytes_allocated();
   float hypo = sqrtf(x*x + y*y + z*z);
   end = m_get_current_bytes_allocated();
   mp_obj_t tuple[4];
   tuple[0] = MP_OBJ_NEW_SMALL_INT(start);
   tuple[1] = MP_OBJ_NEW_SMALL_INT(middle);
   tuple[2] = MP_OBJ_NEW_SMALL_INT(end);
   tuple[3] = mp_obj_new_float(hypo);
   return mp_obj_new_tuple(4, tuple);
STATIC MP_DEFINE_CONST_FUN_OBJ_3 (measure_cpu_obj, measure_cpu);
STATIC const mp_rom_map_elem_t profiling_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_profiling) },
    { MP_ROM_QSTR(MP_QSTR_measure), MP_ROM_PTR(&measure_cpu_obj) },
STATIC MP_DEFINE_CONST_DICT(profiling_module_globals, profiling_module_globals_table);
const mp_obj_module_t profiling_user_cmodule = {
    .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&profiling_module_globals,
};
```

(continues on next page)

11.2. Profiling in C 67

```
MP_REGISTER_MODULE(MP_QSTR_profiling, profiling_user_cmodule, MODULE_PROFILING_

→ENABLED);
```

The above-mentioned mem\_info() function of the micropython module can directly be called from C: after including the builtin.h header, we can issue mp\_micropython\_mem\_info(0, NULL);, defined in modmicropython.c, which will print everything we need. Although its signature contains two arguments, a size\_t and an mp\_obj\_t pointer to the arguments, the function does not seem to care about them, so we can pass 0, and NULL without any meaning.

The function mp\_micropython\_mem\_info() doesn't carry out any measurements in itself, it is only for pretty printing. The stats are collected by mp\_micropython\_mem\_total(), mp\_micropython\_mem\_current(), and mp\_micropython\_mem\_peak(). Unfortunately, these functions are all declared STATIC, so we cannot call them from outsize modmicropython.c. If you need a numeric representation of the state of the RAM, you can make use of the m\_get\_total\_bytes\_allocated(void), m\_get\_current\_bytes\_allocated(void), and m\_get\_peak\_bytes\_allocated(void) functions of py/malloc.c. All three return a size\_t.

With the help of these three functions, we could, e.g., return the size of the consumed memory to the micropython interpreter at the end of our calculations. This is what we do, when collecting the bits an pieces, and returning the 4-tuple at the end of the measure\_cpu function.

https://github.com/v923z/micropython-usermod/tree/master/snippets/profiling/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/profiling.c

# We can add our module folder to include paths if needed
# This is not actually needed in this example.
CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
%%micropython

import profiling

print(profiling.measure(123, 233, 344))
```

```
(672, 672, 672, 433.305908203125)
```

# CHAPTER 12

#### Working with larger modules

Once you add more and more functionality and functions to your module, it will become unmanageably, and it might make more sense to split the module into smaller components. We are going to hack our very first module, simplefunction, and factor out the function in it.

Since we will want to refer to our functions in the module definition, we have to declare them in a header file. Let us call this file helper.h. The functions declared therein operate on micropython types, so do not forget to include py/obj.h, and possibly py/runtime.h!

https://github.com/v923z/micropython-usermod/tree/master/snippets/largemodule/helper.h

```
#include "py/obj.h"
#include "py/runtime.h"

mp_obj_t largemodule_add_ints(mp_obj_t , mp_obj_t );
mp_obj_t largemodule_subtract_ints(mp_obj_t , mp_obj_t );
```

Next, in helper.c, we have to implement the functions. helper.c should also contain the declarations, i.e., header.h has to be included.

https://github.com/v923z/micropython-usermod/tree/master/snippets/largemodule/helper.c

```
#include "helper.h"

mp_obj_t largemodule_add_ints(mp_obj_t a_obj, mp_obj_t b_obj) {
    int a = mp_obj_get_int(a_obj);
    int b = mp_obj_get_int(b_obj);
    return mp_obj_new_int(a + b);
}

mp_obj_t largemodule_subtract_ints(mp_obj_t a_obj, mp_obj_t b_obj) {
    int a = mp_obj_get_int(a_obj);
    int b = mp_obj_get_int(b_obj);
    return mp_obj_new_int(a - b);
}
```

Finally, in the module implementation, we include helper.h, and create the function objects with MP\_DEFINE\_CONST\_FUN\_OBJ\_2, and its relatives. The rest of the code is equivalent to simplefunction. c, with the only exception of the module name.

https://github.com/v923z/micropython-usermod/tree/master/snippets/largemodule/largemodule.c

```
#include "py/obj.h"
#include "py/runtime.h"
#include "helper.h"
STATIC MP_DEFINE_CONST_FUN_OBJ_2(largemodule_add_ints_obj, largemodule_add_ints);
STATIC MP_DEFINE_CONST_FUN_OBJ_2 (largemodule_subtract_ints_obj, largemodule_subtract_
→ints);
STATIC const mp_rom_map_elem_t largemodule_module_globals_table[] = {
    { MP_ROM_QSTR(MP_QSTR___name__), MP_ROM_QSTR(MP_QSTR_largemodule) },
    { MP_ROM_QSTR(MP_QSTR_add_ints), MP_ROM_PTR(&largemodule_add_ints_obj) },
    { MP_ROM_QSTR(MP_QSTR_subtract_ints), MP_ROM_PTR(&largemodule_subtract_ints_obj) }
STATIC MP_DEFINE_CONST_DICT(largemodule_module_globals, largemodule_module_globals_
\hookrightarrowtable);
const mp_obj_module_t largemodule_user_cmodule = {
   .base = { &mp_type_module },
    .globals = (mp_obj_dict_t*)&largemodule_module_globals,
};
MP_REGISTER_MODULE(MP_QSTR_largemodule, largemodule_user_cmodule, MODULE_LARGEMODULE_
→ENABLED);
```

Now, since we have multiple files in our module, we have to change the makefile accordingly, and before linking, we have to compile both helper.c, and largemodule.c, thus, we add \$ (USERMODULES\_DIR) /helper.c, and \$ (USERMODULES\_DIR) /largemodule.c to SRC USERMOD.

https://github.com/v923z/micropython-usermod/tree/master/snippets/largemodule/micropython.mk

```
USERMODULES_DIR := $(USERMOD_DIR)

# Add all C files to SRC_USERMOD.
SRC_USERMOD += $(USERMODULES_DIR)/helper.c
SRC_USERMOD += $(USERMODULES_DIR)/largemodule.c

CFLAGS_USERMOD += -I$(USERMODULES_DIR)
```

```
%%micropython
import largemodule
print(largemodule.add_ints(1, 2))
print(largemodule.subtract_ints(1, 2))
```

2		
3		
9		
1_1		
_ T		

# CHAPTER 13

## A word for the lazy

If you still find that coding in C is too cumbersome, you can try your hand at a stub generator, e.g., https://github.com/pazzarpj/micropython-ustubby, or https://gitlab.com/oliver.robson/mpy-c-stub-gen . These tools allow you to convert your python code into C code. Basically, they will produce a boilerplate file, which you can flesh out with the C implementation of the required functionality.

Looking at the usage examples, it is clear to me that one can save a lot of typing with these stub generators, but one will still need a basic understanding of how to work with the micropython C code.

Micropython usermod documentation, Release 1.622						

### Outline of a math library

As I indicated at the very beginning, my main motivation for writing this document was that I wanted to have a reasonable programming manual for the development of a math library. Since I couldn't find any, I have turned the problem around, and written up, what I have learnt by developing the library. But the question is, what this library should achieve in the first place?

#### 14.1 Requirements

Recently, I have run into some limitations with the micropython interpreter. These difficulties were related to both speed, and RAM. Therefore, I wanted to have something that can perform common mathematical calculations in a pythonic way, with little burden on the RAM, and possibly fast. On PCs, such a library is called numpy, and it felt only natural to me to implement those aspects of numpy that would find an applications in the context of data acquisition of moderate volume: after all, no matter what, the microcontroller is not going to produce or collect huge amounts of data, but it might still be useful to process these data within the constraints of the microcontroller. Due to the nature of the data that would be dealt with, one can work with a very limited subset of numpy.

Keeping these considerations in mind, I set my goals as follows:

• One should be able to vectorise standard mathematical functions, while these functions should still work for scalars, so

```
a = 1.0
sin(a)
```

and

```
a = [1.0, 2.0, 3.0]
sin(a)
```

should both be valid expressions.

• There should be a binary container, (ndarray) for numbers that are results of vectorised operations, and one should be able to initialise a container by passing arbitrary iterables to a constructor (see sin([1, 2, 3]) above).

- The array should be iterable, so that we can turn it into lists, tuples, etc.
- The relevant binary operations should work on arrays as in numpy, that is, e.g.,

```
>>> a = ndarray([1, 2, 3, 4])
>>> (a + 1) + a*10
```

should evaluate to ndarray ([12, 23, 34, 45]).

- 2D arrays (matrices) could be useful (see below), thus, the above-mentioned container should be able to store its shape.
- Having matrices, it is only natural to implement standard matrix operations (inversion, transposition etc.)
- These numerical arrays and matrices should have a reasonable visual representation (pretty printing)
- With the help of matrices, one can also think of polynomial fits to measurement data
- There should be an FFT routine that can work with linear arrays. I do not think that 2D transforms would be very useful for data that come from the ADC of the microcontroller, but being able to extract frequency components of 1D signals would be an asset.

And this is, how ulab was born. But that is another story, for another day https://github.com/v923z/micropython-ulab/.

# CHAPTER 15

## Indices and tables

- genindex
- modindex
- search