
USB
J1
USB_C_Receptacle_USB2.0
VBUS
C3
4u7
GND
+5V
F1
500mA
D1
B5817WS
R1
5K1
R2
5K1
CC1
CC2
TP1
USB−
USB+
TP2
SHIELD
SBU1
SBU1
S1
Power
U1
ME6211C33M5G−N
+5V
+3V3
VIN
VOUT
EN
GND
C1
4u7
C2
4u7
RP2040
U3
RP2040
+3V3
+1V1
C8
100n
C10
100n
C13
100n
C15
100n
C11
100n
C14
100n
C16
100n
C17
100n
C18
100n
C12
2u2
Place caps close to VREG_VIN and VREG_VOUT
C9
2u2
VREG_VIN
VREG_VOUT
USB_VDD
IOVDD
ADC_AVDD
DVDD
nRST
RUN
R7
27R
R8
27R
D+
D−
Y1
12MHz
C6
15p
C7
15p
R9
1K
XTAL_IN
XTAL_OUT
SWDCLK
SWDIO
TP3
TP4
R6
5K1
R10
5K1
U2
GD25Q64CWIGR
VCC
CS
CLK
DI(IO0)
DO(IO1)
IO2
IO3
C4
100n
FLASH_nCS
FLASH_SCK
FLASH_SD0
FLASH_SD1
FLASH_SD2
FLASH_SD3
QSPI_SS_N
QSPI_SCLK
QSPI_SD0
QSPI_SD1
QSPI_SD2
QSPI_SD3
TESTEN
GPIO0
GPIO1
GPIO2
GPIO3
GPIO4
GPIO5
GPIO6
GPIO7
GPIO8
GPIO9
GPIO10
GPIO11
GPIO12
GPIO13
GPIO14
GPIO15
GPIO16
GPIO17
GPIO18
GPIO19
GPIO20
GPIO21
GPIO22
GPIO23
GPIO24
GPIO25
GPIO26/ADC0
GPIO27/ADC1
GPIO28/ADC2
GPIO29/ADC3
0_TX0
1_RX0
2_SDA1
3_SCL1
20_MISO
21_nCS
22_SCK
23_MOSI
LED_DO
A0
A1
A2
A3
IO
J2
0.1" x 12
J3
0.1" x 12
SWITCH
A3
A2
A1
A0
22_SCK
20_MISO
23_MOSI
21_nCS
LEDs
R3
1K
D2
LED
D3
WS2812C−2020
DIN
DOUT
VDD
VSS
Reset / Boot Circuit
Tap for 500ms to reset
Hold for 2 seconds to enter UF2 bootloader
R12
5K1
nRST
TP7
nRST
Q2A
2N7002DW−7−F
Q2A − pulls nRST to GND
R11
100K
R4
5K1
R5
5K1
TP5
SWITCH
Q1A
2N7002DW−7−F
SW1
RESET
TP6
Q1A − inverter, as button can only pull to ground due to being backwards compatiable
Q1B
2N7002DW−7−F
Q1B − using body diode due to lack of space. Can sub with normal diode
RC Delay circuit, values can be tweaked as required
R13
51K
R14
100K
C5
4u7
C19
4u7
R15
1K
BOOT
TP8
BOOT
Q2B
2N7002DW−7−F
Q2B − pulls nCS to GND
VBUS
PWR_FLAG
Josh Johnson
Sheet: /
File: sea−picro.kicad_sch
Title: Sea Picro
Size: A4
Date: 2022−03−07
Rev: 0.2
KiCad E.D.A. kicad 6.0.2−378541a8eb−116−ubuntu20.04.1
Id: 1/1