HOORVIA - POLYESTER SHIRT HEAT PRESS CHART: PRINTABLE SUBLIMATION SETTINGS

Quick Reference Cheat Sheet · A4 Printable

Crafting & DIY · Sheet #1

Setting	Value	Why It Matters	Watch Out For
Fabric	100% polyester (or 65%+ poly blend)	Sublimation ink bonds only to polyester fibers	Cotton prints wash out
Temperature	385-400°F (196-204°C)	Activates the sublimation dye	Below 380°F / 193°C the transfer is faint
Time	45-60 seconds	Lets dye gas fully into fibers	Over 60s can scorch light shirts
Pressure	Medium (firm, even)	Presses paper flat to the fabric	Uneven pressure leaves ghosting
Paper	Sublimation paper, print side down	Carries the dye to the shirt	Regular paper absorbs the ink
Tape	Heat-resistant tape	Holds paper still while pressing	Any shift causes a double image
Pre-press	5 seconds, no paper	Removes moisture and wrinkles	Damp fabric causes faded spots
Teflon sheet	Cover the print before pressing	Protects the press and the shirt	Never press bare ink directly
Peel	Hot peel immediately	Dye sets as it cools	Waiting can stick paper to fibers
Wash	Cold water, inside out	Keeps the print vivid	Hot water fades sublimation
Drying	Hang dry or low heat	Heat degrades the dye bond	Avoid high-heat dryers
Blends (65/35)	Same settings, lighter result	Only the polyester fibers take dye	Expect a vintage, faded look