HOORVIA - TIRE ROTATION PATTERNS: PRINTABLE GUIDE

Quick Reference Cheat Sheet · US Letter Printable

Home, Family & Health · Sheet #1

Drive / Tire Type	Pattern	How It Moves	Rotate Every
Front-wheel drive	Forward cross	Front straight back; rear cross to front	5,000-7,500 miles
Rear-wheel drive	Rearward cross	Rear straight forward; front cross to rear	5,000-7,500 miles
All-wheel drive	X-pattern	Every tire crosses to the opposite corner	5,000-7,500 miles
Directional tires	Front-to-back only	Same side only - never cross	5,000-7,500 miles
Staggered sizes	Side-to-side	Left and right swap on the same axle	5,000-7,500 miles
With full-size spare	5-tire rotation	Spare joins the pattern	5,000-7,500 miles
Dually trucks	6-tire rotation	Inner and outer duals swap sides	5,000-7,500 miles
Performance (same size)	X-pattern	Cross all four corners	3,000-5,000 miles
Winter tires	Drive-type pattern	Follow the car's drive pattern	At seasonal swap
New tires	Check alignment first	Rotate at first service	5,000 miles
Uneven wear	Cross to even it out	Move the worn tire to the rear	Immediately
After a flat repair	Rebalance + rotate	Check the repaired tire's position	At the next service