HOORVIA - CAR MILEAGE MAINTENANCE SCHEDULE CHART: PRINTABLE SERVICE INTERVALS GUIDE

Quick Reference Cheat Sheet · US Letter Printable

Home, Family & Health · Sheet #1

Service Item	Mileage Interval	What Gets Done	Why It Matters
Engine oil & filter	Every 5,000-7,500 mi	Replace oil and oil filter	Fresh oil protects engine parts; check your manual for the synthetic vs conventional interval
Tire rotation	Every 5,000-8,000 mi	Rotate tires, check pressure	Even tread wear means longer tire life and better handling
Engine air filter	Every 15,000-30,000 mi	Inspect, replace if dirty	A clogged filter cuts fuel economy and engine power
Cabin air filter	Every 15,000-20,000 mi	Replace cabin filter	Restores HVAC airflow and keeps dust and pollen out of the cabin
Brake inspection	Every 10,000-15,000 mi	Check pads, rotors, fluid level	Worn pads destroy rotors - cheap inspection, expensive repair
Coolant flush	Every 30,000-50,000 mi	Drain and refill coolant	Old coolant corrodes the radiator and water pump
Transmission fluid	Every 30,000-60,000 mi	Service fluid and filter	Fresh fluid prevents harsh shifting and transmission wear
Spark plugs	Every 30,000-100,000 mi	Replace spark plugs	Worn plugs misfire, waste fuel, and can damage the catalytic converter
Serpentine belt	Every 60,000-100,000 mi	Inspect, replace if cracked	A snapped belt kills power steering, the alternator, and AC
Timing belt (if equipped)	Every 60,000-100,000 mi	Replace belt and water pump	On interference engines, a failed timing belt can destroy the engine
Brake fluid flush	Every 2-3 years / 30,000 mi	Replace brake fluid	Fluid absorbs moisture and corrodes brake lines and calipers
Battery test	Every 12 months / 36,000 mi	Load-test the battery	Most batteries last 3-5 years; heat kills them fastest

PRO TIP: Follow Your Manual First: These are standard ranges - your owner's manual always wins for your exact car.