# HOORVIA - POLYESTER SHIRT HEAT PRESS CHART: PRINTABLE SUBLIMATION SETTINGS

Quick Reference Cheat Sheet · A4 Printable

**Crafting & DIY · Sheet #1**

| Setting | Value | Why It Matters | Watch Out For |
|---|---|---|---|
| **Fabric** | 100% polyester (or 65%+ poly blend) | Sublimation ink bonds only to polyester fibers | Cotton prints wash out |
| **Temperature** | 385-400°F (196-204°C) | Activates the sublimation dye | Below 380°F the transfer is faint |
| **Time** | 45-60 seconds | Lets dye gas fully into fibers | Over 60s can scorch light shirts |
| **Pressure** | Medium (firm, even) | Presses paper flat to the fabric | Uneven pressure leaves ghosting |
| **Paper** | Sublimation paper, print side down | Carries the dye to the shirt | Regular paper absorbs the ink |
| **Tape** | Heat-resistant tape | Holds paper still while pressing | Any shift causes a double image |
| **Pre-press** | 5 seconds, no paper | Removes moisture and wrinkles | Damp fabric causes faded spots |
| **Teflon sheet** | Cover the print before pressing | Protects the press and the shirt | Never press bare ink directly |
| **Peel** | Hot peel immediately | Dye sets as it cools | Waiting can stick paper to fibers |
| **Wash** | Cold water, inside out | Keeps the print vivid | Hot water fades sublimation |
| **Drying** | Hang dry or low heat | Heat degrades the dye bond | Avoid high-heat dryers |
| **Blends (65/35)** | Same settings, lighter result | Only the polyester fibers take dye | Expect a vintage, faded look |

**PRO TIP:** Test on a scrap first: One test press on scrap fabric saves a ruined shirt - colors shift with heat.