


Solid State and Devices

Dr Marco Fronzi
School of Physics



THE UNIVERSITY OF
SYDNEY




Carrier Transport



“Drift”


The movement of carrier due to electric field (E)



Force Driven

“Diffusion”

The flow of carrier due to density gradients (dn/dx)



Entropic process


Drift Current

Carrier Motion under an Electric Field


Core Concept

Drift is the net motion of carriers (**electrons**, **holes**) in response to an applied electric field $\mathbf{E}$.

- **Force on Carrier:** $\mathbf{F} = q\mathbf{E}$, where $q = -e$ for electrons, $q = +e$ for holes; e is positive elementary charge.
- **Equation of Motion:** $m_c^* \frac{d\mathbf{v}_d}{dt} = q\mathbf{E}$ (Newton's second law, ignoring scattering initially).
- **Scattering Effects:** Collisions with lattice phonons and impurities randomize carrier momentum.



Acceleration is counterbalanced by collisions during motion (term proportional to velocity)



$$m \frac{d\mathbf{v}}{dt} = q\mathbf{E} - \frac{m}{\tau} \mathbf{v}.$$

the solution is

$$v(t) = v_{ss} + [v(0) - v_{ss}] e^{-t/\tau},$$


$$v_{ss} = \frac{q\tau}{m} E \equiv \mu E.$$

Gain **average drift velocity**, v_{dp}

$$\mathbf{v}_d = \pm \mu \mathbf{E}$$

Drift Current

Drift velocity is defined as the net velocity of free electrons moving randomly in a **conductor** due to an **electric field**. These electrons move at different speeds and directions. When an electric field is applied, they experience a force that aligns them towards the field direction.



$$J_n = -en\vec{v}_{dn} = en\mu_n\vec{E}, \quad J_p = ep\vec{v}_{dp} = ep\mu_p\vec{E}$$

$$J_{\text{drift}} = e(n\mu_n + p\mu_p)\vec{E}$$

At Steady State

$$v_d = \left(\frac{dv}{dt} \right) \tau = -\frac{eE}{m^*} \tau$$

$$\mu = \frac{v_d}{E} = \frac{e\tau}{m^*}$$

$$\tau(T, E, n)$$

- Longer $\tau \Rightarrow$ carriers move farther before scattering $\Rightarrow$ **higher mobility**
- Shorter $\tau \Rightarrow$ more frequent scattering $\Rightarrow$ **lower mobility**

Function of E field, Temperature and carrier concentration

Relaxation time

$$\tau(T, n)$$


$$v_d = \left(\frac{dv}{dt} \right) \tau = -\frac{eE}{m^*} \tau$$

$$\mu = \frac{v_d}{E} = \frac{e\tau}{m^*}$$

$$\lambda = \langle v \rangle \tau$$

Mean free path

$$\lambda(E) = \frac{m^* v_d(E)}{qE}$$



$$\lambda(E) = \frac{m^* v_d(E)}{qE}$$

Distance traveled $\bar{v}t$

Mean distance per collision

Mean free path estimate = $\frac{\bar{v}t}{\underbrace{\pi d^2 \bar{v} t}_{\text{Volume of interaction}} \underbrace{n_V}_{\text{Number of molecules per unit volume}}} = \frac{1}{\pi d^2 n_V}$

v_d saturates at large E and mean free path is $1/\bar{v}t$
They collide more often with phonons and lose energy

Electrons

Equation: $\mathbf{J}_{n,\text{drf}} = \rho_n \mathbf{v}_{dn} = (-en)(-\mu_n \mathbf{E}) = en\mu_n \mathbf{E}$

- $\rho_n = -en$: Electron charge density.
- $\mathbf{v}_{dn} = -\mu_n \mathbf{E}$: Velocity opposite to $\mathbf{E}$.
- Meaning: Current flows parallel to $\mathbf{E}$ despite opposite velocity (due to negative charge).

Holes

Equation: $\mathbf{J}_{p,\text{drf}} = \rho_p \mathbf{v}_{dp} = (ep)(\mu_p \mathbf{E}) = ep\mu_p \mathbf{E}$

- $\rho_p = ep$: Hole charge density.
- $\mathbf{v}_{dp} = \mu_p \mathbf{E}$: Velocity parallel to $\mathbf{E}$.
- Meaning: Current flows parallel to $\mathbf{E}$.

Total drift current;

$$J_{\text{drf}} = e(\mu_n n + \mu_p p)E$$

The sum of the individual electron and hole drift current densities

- If **only electrons** are present (n-type semiconductor): current is dominated by J_n .
- If **only holes** are present (p-type semiconductor): current is dominated by J_p .
- In **intrinsic material** (equal numbers of electrons and holes): both contribute.

Total Drift Current Density

Equation: $\mathbf{J}_{\text{drf}} = \mathbf{J}_{n,\text{drf}} + \mathbf{J}_{p,\text{drf}} = e(n\mu_n + p\mu_p)\mathbf{E}$ Meaning: Sum of electron and hole contributions to drift current.

Microscopic Form

$$\mathbf{J} = \sigma \mathbf{E}$$

- σ : conductivity of the material.
- J : current density (A m^{-2}).
- E : electric field (V m^{-1}).

⚡ Macroscopic Form

$$V = IR$$

- $R = \frac{L}{\sigma A}$ is the resistance.
- I : total current, V : potential difference.
- Linear relation between I and V in ohmic regime.

$$\lambda = \langle v \rangle \tau$$

Ohm's law is valid when mean free path,
or relaxation time are constant

High $E \rightarrow$ more scattering $\rightarrow$ mobility drops $\rightarrow$ non-Ohmic behaviour.

Ohm's Law

$\mathbf{J}_{\text{drf}} = \sigma \mathbf{E}$, where $\sigma = e(n\mu_n + p\mu_p)$ is the conductivity.

- **Extrinsic Semiconductors:**

- n-type ($n \approx N_d \gg p$): $\sigma_n \approx eN_d\mu_n$.
- p-type ($p \approx N_a \gg n$): $\sigma_p \approx eN_a\mu_p$.

- **Resistivity:** $\rho = 1/\sigma$ (inverse of conductivity, in $\Omega \text{ cm}$).


Assumptions for $J = \sigma E$

- Linear relation between J and E (low-field regime).
- Carrier concentration n independent of E (no field ionisation).
- Scattering time τ constant (independent of E and v_d).
- Temperature uniform (no Joule heating).

Diffusion Microscopic Basis

• In gases/liquids

Brownian motion



Temperature effect

$$D = l^2 / (2n\tau)$$

Distance quantified by the Einstein Relation


$$\langle x^2 \rangle = 2nDt,$$

where n is the dimensionality, D is the diffusion coefficient, and t is time.


- l : mean free path (average distance between collisions)

- τ : mean free time between collisions

- n : dimensionality of the system



Diffusion Microscopic Basis



Temperature effect

Entropy (S): A measure of the number of available microstates or, more simply, **disorder**. The second law of thermodynamics states that isolated systems evolve towards **maximum entropy**.

Carrier Distribution and Microstates: A localized, high-concentration carrier distribution has low spatial entropy (highly ordered state).

The Spontaneous Drive: Diffusion is the spontaneous process where a non-uniform distribution expands to fill available space, moving from **low entropy** (ordered) to **high entropy** (disordered) states.

Entropy vs. Chemical Potential: The force driving diffusion is more accurately described by the **gradient of the electrochemical potential**, which includes the chemical potential (μ) related to entropy and the electrostatic potential ($q\psi$).

Non-Equilibrium Drive: In non-equilibrium (e.g., carrier injection), the concentration gradient $\frac{dn}{dx}$ drives the system towards maximum entropy (uniformity) via diffusion.


Point Defect Diffusion

- **Vacancy diffusion:** D limited by **activation barrier** — exponential T -dependence.

$$\langle x^2 \rangle = 2nDt,$$

$$D = D_0 \exp\left(-\frac{Q}{k_B T}\right) \quad \frac{1}{\tau} \propto \exp\left(-\frac{Q}{k_B T}\right)$$

Q is the sum of vacancy formation and migration energies



Temperature effect

- **Physical Picture:** Atoms hop from one lattice site to another when a neighboring site (vacancy) is available.
- **Key Requirement:** The atom must overcome an energy barrier (migration energy Q_m) to jump, and vacancies must exist (formation energy Q_f).

- **Resulting D :**

$$D = D_0 \exp\left(-\frac{Q}{k_B T}\right), \quad Q = Q_f + Q_m$$

where D_0 is a pre-factor that depends on attempt frequency and jump distance.

- **Reason:** The probability of a jump follows Boltzmann statistics — higher T means more atoms have enough thermal energy to hop → exponential growth of D .




Diffusion Current First Flick's Law

Steady state


$$J_{\text{diff}} = qD \frac{dn}{dx}$$

where J is diffusion flux, n concentration, x position. Negative sign indicates flow from high to low n. Units: D in cm²/s.2.2 Ficks Second Law (Non-Steady State)

Current flows in opposite direction to the electron motion



Diffusion Current First Flick's Law



Steady state

$$J_{\text{diff}} = qD \frac{dn}{dx}$$

Carriers have **random thermal motion** due to temperature. At thermal equilibrium:


- Carriers move randomly in all directions with average speed:
$$v_{\text{th}} = \sqrt{\frac{3k_B T}{m^*}}$$
- In regions of high concentration: more carriers moving in all directions
- In regions of low concentration: fewer carriers moving in all directions
- **Net Result:** More carriers move from high to low concentration regions

where J is diffusion flux, n concentration, x position. Negative sign indicates flow from high to low n. Units: D in cm²/s. 2.2 Ficks Second Law (Non-Steady State)

Current flows in opposite direction to the electron motion

Diffusion Current Second Flick's Law

- Transient (non-steady-state)**



$$\frac{\partial n}{\partial t} = D \frac{\partial^2 n}{\partial x^2}$$

governs $n(x, t)$ for time-varying diffusion. Solution for semi-infinite solid with surface concentration n_s :

$$n(x, t) = n_s - (n_s - n_0) \operatorname{erf}\left(\frac{x}{2\sqrt{Dt}}\right)$$

- Lets you estimate how long it takes for a desired concentration level to be reached at a certain depth.

- Fick's second law combined with recombination models predicts how minority carriers diffuse to the junction before recombining.

- **minority carrier diffusion in non-equilibrium conditions.**

Electrons

Equation: $\mathbf{J}_n = \mathbf{J}_{n,\text{drf}} + \mathbf{J}_{n,\text{diff}} = en\mu_n\mathbf{E} + eD_n\nabla n$ Meaning: Total

electron current as sum of field-driven drift and gradient-driven diffusion.

Holes

Equation: $\mathbf{J}_p = \mathbf{J}_{p,\text{drf}} + \mathbf{J}_{p,\text{diff}} = ep\mu_p\mathbf{E} - eD_p\nabla p$ Meaning: Total

hole current as sum of drift and diffusion (note sign for diffusion).

Overall Total Current

$\mathbf{J} = \mathbf{J}_n + \mathbf{J}_p$ Fundamental equations for analyzing semiconductor devices like p-n junctions and transistors.

At thermal equilibrium: No net current flows anywhere in the material.
This requires: $J_{\text{drift}} + J_{\text{diff}} = 0$


$$q\mu nE - qD\frac{dn}{dx} = 0$$

$$\mu nE = D\frac{dn}{dx}$$

Key Insight: At equilibrium, drift and diffusion perfectly cancel!

Consequence:

- No net current even though both drift and diffusion are acting
- The electric field creates a drift current in one direction
- The concentration gradient creates a diffusion current in opposite direction
- These must exactly balance at equilibrium



At thermal equilibrium, carriers follow Boltzmann statistics:

$$n(x) = n_0 \exp \left(-\frac{qV(x)}{k_B T} \right)$$

where $V(x)$ is the electrostatic potential.


Taking the derivative:


$$\frac{dn}{dx} = n_0 \left(-\frac{q}{k_B T} \right) \exp \left(-\frac{qV(x)}{k_B T} \right) \frac{dV}{dx}$$

$$\frac{dn}{dx} = -\frac{q}{k_B T} n(x) \frac{dV}{dx} = \frac{q}{k_B T} n(x) E$$

where $E = -\frac{dV}{dx}$ is the electric field.

Key Result: The concentration gradient is proportional to the electric field!





Step 1: Substitute Boltzmann into current balance

$$\mu n E = D \frac{dn}{dx} = D \cdot \frac{q}{k_B T} n E$$


Step 2: Cancel n and E (assuming both nonzero)

$$\mu = D \cdot \frac{q}{k_B T}$$

Step 3: Rearrange

$$D = \frac{k_B T}{q} \mu$$

Alternative form with thermal voltage $V_T = k_B T / q$:



What does $D = \frac{k_B T}{q} \mu$ tell us?

1. Microscopic Origin:

- Drift and diffusion arise from the **same scattering mechanism**
- Mobility μ measures how easily carriers drift
- The same μ determines how easily carriers diffuse
- No separate “diffusion coefficient mechanism”

2. Thermodynamic Consistency:

- Prevents spontaneous currents at equilibrium
- Ensures $J_{\text{total}} = 0$ when Boltzmann distribution exists
- If $D/\mu \neq k_B T/q$, the second law of thermodynamics would be violated

Primary Scattering types and effect on mobility

1. Lattice (Phonon) Scattering (μ_L):




- Caused by thermal vibrations of the lattice (phonons).
- Dominant at higher temperatures ($T > 150$ K).
- Temperature dependence: $\mu_L \propto T^{-3/2}$.

2. Ionized Impurity Scattering (μ_I):

- Due to Coulomb interactions with ionized donors N_d^+ or acceptors N_a^- .
- Dominant at lower temperatures.
- Temperature dependence: $\mu_I \propto T^{3/2}$; inversely proportional to total impurity concentration: $\mu_I \propto N_{\text{total}}^{-1}$.

3. CarrierCarrier Scattering (μ_{cc}):

- Occurs in heavily doped or degenerate semiconductors.
- Arises from Coulomb interactions among free carriers.
- Screening reduces scattering efficiency at very high densities.
- Dependence: $\mu_{cc} \propto n^{-1/3}$; weak temperature dependence near degeneracy.



Primary Scattering types and effect on mobility

Analytical Form

Matthiessens Rule:

$$\frac{1}{\mu(T, n)} = \frac{1}{\mu_{\text{phonon}}(T)} + \frac{1}{\mu_{\text{impurity}}(T, n)} + \frac{1}{\mu_{\text{carrier-carrier}}(n)}$$

Typical Dependencies:

$$\mu_{\text{phonon}} \propto T^{-3/2} \quad (\text{lattice vibrations})$$

$$\mu_{\text{impurity}} \propto \frac{T^{3/2}}{n} \quad (\text{Coulomb scattering})$$

$$\mu_{\text{carrier-carrier}} \propto n^{-1/3} \quad (\text{degenerate regime})$$

Approximate Combined Behaviour:

$$\mu(T, n) \approx \left(C_1 T^{3/2} n^{-1} + C_2 T^{-3/2} \right)^{-1}$$

Primary Scattering types and effect on mobility

Summary

Mobility decreases with both rising temperature and increasing doping.

- At low T : impurity scattering dominates.
- At high T : phonon scattering dominates.
- Maximum μ occurs at intermediate T (transition point).
- Doping increases scattering centres μ falls with n .

High T → more phonons → mobility decreases

High n → more impurity and carrier–carrier collisions → mobility decreases.

Einstein Relation: $D = \frac{k_B T}{q} \mu(T, n)$

Regime	Main Scattering	$\mu(T, n)$	$D(T, n)$
Low T , High n	Ionised impurity	$T^{3/2} n^{-1}$	$T^{5/2} n^{-1}$
High T , Any n	Lattice (phonon)	$T^{-3/2}$	$T^{-1/2}$
Very High n (deg.)	Carriercarrier	$n^{-1/3}$	$n^{-1/3} T$
Intermediate T	Mixed regime	$\mu_{\max}$	$D_{\max}$

Summary:

- D increases with T at low T (impurities) and decreases at high T (phonons).
- Maximum D occurs where both scattering mechanisms balance.

Ohm's law with T , E and n

Parameter	What increases	What happens microscopically
E	electric field	carriers heat up, scatter more, velocity saturates
T	temperature	more phonons (lattice vibrations) → more scattering
n	doping level	more impurities + carrier–carrier scattering

Anything that makes electrons collide more — higher **field**, higher **temperature**, or higher **doping** — will **reduce mobility**






Figure 5.7 | Carrier drift velocity versus electric field for high-purity silicon, germanium, and gallium arsenide. (From Sze [14].)

Hall Effect

Hall effect provides the experimental access to diffusivity



In the Hall effect, you **apply** a magnetic field and current, **measure** the transverse Hall voltage, and from these you **derive** the carrier type, concentration, and mobility —thereby connecting microscopic transport (diffusion, scattering) with macroscopic measurements.

- **Known quantities (controlled experimentally):**


- Current I
- Magnetic field B
- Sample geometry (thickness t , width w , length L)

Forces acting:

$$\mathbf{F} = q(\mathbf{E} + \mathbf{v} \times \mathbf{B})$$

$$E_H = v_x B_z$$

$$q(E_H + v_x B_z) = 0 \Rightarrow E_H = -v_x B_z = -\mu E_x B_z$$



$V_H > 0$ p-type (holes)

$V_H < 0$ n-type (electrons)

1. Force equilibrium:

$$qE_H = qv_x B_z = q\mu E_x B_z$$

2. Hall field and voltage:

$$E_H = \mu E_x B_z \Rightarrow V_H = E_H W = \mu E_x B_z W$$

3. Express drift current:

$$J_x = qn\mu E_x = \frac{I_x}{Wd} \Rightarrow E_x = \frac{I_x}{qn\mu Wd}$$

4. Substitute in V_H :

$$V_H = \frac{I_x B_z}{qnd}$$

(W cancels out)

5. Rearrange:

$$n = \frac{I_x B_z}{qdV_H}$$

$$\mu = \frac{\sigma}{qn} = \sigma R_H$$

where $R_H = V_H d / (I_x B_z)$.

Example 1: Conductivity in n-type Si

- Given: $N_d = 10^{17} \text{ cm}^{-3}$, $\mu_n = 1350 \text{ cm}^2 \text{ V}^{-1} \text{ s}^{-1}$,
 $e = 1.6 \times 10^{-19} \text{ C}$.
- Calculation: $\sigma_n \approx eN_d\mu_n = (1.6 \times 10^{-19} \text{ C}) \cdot (10^{17} \text{ cm}^{-3}) \cdot (1350 \text{ cm}^2 \text{ V}^{-1} \text{ s}^{-1}) \approx 216 \text{ S cm}^{-1}$.
- Resistivity: $\rho_n = 1/\sigma_n \approx 4.63 \times 10^{-3} \Omega \text{ cm}$.

Example 2: Hall Voltage in p-type Si

- Given: $p = 10^{16} \text{ cm}^{-3}$, $I_x = 1 \text{ mA}$, $B_z = 0.1 \text{ T}$, $W = 0.1 \text{ cm}$,
 $\mu_p = 480 \text{ cm}^2 \text{ V}^{-1} \text{ s}^{-1}$, thickness $t = 0.01 \text{ cm}$.
- $J_x = I_x/(Wt) = 100 \text{ A cm}^{-2}$.
- $R_H = 1/(ep) = 6.25 \times 10^3 \text{ cm}^3 \text{ C}^{-1}$.
- $E_y = R_H J_x B_z = 62.5 \text{ V cm}^{-1}$.