

- 1.4

Breaking Capacity

:
- 1.5

Type of Breaker

:
- 2.0

General Check-up

:
- 2.1

Check for Physical damage if any

:
- 2.2

Check enclosure for cleanliness and vermin proofing

:
- 2.3

Check earth bus continuity

:
- 2.4

Check withdraw ability of RMU

:
- 2.5

Check tightness of all bolts and wiring

:
- 3.0

Control Circuit and Operational Tests

:
- 3.1

Check mechanical charging-closing-tripping of RMU

:
- 3.2

Check mechanical interlocks of RMU

:
- 3.3

Check electrical charging-closing-tripping of RMU

:
- 3.4

Trip circuit healthiness and tripping through protective relays

:
- 3.5

Remote tripping-interlocks circuits checked

:
- 3.6

Check of signal lamps / annunciation circuits.

:
- 3.7

Check operation of spare contacts for customer use

:
- 3.8

Check panel space heater circuit

:

4.0 Current Transformer Test

4.1 Protection Core

Ph	Sr. No.	Ratio	VA	Acc. Class	Polarity	Primary Injected Current	Secondary Current	CT Resis.
R	1	45	78	756	86	45	89	55
Y	2	45	45	665	54	564	69	56
B	3	4545	75	56	657	86	65	25

5.0 Contact Resistance Test

With All Outgoing Feeders

PHASE	Resistance In Micro Ohms		
	RMU 1 & 2	RMU 2 & 3	RMU 3&4
R-R	120 μΩ	58 μΩ	56 μΩ
Y-Y	11 μΩ	256 μΩ	53 μΩ
B-B	120 μΩ	120 μΩ	89 μΩ

6.0 Coil Resistance Test

PHASE	Resistance In Ohms
Closing Coil	100
Tripping Coil 1 & 2	56
Spring Charging Motor	90

7.0 Remarks: