


POWER FEED X-AXIS



TP5356

Figure 4.18 - Power Feed X-Axis Control Assembly, Front View

ITEM	CODE NO.	DESCRIPTION	QTY
1	11011189	Screw, Button Hd Cap, #6-32 x .250"	4
2	11632618	Potentiometer, 500Ω, Log Taper	1
	11630445	Potentiometer, 8F Power Feed	1
3	11632153	Knob, Black	1
4	11632607	Fuseholder, Panel Mount	1
5	11632606	Fuse, 10 Amp	1
6	11632593	Light, Pilot	1
7	11632659	Switch, Toggle 2PST	1
8	11632628	Boot, Insulator	1
9	11632599	Nut, Hex	1
10	11632620	Pushbutton, 1PST	1
11	11632506	Boot, Insul PB/Switch	1
12	11636404	Panel	1
13	12636400	Box, Control	1
14	11636412	Cord, Power	1
15	11636411	Cover, Bottom, 6F Power Feed	1
	11630421	Cover, Bottom, 8F Power Feed	1
16	11632568	Board, Printed Circuit, 6F Power Feed (Not Shown)	1
	11630417	Board, Circuit, 8F Power Feed (Not Shown)	1
17	11630416	Assembly, Plug-In Connector Type Harness, 6F	1
	32632751	Assembly, Harness, Power Feed	1