


LUBRICATION SYSTEM



TP5348

Figure 4.10 - Lubrication System Assembly

LUBRICATION SYSTEM

ITEM	CODE NO.	DESCRIPTION	QTY
1*	11413210	Unit, Metering, Bijur #B-2495	3
2*	11413211	Unit, Metering, #FJB-1, B-2496	6
3	11413226	Plug, Closure, #B-3784	1
4	11413220	Bushing, Compression, Bijur #1371	11
5	11413221	Sleeve, Compression, Bijur #B-8272	11
6	11413224	Tubing, Brass, .156"	1
7	11413225	Tubing, Nylon, .156"	to
suit			
8	11413222	Connector, 90° EL	2
9	11410017	Junction, 4-Way	1
10	11413219	Nut, Compression	11
11	11413293	Bushing, Compression Sleeve	1
12	11410053	Hose, Flexible, 18" Lg	1
13	11413230	Bracket, Hose	1
14	11413233	Nut, Terminal	1
15	11011475	Screw, Round Hd Machine, .250"-20 x .500"	1
16	11413236	Clip, Tubing, #B-7535	2
17	11413290	Clip, Tubing, #A-2435	1
18	11410063	Junction, 10-Way	1
19	11011420	Screw, Round Hd Machine, #8-32 x .250"	3
20	11413235	Bushing, Drive	8
21	11011194	Screw, Button Hd Cap, .250"-20 x .5.00"	2
22	11011195	Screw, Button Hd Cap, .250"-20 x 1.00"	2
23	11413209	Pump, Auto Lube	1
	11410324	Pump, One Shot Lube, Manual	1

- CAUTION -

When replacing metering units be sure you replace with correct number meter units. A wrong installation will cause poor lubrication.