
DIGITAL DESIGNER 4.2

Model Name: line robo

Number of Bricks: 83









Step 2 of 49















Step 5 of 49















Step 8 of 49










Step 10 of 49




Step 11 of 49





Step 12 of 49



Step 13 of 49





Step 14 of 49





Step 15 of 49






Step 16 of 49











Step 18 of 49



Step 19 of 49







Step 20 of 49











Step 22 of 49










Step 24 of 49










Step 26 of 49



Step 27 of 49






Step 28 of 49






Step 29 of 49










Step 31 of 49



Step 32 of 49






Lego Digital Designer

Step 33 of 49






Step 34 of 49








Step 36 of 49












Step 38 of 49




Step 39 of 49







Step 40 of 49











Step 43 of 49






Step 44 of 49






Step 45 of 49





Step 46 of 49









Step 48 of 49





Step 49 of 49





© 2012 The LEGO Group. All rights reserved.
Use of the LEGO Digital Designer html print tool, signifies your agreement to the terms of use.