Audio Synthesizer Interface

Filter

Soft

1. Joystick

Detune

Echo

Harsh

Tempo

2. Filter Cutoff Freq.

3. Tempo

4. Play button

5. Pause button

Short

Note

Long

6. Sustain Ribbon

7. Step LEDs

8. Note potentiometers

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |