How to Update your Instrument Firmware

The instrument firmware can be updated with USB data cable through the type-c port on the side panel.

Caution: Updating your instrument firmware is a sensitive operation, to prevent damage to the instrument, do not power off the instrument or remove the USB memory device during the update process.

To update your instrument firmware, do the following:

1. Push the **System** button,select **System** in the bottom menu,press 1/2 to next page,press Upgrade ,the instrument weill have a prompt message.

2. Push the **System** button,in the bottom menu,press 1/2 to next page，Press USB to switch to MSC port. The external disk icon is displayed on the PC .

3. Visit the company's website on the PC and select the required instrument firmware upgrade package for the corresponding model. Download the " scope. upp " file in the firmware upgrade package to the PC, and copy the firmware to the external disk that is displayed.。

4. Restart the device. After the device is powered on, the upgrade status is displayed.

5. After the upgrade, the instrument will shut down automatically.

6. Press the ⏻ button to power on the instrument(Press System - System - 1/2 - About to check whether the version is the desired target version).