KeyStep

Sequencer

Create a sequence: toggle Seq mode, select location with encoder.

Step record: press REC, play one or more keys, let go of all to move to next step, STOP when done (max 64 steps, 8 notes in each step).

TAP for a rest. Hold key and press TAP to tie note (as many times as needed). For legato, hold TAP before playing notes (doesn't trigger new gate). Press REC while playing to replace notes.

Set empty Seq of specified length: press REC, hold REC, tap channel keys for number of steps (eg 16 + 16 for 32 steps)

length Hold REC and press MIDI channel to set length of seq
append Shift / REC to append notes (lengthens seq)
clear Shift / STOP to clear last note of Seq (shortens seq)

Arpeggiator

Toggle to Arp. Press PLAY and hold keys. REC button is inactive in Arp mode. Max 32 notes. Can change octave in Hold mode, as long as hold down at least one key.

Chord mode

chord mode Hold Shift / Hold, play chord. Lowest note becomes centre key for transposing chord. Now one note plays whole chord. Shift / Hold to exit.

apreggiate chords Arp mode, play, shift / Hold \rightarrow chord mode.

Other tips

transpose Shift / OCT- uses keyboard to transpose sequence Shift / OCT+ reverts to Kbd play.

MIDI, gate, swing Shift & key changes MIDI channel, gate & swing

2 MIDI channels Hold Shift & KBD PLAY (OCT+), select MIDI ch key allows keyboard to play different channel to sequence

skip selection Hold shift while turning knob to avoid playing the intermediate selections

restart Shift / PLAY to restart from beginning (rather than pause)

fine tempo Shift / Rate encoder for fine changes of tempo (Internal clock mode)