0x4000:0000

LOW_MEMORY 0x0040:0000


bss kernel img

stack

Memory space NOT drawn to scale

0x0000:0000 (0x0008:0000

for QEMU)



the init task

kernel img

stack
task_struct

