

C61

Handheld Computer

Accessories



STD. Spec.

Adapter



PWR-C61-5V2A-CN



PWR-C61-5V2A-EU



PWR-C61-5V2A-UK



PWR-C61-5V2A-US

Adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 5V2A, use with DC-BK-TypeC cable

QC Adapter



PWR-18W-CN



PWR-18W-EU



PWR-18W-UK



PWR-18W-US

Quick Charge adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 5V3A/12V1.5A/9V2A, use with DC-BK-TypeC cable
[Comment: standard adaptor and QC adaptor are alternative.](#)

USB Cable



DC-BK-TypeC
1.0 meter Type-C cable

Battery



BTRY-C61-67MA
6700mAh Li-ion battery, 3.8V ouput

Optional

Charging Cradles & Adapters



CRD-C61-MBC
Charging Cradle for main battery, up to 2 slots, use with DCP-WR-12V2A-XX adapter.



CRD-C61-PBC
Charging Cradle for pistol battery, up to 2 slots, use with DCP-WR-12V2A-XX adapter.



CRD-C61-INS



CRD-C61-RBC




CRD-C61-RBCE



CN UK EU US

CRD-C61-RBC/CRD-C61-RBCE
Charging Cradle for device, use with DCPWR-12V2A-XX adapter.
CRD-C61-RBCE is an advanced CRD-C61-RBC, w/sync, w/ethernet, w/DC. The cradle cup has an insert that must be removed prior to inserting the C61 with Rugged Boot.

DCPW-12V2A-XX
Adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 12V2A, DC



CRD-MCB
The base of 4-slots charging cradle set for 4 pieces of cradle, use with DCPWR-12V5A-XX adapter.
For load balance, recommendation:
1. 4x cradle for device
2. 3x cradle for device + 1x cradle for main battery
3. 2x cradle for device + 1x cradle for main battery + 1x cradle for pistol battery

Pistol Grip



RB-C61-PS
Snap-On Trigger Handle, use with optional pistol battery



BTY-C61-PB
Pistol battery, 5,200 mAh

Rugged Rubber Boot



RB-C61-RR
Rugged Rubber Boot, omni-directional protected. It can coexist with hand strap and supports CRD-C61-RBC/CRD-C61-RBCE charging cradle.

Hand Strap



RB-C61-HS
hand strap