# Machine Design Homework 1

June 5, 2022

Gabe Morris


```
[1]: # Notebook Preamble
import sympy as sp
import matplotlib.pyplot as plt
from IPython.display import display, Markdown

plt.style.use('maroon_ipynb.mplstyle')
```

# Contents

1	Problem 3 3			
	1.1	Given		
	1.2	Find		
		Solution		
2	Prob	olem 5		
	2.1	Given		
	2.2	Find		
		Solution		
3	Prob	olem 15		
_		Given		
		Find		
		Solution		
		3.3.1 Part A		
		3.3.2 Part D		
4	Prob	olem 20		
_		Given		
		Find		
		Solution		
		4.3.1 Principal Stresses and Max Shear Stress		
		4.3.2 Von Mises Stress		
		4.3.3 Mohr's Circle Diagram		
5	Drob	olem 42		
J		Given		
		Find		
		FING		

# 1.1 Given




Problem 3-3

# 1.2 Find


Sketch a free-body diagram of each element in the figure above. Compute the magnitude and direction of each force using an algebraic or vector method.

# 1.3 Solution


The overall structure has a free body diagram like so,



Separating the structure into individual elements would yield more equations to solve the system,



 ${\rm Link}\ 2$ 



Link 3

The 800 N force is a point load, which means it can only be applied to one link. This is why the load is shown in one FBD and not the other. Changing the link the point load is applied to will change the values for  $F_1$  and  $F_2$ , but it will not change the values of the reactions at O and A.

```
[2]: v = Ox, Oy, Ax, Ay, F1, F2 = sp.symbols('O_x O_y A_x A_y F_1 F_2')
y, x = sp.S(0.9), sp.S(0.9)/sp.tan(60*sp.pi/180) # Vertical and horizontal_
distance of the structure

# Overall structure equations
eq1 = sp.Eq(Ox + Ax, 800) # Sum in x
eq2 = sp.Eq(Oy - Ay, 0) # Sum in y
```

```
eq3 = sp.Eq(-Ay*x + 800*y, 0) # Sum the moments about 0
# Link 2 equations
eq4 = sp.Eq(0x + F1, 800) # Sum in x
eq5 = sp.Eq(0y, F2) # Sum in y
eq6 = sp.Eq(F1*y, 800*y) # Sum the moments about O
# Link 3 equations (don't need to use and still get the same answer)
\# eq4 = sp.Eq(Ax, F1)
\# eq5 = sp.Eq(Ay, F2)
\# eq6 = sp.Eq(F2*x, F1*y)
eqs = [eval(f'eq{i}') for i in range(1, 7)]
display(Markdown('**Equations:**'))
for eq in eqs:
    display(eq)
display(Markdown('---'))
A, b = sp.linear_eq_to_matrix(eqs, v)
matrix_eqn = sp.Eq(sp.MatMul(A, sp.Matrix(v)), b)
display(matrix_eqn)
display(Markdown('---'))
sol = sp.solve(matrix_eqn)
display(Markdown('**Solution:**'))
for val in v:
    display(sp.Eq(val, sol[val]))
```

#### **Equations:**

$$\begin{split} A_x + O_x &= 800 \\ -A_y + O_y &= 0 \\ -0.3\sqrt{3}A_y + 720.0 &= 0 \\ F_1 + O_x &= 800 \\ O_y &= F_2 \\ 0.9F_1 &= 720.0 \end{split}$$

$$\begin{bmatrix} 1 & 0 & 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & -1 & 0 & 0 \\ 0 & 0 & 0 & -0.3\sqrt{3} & 0 & 0 \\ 1 & 0 & 0 & 0 & 1 & 0 \\ 0 & 1 & 0 & 0 & 0 & -1 \\ 0 & 0 & 0 & 0 & 0.9 & 0 \end{bmatrix} \begin{bmatrix} O_x \\ O_y \\ A_x \\ A_y \\ F_1 \\ F_2 \end{bmatrix} = \begin{bmatrix} 800 \\ 0 \\ -720.0 \\ 800 \\ 0 \\ 720.0 \end{bmatrix}$$

# Solution:

$$O_{x} = 0.0$$

$$O_y = 1385.6406460551$$


$$A_x = 800.0$$

$$A_y = 1385.6406460551$$


$$F_1 = 800.0$$

$$F_2 = 1385.6406460551 \,$$

The internal stresses of each link may be found by using the method of sections.



Upper Section Cut



Lower Section Cut

```
[3]: F_OB, F_AB = sp.symbols(r'F_{OB} F_{AB}')

# Upper section equations
eq7 = sp.Eq(F_AB*sp.cos(sp.pi/3), 800) # Sum in x
```

```
eq8 = sp.Eq(F_OB, F_AB*sp.sin(sp.pi/3)) # Sum in y

display(eq7)
display(eq8)
display(Markdown('---'))

sol = sp.solve([eq7, eq8])

for val in [F_OB, F_AB]:
    display(sp.Eq(val, sol[val].n()))
```


$$\frac{F_{AB}}{2} = 800$$
 
$$F_{OB} = \frac{\sqrt{3}F_{AB}}{2}$$

 $F_{OB} = 1385.6406460551$ 

 $F_{AB} = 1600.0$ 

Link 2 is in compression and link 3 is in tension.

#### 2.1 Given



Problem 3–5
Dimensions in millimeters

#### 2.2 Find


Find the reactions at the supports and plot the shear and bending moment diagrams.

#### 2.3 Solution

Due to the large amount of practice, this problem is quite simple and can be plotted instantly without showing calculation.

```
[4]: 0, A, B, C = 0, 300, 300 + 900, 300 + 900 + 300
     V_0, V_A, V_B, V_C = 8.2, 8.2 - 9, 8.2 - 9 - 5, 0 # Values shortly after cross_
     ⇔the point
    M_0, M_A, M_B, M_C = 0, V_0*300, V_0*300 + V_A*900, V_0*300 + V_A*900 + V_B*300
     x = [0, A, A, B, B, C, C]
     V = [V_0, V_0, V_A, V_A, V_B, V_B, V_C]
     x_bending = [0, A, B, C]
     M = [M_O, M_A, M_B, M_C]
     fig, shear = plt.subplots()
     bend = shear.twinx()
     shear.plot(x, V, label='Shear')
     shear.set_xlabel('$x$ ($mm$)')
     shear.set_ylabel('$V$ ($kN$)')
     bend.plot(x_bending, M, label='Bending', color='black')
     bend.set_ylabel(r'$M$ ($N\cdot m$)')
     bend.grid(visible=False)
```

```
shear.legend(handles=[shear.lines[0], bend.lines[0]], labels=['Shear', __
 ⇔'Bending'])
plt.show()
```



Notice that the plot above has a dual y-axis.

The values at the points are (shortly after for the shear values),

- $$\begin{split} \bullet & \ V_O = 8.2 \ kN, \ M_O = 0 \ N \cdot m \\ \bullet & \ V_A = -0.8 \ kN, \ M_A = 2460 \ N \cdot m \\ \bullet & \ V_B = -5.8 \ kN, \ M_B = 1740 \ N \cdot m \\ \bullet & \ V_C = 0 \ kN, \ M_C = 0 \ N \cdot m \end{split}$$

#### 3.1 Given

Plane stress values,

a. 
$$\sigma_x=20~kpsi,~\sigma_y=-10~kpsi,~{\rm and}~\tau_{xy}=8~kpsi~cw$$
b.  $\sigma_x=-12~kpsi,~\sigma_y=22~kpsi,~{\rm and}~\tau_{xy}=12~kpsi~cw$ 

#### **3.2** Find

Draw a Mohr's circle diagram. Find the principal normal and shear stresses, and determine the angle from the x-axis to  $\sigma_1$ . Draw the stress elements as in Figure 3-11c and d.

#### 3.3 Solution


Mohr's circle is a circle that has the following characteristics:

- The x-axis is  $\sigma$  and the y-axis is  $\tau$ .
- The center of the circle is along the x-axis at the average of  $\sigma_x$  and  $\sigma_y$ .
- The radius of the circle is  $R = \sqrt{\left(\frac{\sigma_x \sigma_y}{2}\right)^2 + \tau_{xy}^2}$ .

The principle stresses and max angles may be calculated using the following,


$$\begin{split} \sigma_1, \sigma_2 &= \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} \\ \tau_1, \tau_2 &= \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} \\ \tan 2\phi_p &= \frac{2\tau_{xy}}{\sigma_x - \sigma_y} \\ \tan 2\phi_s &= -\frac{\sigma_x - \sigma_y}{2\tau_{xy}} \end{split}$$

Here is a breakdown of Mohr's circle,



# 3.3.1 Part A

Using the information from the figure above,



Center and Radius:

$$C = \frac{\sigma_x}{2} + \frac{\sigma_y}{2} = 5$$

$$R = \sqrt{\tau_{xy}^2 + \left(\frac{\sigma_x}{2} - \frac{\sigma_y}{2}\right)^2} = 17.0$$

# **Principle Stresses:**

$$\sigma_1=C+R=22.0$$

$$\sigma_2 = C - R = -12.0$$


$$\tau_1=R=17.0$$

$$\tau_2 = -R = -17.0$$

#### Angle of Occurrence:

$$2\phi_p = \operatorname{atan}\left(\frac{2\tau_{xy}}{\sigma_x - \sigma_y}\right) = 28.072486935853$$

#### 3.3.2 Part D



#### Center and Radius:

$$C = \frac{\sigma_x}{2} + \frac{\sigma_y}{2} = 5.0$$

$$R = \sqrt{\tau_{xy}^2 + \left(\frac{\sigma_x}{2} - \frac{\sigma_y}{2}\right)^2} = 20.8086520466848$$

#### **Principle Stresses:**

$$\sigma_1 = C + R = 25.8086520466848$$

$$\begin{split} &\sigma_2 = C - R = -15.8086520466848 \\ &\tau_1 = R = 20.8086520466848 \\ &\tau_2 = -R = -20.8086520466848 \end{split}$$

# Angle of Occurrence:

$$2\phi_p = \mathrm{atan}\left(\frac{2\tau_{xy}}{\sigma_x - \sigma_y}\right) = 144.782407031807$$

#### 4.1 Given

Element stresses in ksi:

- $\sigma_x = -6$
- $\sigma_{u} = 18$
- $\sigma_z = -12$
- $\bullet \quad \tau_{xy}=9$
- $\tau_{yz} = 6$
- $\tau_{zx} = -15$

#### 4.2 Find

Determine the principal stresses and draw a complete Mohr's three-circle diagram, labeling all points of interest. Report the maximum shear stress for this case.

#### 4.3 Solution

#### 4.3.1 Principal Stresses and Max Shear Stress

The principal stresses may be found by finding the roots of the following expression,

$$\sigma^3 - \sigma^2 \left(\sigma_x + \sigma_y + \sigma_z\right) + \sigma \left(\sigma_x \sigma_y + \sigma_x \sigma_z + \sigma_y \sigma_z - \tau_{xy}^2 - \tau_{yz}^2 - \tau_{zx}^2\right) - \sigma_x \sigma_y \sigma_z + \sigma_x \tau_{yz}^2 + \sigma_y \tau_{zx}^2 + \sigma_z \tau_{xy}^2 - 2\tau_{xy} \tau_{yz} \tau_{zx} = 0$$

```
[7]: sig_x, sig_y, sig_z, tau_xy, tau_zx, tau_yz = sp.symbols(r'\sigma_x \sigma_yu\sigma_z \tau_{xy} \tau_{zx} \tau_{yz}')
sig = sp.Symbol(r'\sigma')
sig1, sig2, sig3 = sp.symbols(r'\sigma_1 \sigma_2 \sigma_3')

poly = sig**3 - (sig_x + sig_y + sig_z)*sig**2 + (sig_x*sig_y + sig_x*sig_z + sig_y*sig_z - tau_xy**2 - tau_yz**2 - tau_zx**2)*sig - (sig_x*sig_y*sig_z + sig_y*sig_z - tau_xy**2 - sig_x*tau_yz**2 - sig_y*tau_zx**2 - sig_x*tau_xy**2)

display(sp.Eq(poly.simplify(), 0))
poly_ = poly.subs([(sig_x, -6), (sig_y, 18), (sig_z, -12), (tau_xy, 9), sig_y))
sig(tau_yz, 6), (tau_zx, -15)])
roots = [sp.re(root.n()) for root in sp.roots(poly_, sig)]
roots_ = sorted(list(roots), reverse=True)
s1, s2, s3 = roots_
for i, j in zip((sig1, sig2, sig3), roots_):
    display(sp.Eq(i, j))
```

$$\sigma^3 - \sigma^2 \left(\sigma_x + \sigma_y + \sigma_z\right) + \sigma \left(\sigma_x \sigma_y + \sigma_x \sigma_z + \sigma_y \sigma_z - \tau_{xy}^2 - \tau_{yz}^2 - \tau_{zx}^2\right) - \sigma_x \sigma_y \sigma_z + \sigma_x \tau_{yz}^2 + \sigma_y \tau_{zx}^2 + \sigma_z \tau_{xy}^2 - 2\tau_{xy}\tau_{yz}\tau_{zx} = 0$$

 $\sigma_1 = 21.0369191756785$ 

 $\sigma_2 = 5.67061153118965$ 

 $\sigma_3 = -26.7075307068682$ 

The max shear stress is,

$$\tau_{max} = \frac{\sigma_1 - \sigma_3}{2}$$

- [8]: (s1 s3)/2
- [8]: 23.8722249412734

#### 4.3.2 Von Mises Stress

The Von Mises Stress is,

[9]: 42.2137418384109

The Von Mises Stress may also be computed without using the principal stresses,

```
[10]: sig_x, sig_y, sig_z, tau_xy, tau_yz, tau_zx = -6, 18, -12, 9, 6, -15
(1/sp.sqrt(2)*sp.sqrt((sig_x - sig_y)**2 + (sig_y - sig_z)**2 + (sig_z -
sig_x)**2 + 6*(tau_xy**2 + tau_yz**2 + tau_zx**2))).n()
```


[10]: 42.2137418384109

# 4.3.3 Mohr's Circle Diagram


```
[11]: # Calculating additional shear stress values
    tau_1_2, tau_2_3 = sp.symbols(r'\tau_{1/2} \tau_{2/3}')
    display(sp.Eq(tau_1_2, (s1 - s2)/2))
    display(sp.Eq(tau_2_3, (s2 - s3)/2))
```

 $\tau_{1/2} = 7.68315382224444$ 

 $\tau_{2/3} = 16.1890711190289$ 




#### 5.1 Given



 $F = 4 \ kN$ ,  $a = 6 \ mm$ ,  $b = 18 \ mm$ , and  $d = 12 \ mm$ 

# **5.2** Find

Find the maximum bending and shear stress if modeled like so,



# 5.3 Solution


Start with a shear and moment diagram.

```
fig, ax1 = plt.subplots()
ax2 = ax1.twinx()

ax1.plot(x_shear, V, label='Shear')
ax1.set_xlabel('$x$ ($mm$)')
ax1.set_ylabel('$V$ ($kN$)')

ax2.plot(x, M, label='Bending', color='black')
ax2.set_ylabel(r'$M$ ($N\cdot m$)')
ax2.grid(visible=False)

ax1.legend(handles=[ax1.lines[0], ax2.lines[0]], labels=['Shear', 'Bending'])
plt.show()
```



The maximum bending moment is 15  $N \cdot m$ , and the maximum shear stress is  $\tau_{max} = 2000 \ N$ . The normal and shear stress due to bending is,

$$\sigma_{max} = \frac{Mc}{I}$$

$$I = \frac{1}{4}\pi r^4$$

and for shear, the maximum stress for circular cross-sections is,

$$\tau_{max} = \frac{4}{3} \frac{V}{A}$$

[13]: M, c = sp.S(15), sp.S(0.006) I = sp.S(0.25)\*sp.pi\*sp.S(0.006)\*\*4 sig\_max = M\*c/I sig\_max.n() # in Pa

# [13]: 88419412.8288307

[14]: V, A = 2000, sp.pi\*sp.S(0.006)\*\*2
tau\_max = 4/3\*V/A
tau\_max.n() # in Pa

# [14]: 23578510.0876882