



```
#include "buttons.h"
int main(void) {
    unsigned char portValue;
    // Port A access
    AD1PCFG = 0xFFFF;
    TRISA = 0x0000;
    portValue = 0b00000000;
    while(1) {
        if (BUTTON_IsPressed ( BUTTON_S3 ) == true) {
            portValue = 0b11110000;
        } else if ((BUTTON_IsPressed ( BUTTON_S4 ) == true)) {
            portValue = 0b00001111;
        }
        LATA = portValue;
    }
    return -1;
}
```

II opcja:

```
#include "buttons.h"
int main(void) {
    unsigned char portValue;
    AD1PCFG = 0xFFFF; // set to digital I/O (not analog)
    TRISA = 0x0000; // set all port bits to be output
    portValue = 0b00000000;
    if (BUTTON_IsPressed ( BUTTON_S3 ) == true) {
        portValue = 0b11110000;
    } else if ((BUTTON_IsPressed ( BUTTON_S4 ) == true)) {
        portValue = 0b00001111;
    }
    LATA = portValue;
}
```

Co się zmienia?