







LiPo Charger



DC/DC



IMU



- SWO TP_SWO
- SWDIO TP_SWIO
- SWDCLK TP_SWDCLK
- RESET TP_RESET
- 3V3 TP_3.3V
- GND TP_GND

SWD

