Digital Systems: Problem sheet 3

Mike Spivey, Hilary Term, 2019

- 1 Figure 1 shows the interrupt-based driver for serial output that we studied in the lecture. The functions intr_disable() and intr_enable() use the instructions cpsid i and cpsie i to change the PRIMASK bit in the CPU that allows interrupts. The function pause() uses the wfe instruction to halt the CPU until an interrupt occurs.
- (a) What relationship is maintained among the values of bufin, bufout and bufcnt? Try to find an alternative implementation with only two integer variables.
- (b) Why is it necessary in serial_putc to disable interrupts before checking txidle?
- (c) Why must interrupts be disabled during the command bufcnt++? *Hint:* consider the assembly-language equivalent of the command.
- (d) Study the difference between the wfe and wfi instructions, and explain why wfe is needed in this program.
- (e) If it was important to have interrupts disabled for the shortest possible time, how could the code of serial_putc be modified so as to remain safe?
- 2 Program heart-intr embeds all the code needed to multiplex the LED display in the handler for the timer interrupt, allowing the 'main program' to be devoted to other tasks but it can display only a static image. Show how to enhance it to show an animated heartbeat, like the one in Lab 2. What are the limitations of this approach?
- 3 The NRF51822 has a hardware random number generator. When appropriately configured, it periodically generates an interrupt with handler rng_handler, and an eight-bit random number can then be retrieved from the device register RNG_VALUE before resetting the event flag RNG_VALRDY to zero. Design an interrupt-based driver for the random number generator; provide two functions

```
unsigned randint(void);
unsigned roll(void);
```

```
void uart_handler(void) {
    if (UART_TXDRDY) {
        UART_TXDRDY = 0;
        if (bufcnt == 0)
            txidle = 1;
        else {
            UART_TXD = txbuf[bufout]; bufcnt--;
            bufout = (bufout+1) % NBUF;
        }
    }
}
/* serial_putc -- send output character */
void serial_putc(char ch) {
    while (bufcnt == NBUF) pause();
    intr_disable();
    if (txidle) {
        UART_TXD = ch;
        txidle = 0;
        txbuf[bufin] = ch; bufcnt++;
        bufin = (bufin+1) % NBUF;
    intr_enable();
}
```

Figure 1: *Code for interrupt-driven serial output*

such that randint() returns a random four-byte value each time it is called, and roll() returns a random integer between 1 and 6, with each outcome having precisely equal probability. Arrange a suitable buffering scheme so that the caller of these functions does not have to wait if it calls them infrequently enough, and introduce a subroutine whenever doing so avoids repeating the same code in more than one place. What should happen if random bytes are generated by the hardware faster than the program is consuming them?

- 4 A cut-down version of the Cortex-M0 saves only the program counter and the processor status register to the stack before invoking the interrupt handler. It does not set lr to a magic value, but leaves it unchanged, and returning from the interrupt requires a special instruction rti (with encoding 0xbfd0). Design an assembly-language adapter that allows a C function such as uart_handler in Exercise 1 to be installed as an interrupt handler.
- 5 In the buffer overrun attack of Lecture 7, a long input string was able to overflow the buffer in the frame of getnum() and replace its return address. This worked because the buffer was stored at a lower address than the register save area in getnum's stack frame. Would buffer overrun attacks be prevented if the stack were to grow upwards in memory instead of downwards?