

Matcha On Ice Cafe — Equipment & Bar Manual

I The Grinder

Fiorenzato E64 Evo Pro

The E64 Evo Pro is a 64 mm flat-burr commercial grinder built for on-demand dosing — it grinds fresh for each shot rather than sitting pre-ground in a hopper, dosed through a programmable touchscreen rather than a mechanical doser.

Grind size is set with a stepless micrometric adjustment collar, so there are no click-stops to count. Dial in gradually and taste — or better, time the shot — rather than chasing a specific number on the collar. There is no single correct setting: only what lands the shot in the 25–30 second extraction window (see Coffee Bar Manual, Espresso Basics). Adjust in small increments and re-taste.

SPECIFICATIONS

Burr Size	64 mm
Burr Type	Flat
Dosing	On-demand
Adjustment	Stepless (no click-stops)

DIAL-IN & CARE

- [Placeholder] Describe the daily startup procedure here (power on, warm-up time before the first grind).
- [Placeholder] Describe how to select or program a dose on the touchscreen here.
- [Placeholder] Describe the daily cleaning routine here (hopper, chute, exterior).
- [Placeholder] Describe the weekly deep-clean here (burr removal, brush-down).

II The Espresso Machine

Sanremo Zoe Compact, 2 Group

The Zoe Compact is a 2-group machine with independently PID-controlled boilers per group — each side can be dialed to its own brew temperature, useful for running more than one bean on the bar at once.

Temperature stability depends on a full warm-up before service. A machine that is merely powered on is not necessarily ready — give the boilers and group heads time to stabilize before pulling shots for guests.

SPECIFICATIONS

Groups	2
Boiler Control	Independent PID per group
Warm-Up Time	30–45 min before service

STARTUP & CARE

1. [Placeholder] Describe the daily startup procedure here (power on, warm-up time, target temperatures).
2. [Placeholder] Describe the daily backflushing routine here (detergent, cycles, which groups).
3. [Placeholder] Describe the closing shutdown procedure here.
4. [Placeholder] Describe the weekly deep-clean here (steam wands, drip tray, gaskets).

III Steaming Milk

Microfoam Technique

Good microfoam is glossy and velvety with no visible bubbles — thick enough to hold latte art, light enough to integrate into the drink rather than sitting on top like dry foam.

It is built in two stages, the same logic as Cold Foam: first stretch, incorporating air near the surface while the milk is still cool and the volume grows; then texture, submerging the wand to spin that air into the milk until smooth.

SETUP & TARGET

Target Temperature	150°F – 155°F (65°C – 68°C)
Pitcher Fill (before steaming)	1/3 – 1/2 full
Tip Depth — Stretch	Just below the surface
Tip Depth — Texture	Fully submerged, angled to spin

Stop just before the target range — residual heat carries it the rest of the way. Past 170°F / 77°C, milk scalds and turns sweet-flat.

TECHNIQUE

1. Purge the wand briefly to clear condensation before steaming.
2. Submerge the tip just below the surface, slightly off-center, to begin stretching — a light hissing or tearing sound means air is incorporating.
3. Once the volume has grown by about a third, submerge the tip fully and angle it to create a whirlpool, texturing out any large bubbles.
4. Keep spinning the milk until the pitcher is warm to the touch and near the target temperature.
5. Purge and wipe the wand immediately after every use.
6. Tap the pitcher on the counter and swirl to pop any remaining bubbles before pouring.

IV Barista Tools

The Kit on the Bar

TOOLS

Tamper (58 mm, flat base) —

- Distribute the grounds evenly before tamping.
- Tamp level and firm, straight down — consistent pressure, not forced.

An off-level tamp is one of the most common causes of channeling.

WDT Tool (Fine-gauge tines) —

- Stir through the dose in a circular motion after grinding, before tamping.
- Break up any clumps and redistribute the grounds evenly across the basket.

Especially useful on darker roasts, which clump more from surface oils.

Digital Scale (0.1 g precision) —

- Weigh the dose before grinding.
- Weigh the shot as it pulls, to hit the target yield.

Dose, yield and time together — not the clock alone — is what makes a shot repeatable.

Milk Pitchers (12 oz / 20 oz / 32 oz) —

- Match the pitcher to the drink — a smaller pour is easier to control in a smaller pitcher.
- Fill no more than halfway before steaming, to leave room for the milk to expand.

Rinse immediately after each use — dried milk is the hardest to get out.

Knock Box (Rubber-lined) —

- Knock the spent puck out of the portafilter with a firm, single motion.
- Empty and rinse it out through service, not just at close.

A full knock box slows everyone down — empty it before it's overflowing.

Puck Screen (58 mm) —

- Place on top of the dose before tamping.
- Wipe clean between shots; it keeps the group head cleaner and reduces channeling.

Not a substitute for a good distribution and tamp — it just keeps the mess contained.

Cleaning Kit (Blind basket, group brush, detergent) —

- Backflush at the intervals set out in The Espresso Machine's Startup & Care.
- Brush the group head daily; deep-clean the shower screen and gasket weekly.

A clean group head is a taste issue before it's a hygiene one — old coffee oils turn rancid fast.

WORKSTATION SETUP

Lay the station out in the order of the shot — grinder, portafilter, tamper, machine — left to right (or mirrored, for a left-handed bar), so every shot moves in one direction without doubling back.

Keep the knock box within arm's reach of the grinder, not the machine — pucks get knocked out right after grinding a new dose, not after pulling a shot.

Separate cloths by task: one dry for wiping the steam wand, one damp for the group heads and drip tray, and never the two swapped — milk residue on a group-head cloth spreads dried milk instead of removing it.