

Solutions

- 1. Resistor value must be= 1K
- 2. Battery voltage= 5V
- 3. Arduino Uno needs Hex file
- 4. IR sensor needs Hex file
- 5. If in Proteus connections- It is showing Gray then it is not correct.'
- 6. Proteus must be start- with- Run as administrator other it will show issues as library not found.
- 7.Copy and paste Arduino library file and IR sensor Library file in—
C:\Program Files (x86)\Labcenter Electronics\Proteus 8 Professional\DATA\LIBRARY