DISCRETE TRANSISTOR OP-AMP

Jason Gallicchio and Claude, rev A, 2026-10-24

github.com/gallicchio/op-amp-pcb
circuit, scripts, schematic, this board

The op-amp of Learning the Art of Electronics
(Hayes & Horowitz, 2016), built from eight
2N3904 / 2N3906 so you can probe every node.

POWER: +15 V, GND, −15 V into the terminal, 20 mA; set
the supply's limit to 50 mA. Both LEDs light if right.
SWITCHES, usual: TAIL 1 on (Q6 current source),
COMPENSATION 1 on (100 pF + 1k), FEEDBACK as needed.
TAIL 2 = 10k tail resistor instead.
COMPENSATION 2 = the bare 100 pF, no 1k (the book's):
the x11 amp still works, a follower rings.
FEEDBACK 1 = X to IN−: gain 11. 2 = OUT to IN−:
follower. Both off: it is a bare op-amp.
AS AN OP-AMP IN YOUR OWN CIRCUIT (Labs 6-9): FEEDBACK
both off; IN−, IN+, OUT and GND on the terminals
are pins 2, 3, 6 of a '411. Mind its 2 uA of input
bias current (no 10 M feedback); its output limits
at 20 mA, like a real one (Q7, Q8; not in the book).
OFFSET NULL: as a follower with IN+ grounded,
turn RV1 until OUT reads 0 V.
INPUTS: ±12 V. OUT: ±12 V into 1k, 15 mA; a short to
ground is survived, to a rail only for seconds.
PROBING: a loop on every named node for a scope
hook, and GND loops for the clip.

Sheet: File: opamp.kicad_pcb		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 10.0.7		Id: 1/1