OMNIHARP

CHORD SYNTH · GANWALK

BEAT

MIDI

POWER

(◉ω◉)
CHORD!

SYS MONITOR

C♯m7

CHORD DISPLAY

MENU · PUSH

MIXER

MASTER

CHORD

STRUM

TONE

REVERB

GLIDE

RHYTHM

TEMPO

VOLUME

ARPEGGIATOR

SPEED

VOLUME

SHIFT

MUTE

KEY

OCT –

OCT +

F1

◀ STYLE

STYLE ▶

PLAY

◀ MODE

MODE ▶

ARP

	C	Db	D	Eb	E	F	Gb	G	Ab	A	Bb	B
Major												
Minor												
7th												
m7												
Maj7												
Dim7												

STRUMPLATE · HIGH ▲

▼ LOW

100 mm — measure to confirm the print is at 100%

OmniHarp · top panel 408.6 × 317.3 mm · with wood frame 468.6 × 347.3 mm

red = cut · black = silkscreen · grey dashed = parts · blue dashed = seam between the two panel parts · brown = wood frame · draft