




GANWALK
OMNIHARP
CHORD SYNTH
POWER
(◉ω◉)
CHORD!
SYS MONITOR
C # m
CHORD DIS
MIXER
RHYTHM
+1
0
−1
MASTER
CHORD
STRUM
TONE
REVERB
GLIDE
OCTAVE
TEMPO
RHYTHM
PLAY
◀ RHYTHM
RHYTHM ▶
TAP
ARP
◀ MODE
MODE ▶
KEY
MUTE
SHIFT


STRUMPLATE · HIGH ▲
m 7
PLAY
ARP
BEAT
MIDI
ORD DISPLAY
ARPEGGIATOR
SPEED
ARP VOL
MENU
F1
F2




Sheet 3/9 · row 1, column 3 · neighbouring sheets overlap by 10 mm (blue dashed edge) · print at 100% / actual size


PLAY
◀ RHYTHM
RHYTHM ▶
TAP
ARP
◀ MODE
MODE ▶
KEY
MUTE
SHIFT
C
Db
D
Eb
E
F
Gb
G
Ab
A
Major
Minor
7th
m7
Maj7
Dim7


F1 F2

Bb B




▼ LOW

OmniHarp · top panel 483 × 319.3 mm · with wood frame 543 × 349.3 mm




Sheet 6/9 · row 2, column 3 · neighbouring sheets overlap by 10 mm (blue dashed edge) · print at 100% / actual size



100 mm — measure to confirm the print is at 100%

OmniHarp · top panel 483 × 319.3 mm · with wood frame 543 × 349.3 mm

red = cut · black = silkscreen · grey dashed = parts under/over the panel · brown = wood frame · draft



Sheet 9/9 · row 3, column 3 · neighbouring sheets overlap by 10 mm (blue dashed edge) · print at 100% / actual size