POWER

(◉ω◉)
CHORD!

SYS MONITOR

C#m7

CHORD DISPLAY

OMNIHARP

MENU · PUSH

MIXER

RHYTHM

ARPEGGIATOR

MASTER CHORD STRUM TONE REVERB GLIDE TEMPO VOLUME SPEED VOLUME

SHIFT MUTE KEY OCT − OCT + F1 ◀ STYLE STYLE ▶ PLAY MODE ◀ MODE ▶ ARP

	C	Db	D	Eb	E	F	Gb	G	Ab	A	Bb	B
Major												
Minor												
7th												
m7												
Maj7												
Dim7												

STRUMPLATE · HIGH ▲

▼ LOW

100 mm — measure to confirm the print is at 100%

OmniHarp · top panel 416.6 × 310.3 mm · with wood frame 456.6 × 350.3 mm
red = cut · black = silkscreen · grey dashed = parts · blue dashed = seam between the two panel parts · brown = wood frame · draft