## DC Sweep

VV\_Generi@1 net@4 gnd DC 0.8 AC 0 VV\_Generi@2 net@8 gnd DC 0.8 AC 0

.END

Xnand2@0 net@4 net@8 nand2@0 Out ese3700 nand2

```
*** SPICE deck for cell hw2{sch} from library ese3700
*** Created on Sat Feb 08, 2025 10:04:09
*** Last revised on Sat Feb 08, 2025 10:32:13
*** Written on Sat Feb 08, 2025 13:23:23 by Electric VLSI Design System, version 9.07
*** Layout tech: mocmos, foundry MOSIS
*** UC SPICE ***, MIN_RESIST 4.0, MIN_CAPAC 0.1FF
* Model cards are described in this file:
.include C:/Users/garre/ese 3700/22nm HP.pm
*** SUBCIRCUIT ese3700 nand2 FROM CELL nand2{sch}
.SUBCKT ese3700 nand2 A B Out
** GLOBAL and
** GLOBAL vdd
Mnmos@0 Out A net@1 gnd N L=0.044U W=0.044U
Mnmos@1 net@1 B gnd gnd N L=0.044U W=0.044U
Mpmos@0 vdd B Out vdd P L=0.044U W=0.044U
Mpmos@1 vdd A Out vdd P L=0.044U W=0.044U
.ENDS ese3700 nand2
.global gnd vdd
*** TOP LEVEL CELL: hw2{sch}
VV_Generi@0 vdd gnd DC 0.8 AC 0
```

## **Transient Analysis**

```
*** SPICE deck for cell hw2_tranisient{sch} from library ese3700
*** Created on Sat Feb 08, 2025 11:42:36
*** Last revised on Sat Feb 08, 2025 12:56:56
*** Written on Sat Feb 08, 2025 13:23:47 by Electric VLSI Design System, version 9.07
*** Layout tech: mocmos, foundry MOSIS
*** UC SPICE ***, MIN_RESIST 4.0, MIN_CAPAC 0.1FF
* Model cards are described in this file:
.include C:/Users/garre/ese 3700/22nm HP.pm
*** SUBCIRCUIT ese3700 nand2 FROM CELL nand2{sch}
.SUBCKT ese3700 nand2 A B Out
** GLOBAL and
** GLOBAL vdd
Mnmos@0 Out A net@1 gnd N L=0.044U W=0.044U
Mnmos@1 net@1 B gnd gnd N L=0.044U W=0.044U
Mpmos@0 vdd B Out vdd P L=0.044U W=0.044U
Mpmos@1 vdd A Out vdd P L=0.044U W=0.044U
.ENDS ese3700__nand2
.global gnd vdd
*** TOP LEVEL CELL: hw2 tranisient(sch)
VVPulse@0 net@30 gnd pulse (0 0.8V 50ps 10ps 10ps 250ps 500ps) DC 0V AC 0V 0
VV Generi@0 vdd gnd DC 0.8 AC 0
VV Generi@1 net@27 gnd DC 0.8 AC 0
VV Generi@2 net@20 gnd DC 0.8 AC 0
Xnand2@0 MeasureHere1 MeasureHere1 nand2@0 Out ese3700 nand2
Xnand2@1 MeasureHere2 MeasureHere2 nand2@1_Out ese3700__nand2
Xnand2@2 MeasureHere2 MeasureHere2 nand2@2 Out ese3700 nand2
Xnand2@3 MeasureHere1 net@20 MeasureHere2 ese3700 nand2
Xnand2@4 MeasureHere1 net@20 nand2@4 Out ese3700 nand2
Xnand2@5 net@30 net@27 MeasureHere1 ese3700 nand2
.END
```